



## Aastra Model 6735i IP Phone



### User Guide

### Release 3.2.2 Service Pack 3 Hot Fix 1

41-001451-00 REV01 – 06.2013

# Software License Agreement

Aastra Telecom Inc., hereinafter known as "Seller", grants to Customer a personal, worldwide, non-transferable, non-sub-leaseable and non-exclusive, restricted use license to use Software in object form solely with the Equipment for which the Software was intended. This Product may integrate programs, licensed to Aastra by third party Suppliers, for distribution under the terms of this agreement. These programs are confidential and proprietary, and are protected as such by copyright law as unpublished works and by international treaties to the fullest extent under the applicable law of the jurisdiction of the Customer. In addition, these confidential and proprietary programs are works conforming to the requirements of Section 401 of title 17 of the United States Code. Customer shall not disclose to any third party such confidential and proprietary programs and information and shall not export licensed Software to any country except in accordance with United States Export laws and restrictions.

Customer agrees to not reverse engineer, decompile, disassemble or display Software furnished in object code form. Customer shall not modify, copy, reproduce, distribute, transcribe, translate or reduce to electronic medium or machine readable form or language, derive source code without the express written consent of the Seller and its Suppliers, or disseminate or otherwise disclose the Software to third parties. All Software furnished hereunder (whether or not part of firmware), including all copies thereof, are and shall remain the property of Seller and its Suppliers and are subject to the terms and conditions of this agreement. All rights reserved.

Customer's use of this software shall be deemed to reflect Customer's agreement to abide by the terms and conditions contained herein. Removal or modification of trademarks, copyright notices, logos, etc., or the use of Software on any Equipment other than that for which it is intended, or any other material breach of this Agreement, shall automatically terminate this license. If this Agreement is terminated for breach, Customer shall immediately discontinue use and destroy or return to Seller all licensed software and other confidential or proprietary information of Seller. In no event shall Seller or its suppliers or licensors be liable for any damages whatsoever (including without limitation, damages for loss of business profits, business interruption, loss of business information, other pecuniary loss, or consequential damages) arising out of the use of or inability to use the software, even if Seller has been advised of the possibility of such damages.

# Content

<b>Software License Agreement</b> .....	ii
<b>Content</b> .....	iii
<b>Welcome</b> .....	1
<i>About this Guide</i> .....	1
<i>Documentation</i> .....	1
<i>Phone Features</i> .....	1
<i>Requirements</i> .....	2
<i>Installation and Setup</i> .....	2
<b>Getting Started</b> .....	3
<i>Plugging in and Starting the Phone</i> .....	3
<i>Network Connected/Network Disconnected</i> .....	5
<i>Idle Screen</i> .....	6
<b>IP Phone Keys</b> .....	10
<i>Key Panel</i> .....	10
<i>Key Descriptions</i> .....	11
<i>Keypad Keys</i> .....	13
<b>Methods for Customizing Your Phone</b> .....	14
<i>Phone Options via the IP Phone UI</i> .....	14
<i>Phone Options via the Aastra Web UI</i> .....	17
<b>Phone Status</b> .....	21
<i>Phone Status via IP Phone UI</i> .....	21
<i>Finding Your Phone's IP Address</i> .....	22
<i>Phone Status via the Aastra Web UI</i> .....	23
<b>Customizing Your Phone</b> .....	25
<i>Ring Tones and Tone Sets</i> .....	25
<i>Contrast Level</i> .....	28
<i>Backlight</i> .....	29
<i>Live Dialpad*</i> .....	31
<i>Set Audio</i> .....	32
<i>Time and Date</i> .....	34
<i>User Password</i> .....	48

<i>Resetting a User Password</i> .....	49
<i>Restarting Your Phone</i> .....	50
<i>Phone Lock</i> .....	50
<i>Defining an Emergency Dial Plan</i> .....	52
<b>Line Keys, Programmable Keys, and Softkeys</b> .....	53
<i>Multiple Line and Call Appearances</i> .....	53
<i>Softkeys and Programmable Keys</i> .....	54
<i>State-Based Softkeys (Bottom Keys only)</i> .....	56
<i>Line Key</i> .....	59
<i>Speeddial Key</i> .....	61
<i>Editing Speed Dial Keys</i> .....	66
<i>"Do Not Disturb" (DND) Key</i> .....	69
<i>Busy Lamp Field (BLF) Key</i> .....	71
<i>BLF/List Key</i> .....	72
<i>Automatic Call Distribution (ACD) Key (for Sylantró Servers)</i> .....	75
<i>Directed Call Pickup/Group Call Pickup Keys</i> .....	79
<i>XML Key</i> .....	83
<i>Flash Key</i> .....	89
<i>Sprecode Key</i> .....	90
<i>Park/Pickup Keys</i> .....	91
<i>Last Call Return (lcr) Key (Sylantró Servers only)</i> .....	94
<i>Call Forward Key</i> .....	95
<i>BLF/Xfer</i> .....	96
<i>Speeddial/Xfer</i> .....	98
<i>Speeddial/Conf</i> .....	100
<i>Services Key</i> .....	102
<i>Directory Key</i> .....	104
<i>Callers List Key</i> .....	106
<i>Intercom Key</i> .....	108
<i>Phone Lock Key</i> .....	109
<i>Paging Key (Sends the RTP Stream)</i> .....	110
<i>None Key</i> .....	113
<i>Empty Key</i> .....	114
<i>Deleting a Key</i> .....	115

<b>Making Calls</b> .....	116
<i>Dialing a Number</i> .....	116
<i>Pre-dialing a Number</i> .....	116
<i>Using Handsfree Speakerphone</i> .....	116
<i>Using a Headset</i> .....	117
<i>Using Intercom</i> .....	118
<i>Redial</i> .....	119
<i>Mute</i> .....	120
<b>Receiving Calls</b> .....	121
<i>Answering an Incoming Call</i> .....	121
<i>Sending an Incoming Call to Voicemail</i> .....	121
<b>Handling Calls</b> .....	122
<i>Placing a Call on Hold</i> .....	122
<i>Transferring Calls</i> .....	123
<i>Conferencing Calls</i> .....	126
<i>Ending Calls</i> .....	132
<b>Managing Calls</b> .....	133
<i>Directory List</i> .....	133
<i>Callers List</i> .....	143
<i>Account Configuration (DND and Call Forwarding)</i> .....	148
<i>Missed Calls Indicator</i> .....	166
<i>Voicemail</i> .....	167
<b>Additional Features</b> .....	168
<i>Star Codes</i> .....	168
<i>Display DTMF Digits</i> .....	169
<i>Play Call Waiting Tone</i> .....	170
<i>Stuttered Dial Tone</i> .....	171
<i>XML Beep Support</i> .....	172
<i>Switch UI Focus to Ringing Line</i> .....	173
<i>Call Hold Reminder During Active Calls</i> .....	174
<i>Call Hold Reminder (on single hold)</i> .....	175
<i>Call Waiting Tone Period</i> .....	176
<i>Preferred Line and Preferred Line Timeout</i> .....	177

<i>Message Waiting Indicator</i> .....	179
<i>Incoming Intercom Call Features</i> .....	180
<i>Using Redial Key for “Last Number Redial”</i> .....	181
<i>Group RTP Paging (receives RTP streams)</i> .....	182
<i>Shared Call Appearance (SCA) Call Bridging</i> .....	183
<b>Available Features Enabled by Administrators</b> .....	186
<i>Outgoing Intercom Calls</i> .....	186
<i>Missed Call Summary Subscription</i> .....	186
<i>Customizable Callers List Key and Services Key</i> .....	186
<i>Autodial (Hotline and Warmline)</i> .....	187
<i>Centralized Conferencing</i> .....	187
<i>Answer and Ignore Softkeys for XML Applications</i> .....	188
<i>XML Softkey for Special Characters in XML Applications</i> .....	188
<i>Playing a WAV File On Your Phone</i> .....	188
<i>Using the Keypad During Active XML Applications</i> .....	189
<i>Key Redirection</i> .....	189
<i>XML Applications and Off-Hook Interaction</i> .....	190
<i>XML Override for a Locked Phone</i> .....	190
<i>RTP Recording and Simultaneous Playing</i> .....	190
<i>“Hold” Feature Enhancement (for Broadsoft Servers)</i> .....	190
<i>Authentication Support for HTTP/HTTPS Download Methods Used with Broadsoft Client Management System (CMS)</i> .....	191
<i>Diverting Calls from Your Phone</i> .....	191
<i>Display of Call Destination Information</i> .....	192
<i>Indication of Terminated Calls</i> .....	193
<b>Model M670i and M675i Expansion Modules</b> .....	195
<i>Using the Expansion Modules</i> .....	197
<b>Troubleshooting Solutions</b> .....	199
<b>Limited Warranty</b> .....	Warranty-1
<i>Exclusions</i> .....	Warranty-1
<i>Warranty Repair Services</i> .....	Warranty-1
<i>After Warranty Service</i> .....	Warranty-1
<b>Limited Warranty (Australia Only)</b> .....	Warranty-2
<i>Repair Notice</i> .....	Warranty-2

*Exclusions* ..... Warranty-2

*Warranty Repair Services* ..... Warranty-3

*After Warranty Service* ..... Warranty-3

**Appendix A - Time Zone Codes** ..... A-1

**Index** ..... Index-1

# Welcome

The Aastra 6735i offers advanced XML capability to access custom applications and is fully interoperable with leading IP-PBX platforms. Featuring a 5-line display, the 6735i supports up to 9 lines with call appearances and allows you to make and receive calls, transfer, conference, and more. The 6735i IP telephone provides communications over an IP Network using the SIP IP telephony protocol.

## About this Guide

This guide explains how to use the basic features of your new 6735i phone. Not all features listed are available by default. Contact your system or network Administrator to find out which features and services are available to you on your system.

Your System Administrator has the ability to customize some features on this phone. For information on more advanced settings and configurations, administrators should refer to the **Aastra Models 9000i and 6700i Series SIP IP Phones Administrator Guide**.

## Documentation

- **Aastra 6735i SIP IP Phone Installation Guide** – Contains installation and set-up instructions, general features and functions, and basic options list customization. This Installation Guide is included in the box with your phone.
- **Aastra 6735i SIP IP Phone User Guide** – Describes the most commonly used features and functions for an end user. This User Guide can be downloaded from [www.aastratelecom.com](http://www.aastratelecom.com).
- **Aastra Models 9000i and 6700i Series SIP IP Phones Administrator Guide** – Describes how to set the 6735i phone up on the network and contains advanced configuration instructions for the 6735i. This Administrator Guide is intended for the System Administrator and can be downloaded from <http://www.aastra.com>.

## Phone Features

- 8 line graphical LCD screen (144 x 75 pixels) with white backlight
- Built-in-two-port, 10/100/1000 Gigabit Ethernet switch - lets you share a connection with your computer
- 12 programmable keys
  - 6 Top keys: Programmable hard keys
  - 6 Bottom keys: Programmable state-based softkeys
- Press-and-hold speed dial key configuration feature
- 4 call appearance lines with LEDs
- Supports up to 9 call lines
- HD audio (wideband)
- Full-duplex speakerphone for handsfree calls
- Headset mode support (via handset jack)
- Inline power support (based on 802.3af standard) which eliminates power adapters
- Enhanced busy lamp fields\*
- Set paging\*

\* Availability of feature dependant on your phone system or service provider

## Requirements

The 6735i IP Phone requires the following environment:


- SIP-based IP PBX system or network installed and running with a SIP account created for the 6735i IP phone.
- Access to a Trivial File Transfer Protocol (TFTP), File Transfer Protocol (FTP), Hypertext Transfer Protocol (HTTP) server, or Hyper Text Transfer Protocol over Secure Sockets Layer (SSL) (HTTPS).
- Ethernet/Fast Ethernet LAN (10/100 Mbps) (Gigabit Ethernet LAN (1000 Mbps) recommended)
- Category 5/5e straight through cabling (category 6 straight through cabling required for optimum Gigabit Ethernet performance)
- Power source
  - For Ethernet networks that supply in-line power to the phone (IEEE 802.3af):
    - For power, use the Ethernet cable (supplied) to connect from the phone directly to the network for power. (No 48v AC power adapter required.)
  - For Ethernet networks that DO NOT supply power to the phone:
    - (optional) For power, use a Power over Ethernet (PoE) power injector or a PoE switch. A PoE power injector is available as an optional accessory from Aastra Telecom. Contact your Administrator for more information.

## Installation and Setup

If your System Administrator has not already setup your 6735i phone, please refer to the **Aastra 6735i Installation Guide** for basic installation and physical setup information. For more advanced administration and configuration information, System Administrators should refer to the **Aastra Models 9000i and 6700i Series SIP IP Phones Administrator Guide**.

# Getting Started


The 6735i must be set up and be configured prior to its first use. This section describes phone behavior and start up screens you may see when the phone is first plugged in, or when it is restarted.



## Plugging in and Starting the Phone

The 6735i automatically begins the start up sequence as soon as it is connected. The phone goes through this process the first time you plug in your phone and every time you restart your phone.

The phone displays the following startup screens.



The 6735i phone then checks settings and looks for new configuration and firmware updates for the phone from a server. If a new update is found, the phone displays the message “**Updating Configuration**”. This may take a few moments while the phone downloads the latest updates.

**Note:**

New updates to your phone can be automatically scheduled from the server. This is set up on the phone system by your System Administrator and should be scheduled during non-business hours or slow call periods.


**Important!**

Do not unplug or remove power to the phone while it is checking or installing firmware and configuration information.

If language packs were loaded to your phone by your System Administrator, the following screen displays during startup.




When the configuration update is complete, the phone displays the following screens and then displays the Idle screen.




### **Network Connected/Network Disconnected**

If your phone is successful when connecting to the network the following screen displays before changing to the Idle screen.



If your phone did not successfully connect to the network, the **"Network Disconnected"** prompt appears on the display and the telephone status light turns on.



Check that the cables are tightly connected to the phone and to the wall jack. The phone should automatically detect when it is reconnected and displays the **"Network Connected"** prompt for a few seconds. However, if changes have been made to your phone's network settings, you may need to restart your phone.

For more information about connecting your phone, see the *Aastra 6735i IP Phone Installation Guide*, the section **"Connecting to the Network and to Power"**.

Check with your system or network Administrator for assistance.

**Note:**

If the phone displays "No Service" you can still use the phone but it is not registered with the Registrar. For more information about registering your phone, see your System Administrator.

## Idle Screen

When the phone has successfully updated the configuration and connected to the network, the phone displays the **Idle State** screen. The idle screen is shown whenever your phone is not in use.




**Note:**

Your System Administrator sets up your SIP screen name, line number, and any other administrative features required. If your name does not display on the screen, contact your System Administrator.

The **Idle State** screen lists your name (SIP screen name) and day, date, and time. In the above screen, the "L1" indicates John Smith is configured on Line 1.

By default, the top programmable keys 1 through 4 are configured for Services, Directory, Callers List, and Intercom, respectively. You can configure the 6 top programmable keys with up to 6 functions, and the 6 bottom softkeys with up to 20 functions as required.



**Reference**

For more information about configuring the top programmable keys and the bottom softkeys, see [“Softkeys and Programmable Keys”](#) on page 54.

For more information about using the Services, Directory, Callers List, Intercom, Dial, Conference, and Transfer keys, see the following sections:


- [“Making Calls”](#) on page 116.
- [“Handling Calls”](#) on page 122.
- [“Managing Calls”](#) on page 133.

**Idle Screen With Softkeys/Programmable Keys Configured**

If you or your Administrator have configured softkey functions on your phone, the labels for those functions display on the screen. Programmable key functions (top keys) do not display on the LCD. For example, in the following illustration, **“Home”** and **“Office”** were configured as speed dial keys on the bottom set of softkeys and **“Do Not Disturb” (DND)** was configured on the top set of programmable keys.


**Note:**

The top programmable key descriptions do not display on the LCD. You can write the function assigned to the programmable key using the label provided for the phone.



### Idle Screen with Voicemail Messages


The envelope icon  displays on the Idle State screen only if you have new messages waiting. The number next to the envelope indicates how many new messages you have.



To access your voicemail messages, use the star codes for your system if a voicemail softkey has not been configured on your phone. For more information on your system's star codes, please refer to the documentation for the voicemail system you are using.

### Screen Display After Picking Up the Handset

When you pickup the handset, the screen displays as follows:




This screen displays the following keys located on the bottom left of the screen:

- Dial
- Conf (Conference)
- Xfer (Transfer)

These keys are static and cannot be changed.

A **More** softkey also displays at the bottom right of the screen if you have configured softkeys.

For example, in the illustration below, the 6735i has several bottom softkeys configured on the idle screen. A **"More"** key displays for you to view additional softkeys on another screen. Also, if you pick up the handset, a **"More"** displays for you to view additional softkeys. You can press the **More** softkey to toggle between the first and second screens to display all configured softkeys.




**Note:**

The bottom set of 6 softkeys map to the current state-based configurable softkeys.

# IP Phone Keys

## Key Panel



The following sections describe the various 6735i phone key functions on both the symbol and text hardware platforms, and how they help you make and manage your calls and caller information. Images of the symbol keys and the symbol hardware platform are used throughout this document.



- |          |                           |           |                                    |
|----------|---------------------------|-----------|------------------------------------|
| <b>1</b> | 6735i Handset             | <b>9</b>  | Four (4) Line Call Appearance Keys |
| <b>2</b> | High Quality Speakerphone | <b>10</b> | Speakerphone/Headset Key           |
| <b>3</b> | Message Waiting Lamp      | <b>11</b> | Mute Key                           |
| <b>4</b> | Goodbye Key               | <b>12</b> | Navigation Keys                    |
| <b>5</b> | Options Key               | <b>13</b> | Keypad                             |
| <b>6</b> | Hold Key                  | <b>14</b> | LCD Screen                         |
| <b>7</b> | Redial Key                | <b>15</b> | Volume Control (+) (-)             |
| <b>8</b> | Softkeys                  |           |                                    |

## Key Descriptions

The following table identifies the keys on the key panel of your 6735i IP phone that you can use for handling calls.

Text Keys	Symbol Keys	Key Description
		<b>Goodbye key</b> - Ends an active call. The Goodbye key also exits an open list, such as the Options List, without saving changes.
		<b>Options key</b> - Accesses options to customize your phone. Your System Administrator may have already customized some of your settings. Check with your System Administrator before changing the Administrator-only options.
		<b>Hold key</b> - Places an active call on hold. To retrieve a held call, press the call appearance button beside the light that is flashing.
		<b>Redial key</b> - Redials up to 100 previously dialed numbers. Pressing the Redial key twice simultaneously redials the last dialed number.
		<b>Volume control key</b> - Adjusts the volume for the handset, headset, ringer, and handsfree speaker.
   	   	<b>Line/Call Appearance key</b> - Connects you to a line or call. The Aastra 6735i IP phone supports up to 4 line keys.
		<b>Handsfree key</b> - Activates Handsfree for making and receiving calls without lifting the handset. When the audio mode option is set, this key is used to switch between a headset and the handsfree speakerphone.
		<b>Mute key</b> - Mutes the microphone so that your caller cannot hear you (the light indicator flashes when the microphone is on mute).
		<p><b>Navigation Keys</b> - Pressing the UP and DOWN arrow keys lets you view different status and text messages on the LCD display (if there is more than 1 line of status/text messages). These keys also let you scroll through menu selections, such as the Options List, and scroll through a remote number that is displayed on the phone. Users can press the scrolling DOWN navigation key to view the rest of the phone number content.</p> <p>Pressing the LEFT and RIGHT arrow keys lets you view the different line/call appearances. While in the Options List, these keys allow you to exit or enter the current option. When you are editing entries on the display, pressing the LEFT arrow key erases the character on the left; pressing the RIGHT arrow key sets the option.</p>

Text Keys	Symbol Keys	Key Description
		<p><b>Programmable keys</b> - 6 Top keys: programmable hard keys (up to 6 programmable functions)</p> <p>By default, keys 1 through 4 are assigned as Services, Directory, Callers List, and Intercom, respectively. Keys 5 and 6 have no assigned functions. All 6 keys are programmable and can be assigned to perform specific functions.</p> <p>The following are the default functions for the programmable keys on the 6735i IP phone:</p> <p><b>1 SERVICES</b> Accesses enhanced features and services such as ML applications and voicemail, provided by third parties.</p> <p><b>2 DIRECTORY</b> Accesses the Directory List which displays up to 200 names and phone numbers (stored in alphabetical order)</p> <p><b>3 CALLERS LIST</b> Accesses the Callers List which lists the last 200 calls received.</p> <p><b>4 INTERCOM</b> Automatically connects with a remote extension for outgoing calls, and answers incoming intercom calls.</p> <p><b>5 NONE</b> No assigned function</p> <p><b>6 NONE</b> No assigned function</p> <p>The following softkeys display when you pick up the handset:</p> <p><b>DIAL</b>- After entering a phone number from the keypad, you can press the Dial softkey to immediately dial the number.</p> <p><b>CONF</b> - Begins a conference with the active call.</p> <p><b>XFER</b> - Transfers the active call to another number.</p> <p>For more information about programming the programmable keys to perform specific functions, see the "<a href="#">Softkeys and Programmable Keys</a>" on <a href="#">page 54</a>.</p>
		<p><b>Softkeys</b> - 6 Bottom keys: programmable state-based softkeys (up to 20 programmable functions).</p> <p>For more information about programming the softkeys to perform specific functions, see the "<a href="#">Softkeys and Programmable Keys</a>" on <a href="#">page 54</a>.</p>

## Keypad Keys

The 6735i has a keypad with digits from 0 through 9, a "\*" key, and a "#" key. Keys 2 through 9 contain the letters of the alphabet. The 6735i phone keypad includes the following:

Keypad Key	Description
0	Dials 0 Dials the Operator on a registered phone
1	Dials 1
2 ABC	Dials 2 When entering text, this key enters <b>A</b> with one press, <b>B</b> with two presses, and <b>C</b> with three presses
3 DEF	Dials 3 When entering text, this key enters <b>D</b> with one press, <b>E</b> with two presses, and <b>F</b> with three presses
4 GHI	Dials 4 When entering text, this key enters <b>G</b> with one press, <b>H</b> with two presses, and <b>I</b> with three presses
5 JKL	Dials 5 When entering text, this key enters <b>J</b> with one press, <b>K</b> with two presses, and <b>L</b> with three presses
6 MNO	Dials 6 When entering text, this key enters <b>M</b> with one press, <b>N</b> with two presses, and <b>O</b> with three presses
7 P QRS	Dials 7 When entering text, this key enters <b>P</b> with one press, <b>Q</b> with two presses, <b>R</b> with three presses, and <b>S</b> with four presses.
8 TUV	Dials 8 When entering text, this key enters <b>T</b> with one press, <b>U</b> with two presses, and <b>V</b> with three presses
9 WXYZ	Dials 9 When entering text, this key enters <b>W</b> with one press, <b>X</b> with two presses, <b>Y</b> with three presses, and <b>Z</b> with four presses.

The "\*" is called the "star key". The "#" is called the "number sign", "pound key", or "hash key", depending on one's nationality or personal preference. These can be used for special functions such as accessing voicemail. The "star key" and "pound key" functions are dependant on your country's feature availabilities. Contact your System Administrator for more information about available functions using these keys.

These keypad keys can be used for any of the following on the phone:

- Dial a phone number to make a call (see ["Dialing a Number"](#) on [page 116](#).)
- Enter digits or letters in the IP Phone user interface.
- Program a speed dial number (see ["Speeddial Key"](#) on [page 61](#).)
- Press a speed dial key (see ["Speeddial Key"](#) on [page 61](#).)
- Press the keys associated with a called Interactive Voice Response (IVR) system.

# Methods for Customizing Your Phone

There are two ways to customize specific options on your phone:

- Using the Options  key on the IP Phone
- Using the Aastra Web UI in an Internet browser window from your PC.

## Phone Options via the IP Phone UI

You can customize your phone by pressing the Options  key and accessing the IP Phone UI.

These options allow you to customize the following phone settings.

Option Number	Option
1	Call Forward 1. All 2. Busy 3. No Answer The menus that display for Call Forward are dependant on the Call Forward Mode set on the phone. Default is "Account" mode.
2	Preferences 1. Tones Ring Tone Tone Set 2. Display Contrast Level Backlight 3. Speed Dial Edit 4. Live Dialpad 5. Set Audio Audio Mode Headset Mic Vol DHSG 6. Time and Date Time Format Daylight Savings Date Format Time Zone Time Server 1 Time Server 2 Time Server 3 Set Time Set Date 7. Language Screen Language Input Language
3	Phone Status 1. IP&MAC Addresses 2. LAN Port 3. PC Port 4. Firmware Info 5. Error Messages 6. Copyright
4	User Password
5	Administrator Menu (Password Protected)

Option Number	Option
6	Restart Phone
7	Phone Lock

**Note:**

\*The "**Administrator Menu**" options are Administrator level functions only, and are not accessible by the user. These options should only be set up and changed by your System Administrator.

**Simplified Options Menu**

Your System Administrator may configure a simplified options menu for your phone. The following table indicates the options that may appear on your phone if the simplified options menu is applied.

Option Number	Option
1	Call Forward 1. All 2. Busy 3. No Answer The menus that display for Call Forward are dependant on the Call Forward Mode set on the phone. Default is "Account" mode.
2	Preferences 1. Tones Ring Tone Tone Set 2. Display Contrast Level Backlight 3. Set Audio Audio Mode Headset Mic Vol DHSG
3	Phone Status 1. IP&MAC Addresses 2. LAN Port 3. PC Port 4. Firmware Info 5. Error Messages 6. Restart Phone 7. Factory Default 8. Erase Local Cfg. 9. Copyright
4	Phone Lock

## Using the IP Phone UI



### IP Phone UI

1. Press the Options key  on the phone to enter the Options List.
2. To go to an **Option**, use ▲ and ▼ to scroll through the list, or press the number corresponding to the **Option**.
3. Press the **Select** softkey, the ► button, or press the digit number of the corresponding option to select an option.
4. Use the softkeys that display for each option to change a selected option.
5. Press the **Done** button to save the change.
6. Press the  button, the ◀ button, or the  button at any time to exit without saving changes.

### References

For more information about customizing your phone using the available options from the IP Phone UI, see the section “Customizing Your Phone” on [page 25](#).

For more information about Administrator options, contact your System Administrator.

## Phone Options via the Aastra Web UI

In addition to the IP Phone UI options, you can customize additional options on the IP Phone using the Aastra Web UI. In order to access your phone using the Aastra Web UI, you need to know your phone's IP address. To find your phone's IP address, see ["Finding Your Phone's IP Address"](#) on page 22.

### Using the Aastra Web UI



1. Open your web browser, enter the phone's IP address or host name into the address field and press **<Enter>**. The following logon screen displays.



2. At the prompt, enter your username and password and click **OK**.

**Note:**  
For a user, the default username is **"user"** and the password field is left blank.

The Status window displays for the IP phone you are accessing.

The screenshot shows the Aastra 6735i web interface. The top header includes the Aastra logo and the model number 6735i, with a Log Off button. A left-hand navigation menu lists various settings categories. The main content area is titled 'System Information' and is divided into three sections: Network Status, Hardware Information, and Firmware Information. Each section contains a table of attributes and their values.

Network Status		
Attribute	LAN Port	PC Port
Link State	Up	Down
Negotiation	Auto	Auto
Speed	100Mbps	10Mbps
Duplex	Full	Half

Hardware Information	
Attribute	Value
MAC Address:	00-08-5D-16-10-DC
Platform	6735i

Firmware Information	
Attribute	Value
Firmware Version	3.2.2.7047
Firmware Release Code	SIP
Boot Version	Boot2 1.0.0.0
Date/Time	Sep 6 2012 01:39:58

SIP Status			
Line	SIP Account	Status	Backup Registrar Used?

3. You can logout of the Aastra Web UI at any time by clicking **Log Off**.

The following categories display in the side menu of the Aastra Web UI: **Status, Operation, Basic Settings.**

Headings	Descriptions																										
Status	The <b>Status</b> section displays the network status and the MAC address of the IP phone. It also displays hardware and firmware information about the IP phone, and information about the SIP account(s) currently configured on the phone. The information in the Status window is read-only.																										
Operation	<p><b>User Password</b> - Allows you to change user password.</p> <p><b>Phone Lock</b> - Allows you to assign an emergency dial plan to the phone, lock the phone to prevent any changes to the phone and to prevent use of the phone, and reset the user password.</p> <p><b>Softkeys and XML</b> - Allows you to configure up to 6 bottom softkeys with functions identified in the list below.</p> <p><b>Programmable Keys</b> - Allows you to configure up to 6 top programmable keys. By default, Keys 1 through 4 are programmed as Services, Directory, Callers List, and Intercom, respectively. You can configure any of the six keys with the functions identified in the list below.</p> <p><b>Available Functions for Softkeys and Programmable Keys</b></p> <table border="1"> <tbody> <tr> <td>None</td> <td>Last Call Return (lcr)</td> </tr> <tr> <td>Line</td> <td>Call Forward</td> </tr> <tr> <td>Speed Dial</td> <td>BLF/Xfer</td> </tr> <tr> <td>Do Not Disturb (DND)</td> <td>Speeddial/Xfer</td> </tr> <tr> <td>Busy Lamp Field (BLF)</td> <td>Speeddial/Conf</td> </tr> <tr> <td>BLF List</td> <td>Directory</td> </tr> <tr> <td>Auto Call Distribution (ACD)</td> <td>Callers List</td> </tr> <tr> <td>Directed Call Pickup</td> <td>Icom (Intercom)</td> </tr> <tr> <td>Extensible Markup Language (XML)</td> <td>Services</td> </tr> <tr> <td>Flash</td> <td>Phone Lock</td> </tr> <tr> <td>Sprecode</td> <td>Paging</td> </tr> <tr> <td>Park</td> <td>Empty</td> </tr> <tr> <td>Pickup</td> <td></td> </tr> </tbody> </table> <p><b>Keypad Speed Dial</b> - Allows you to assign a speed dial number to a specific digit on the phone's keypad for speed dialing purposes.</p> <p><b>Expansion Module</b> - Allows you to configure an additional 36 softkeys with a M670i Expansion Module, or an additional 60 softkeys with a M675i Expansion Module if it is attached to the phone. This option displays on the side menu of the Aastra Web UI only if an Expansion Module is attached. Not all functions in the table above apply to the Expansion Modules.</p> <p><b>Directory</b> - Allows you to copy the Callers List and Directory List from your IP phone to your PC.</p> <p><b>Reset</b> - Allows you to restart the IP phone when required.</p>	None	Last Call Return (lcr)	Line	Call Forward	Speed Dial	BLF/Xfer	Do Not Disturb (DND)	Speeddial/Xfer	Busy Lamp Field (BLF)	Speeddial/Conf	BLF List	Directory	Auto Call Distribution (ACD)	Callers List	Directed Call Pickup	Icom (Intercom)	Extensible Markup Language (XML)	Services	Flash	Phone Lock	Sprecode	Paging	Park	Empty	Pickup	
None	Last Call Return (lcr)																										
Line	Call Forward																										
Speed Dial	BLF/Xfer																										
Do Not Disturb (DND)	Speeddial/Xfer																										
Busy Lamp Field (BLF)	Speeddial/Conf																										
BLF List	Directory																										
Auto Call Distribution (ACD)	Callers List																										
Directed Call Pickup	Icom (Intercom)																										
Extensible Markup Language (XML)	Services																										
Flash	Phone Lock																										
Sprecode	Paging																										
Park	Empty																										
Pickup																											

Headings	Descriptions
Basic Settings	<p data-bbox="293 207 802 228"><b>Preferences</b> - Allows you to enable/disable the following:</p> <ul data-bbox="293 233 659 625" style="list-style-type: none"><li data-bbox="293 233 391 254">• Park Call</li><li data-bbox="293 258 483 279">• Pick Up Parked Call</li><li data-bbox="293 283 493 304">• Display DTMF Digits</li><li data-bbox="293 308 509 329">• Play Call Waiting Tone</li><li data-bbox="293 333 493 354">• Stuttered Dial Tone</li><li data-bbox="293 359 483 380">• XML Beep Support</li><li data-bbox="293 384 591 405">• Switch UI Focus to Ringing Line</li><li data-bbox="293 409 659 430">• Call Hold Reminder During Active Calls</li><li data-bbox="293 434 483 455">• Call Hold Reminder</li><li data-bbox="293 459 532 480">• Call Waiting Tone Period</li><li data-bbox="293 485 440 506">• Preferred Line</li><li data-bbox="293 510 607 531">• Preferred Line Timeout (seconds)</li><li data-bbox="293 535 591 556">• Message Waiting Indicator Line</li><li data-bbox="293 560 451 581">• DND Key Mode</li><li data-bbox="293 585 521 606">• Call Forward Key Mode</li></ul> <p data-bbox="293 657 667 678">This category also allows you to configure:</p> <ul data-bbox="293 682 646 814" style="list-style-type: none"><li data-bbox="293 682 597 703">• Incoming Intercom Call Settings</li><li data-bbox="293 707 553 728">• Group Paging RTP Settings</li><li data-bbox="293 732 646 753">• Ring Tones (global and per-line basis)</li><li data-bbox="293 758 521 779">• Time and Date Settings</li><li data-bbox="293 783 483 804">• Language Settings</li></ul> <p data-bbox="293 842 1248 888"><b>Account Configuration</b> - Allows you to configure “Do Not Disturb” (DND) and “Call Forwarding” (CFWD) by account. You can have multiple accounts on the 6735i.</p>

# Phone Status

You can view the status of your phone using the IP Phone UI or the Aastra Web UI.

## Phone Status via IP Phone UI

The "**Phone Status**" option on the IP phone displays the status of your phone to the LCD display.

This option allows you to view your phone's:

- Network status including your phone's IP and MAC address
- Local Area Network (LAN) port information
- PC Port information (if PC link exists)
- Firmware version
- Error messages from the last reboot or startup
- Copyright information

Use the following procedure to view the status of your phone using the IP Phone UI.



### IP Phone UI

1. Press  on the phone to enter the Options List.
2. Select **Phone Status**.
3. Select the option you want to view:
  - IP&MAC Address
  - LAN Port
  - PC Port
  - Firmware Info
  - Error Messages
  - Copyright


The option you select displays to the LCD. Use the ▲ and ▼ keys to scroll the through the LCD display.

## Finding Your Phone's IP Address


If you want to access your phone's options using an Internet browser, you need to enter the IP address of the phone in the browser to open the Aastra Web UI. Use the following procedure to find your phone's IP address.

### IP Phone UI


1. Press  to enter the Options List.
2. Scroll to **Phone Status** and press **Select**.



3. Scroll to **IP&MAC Addresses** and press **Select**.



The IP address of your 6735i IP phone displays in the "**IP Address**" field.



## Phone Status via the Aastra Web UI

Use the following procedure to view the phone status via the Aastra Web UI.



1. Open your web browser, enter the phone's IP address or host name into the address field and press **<Enter>**.
2. In the Username/Password window, enter your username and password and click **OK**.

### Note:

For a user, the default username is **"user"** and the password field is left blank.

The Status window displays for the IP phone you are accessing.

**AASTRA** 6735i Log Off

**Status**

- System Information
- Operation
  - User Password
  - Phone Lock
  - Softkeys and XML
  - Programmable Keys
  - Keypad Speed Dial
  - Directory
  - Reset
- Basic Settings
  - Preferences
  - Account Configuration

**System Information**

**Network Status**

Attribute	LAN Port	PC Port
Link State	Up	Down
Negotiation	Auto	Auto
Speed	100Mbps	10Mbps
Duplex	Full	Half

**Hardware Information**

Attribute	Value
MAC Address:	00-08-5D-16-10-DC
Platform	6735i

**Firmware Information**

Attribute	Value
Firmware Version	3.2.2.7047
Firmware Release Code	SIP
Boot Version	Boot2 1.0.0.0
Date/Time	Sep 6 2012 01:39:58

**SIP Status**

Line	SIP Account	Status	Backup Registrar Used?
1	650@proxy.com:5060	Registered	Yes
2	651@proxy.com:5060	Registered	Yes
3	652@proxy.com:5060	Registered	Yes
4	653@proxy.com:5060	401	No

This Status window is view only. It displays the status of your phone which includes the following:

- Network Status
- Hardware Information
- Firmware Information
- SIP Status

### SIP Account Status

The IP Phones show the SIP registration status on the IP Phone's Status screen in the Aastra Web UI.

SIP Status			
Line	SIP Account	Status	Backup Registrar Used?
1	650@proxy.com:5060	Registered	Yes
2	651@proxy.com:5060	Registered	Yes
3	652@proxy.com:5060	Registered	Yes
4	653@proxy.com:5060	401	No

The following table describes the status conditions that can display for the account.

Status Condition	Description								
Registered	<p>Displays this status on accounts that HAVE been registered with the SIP proxy server.</p> <p><b>Example:</b></p> <table border="1"> <thead> <tr> <th>Line</th> <th>SIP Account</th> <th>Status</th> <th>Backup Registrar Used?</th> </tr> </thead> <tbody> <tr> <td>1</td> <td>650@proxy.com:5060</td> <td>Registered</td> <td>Yes</td> </tr> </tbody> </table> <p><b>where</b>  Account Number is "1"  SIP Account is "650@proxy.com" on port "5060"  Status is "Registered"  Backup registrar is used ("Yes")</p>	Line	SIP Account	Status	Backup Registrar Used?	1	650@proxy.com:5060	Registered	Yes
Line	SIP Account	Status	Backup Registrar Used?						
1	650@proxy.com:5060	Registered	Yes						
SIP Error Number	<p>Displays on accounts when registration fails with the SIP proxy server.</p> <p><b>Example:</b></p> <table border="1"> <thead> <tr> <th>Line</th> <th>SIP Account</th> <th>Status</th> <th>Backup Registrar Used?</th> </tr> </thead> <tbody> <tr> <td>4</td> <td>653@proxy.com:5060</td> <td>401</td> <td>No</td> </tr> </tbody> </table> <p><b>where</b>  Account Number is "4"  SIP Account is "653@proxy.com" on port "5060"  Status is "401" - Unregistered if SIP registration fails.  Backup registrar is used ("No")</p>	Line	SIP Account	Status	Backup Registrar Used?	4	653@proxy.com:5060	401	No
Line	SIP Account	Status	Backup Registrar Used?						
4	653@proxy.com:5060	401	No						

# Customizing Your Phone

The following paragraphs describe the options available from either the IP Phone UI, the Aastra Web UI, or both, and provide procedures applicable to the option.

## Ring Tones and Tone Sets

You can configure ring tones and ring tone sets on the IP phone.

### Ring Tones

There are several distinct ring tones a user can select from to set on the IP phones. You can enable/disable these ring tones on a global or per-line basis.

The following table identifies the valid settings and default values for each type of configuration method.

**Ring Tones Table**

Configuration Method	Valid Values	Default Value
IP Phone UI	Global Tone 1 Tone 2 Tone 3 Tone 4 Tone 5 Silent	Global Setting: Tone 1
Aastra Web UI	Global: Tone 1 Tone 2 Tone 3 Tone 4 Tone 5 Silent	Global Setting: Tone 1
Lines 1 to 9	Per-Line Setting: Global Tone 1 Tone 2 Tone 3 Tone 4 Tone 5 Silent	Per-Line Setting: Global

## Ring Tone Sets

In addition to ring tones, you can configure ring tone sets on a global-basis on the IP phone. Ring tone sets consist of tones customized for a specific country. The ring tone sets you can configure on the IP phones are:

- Australia
- Brazil
- Europe (generic tones)
- France
- Germany
- Italy
- Italy2
- Malaysia
- Mexico
- Russia
- Slovakia
- UK
- US (Default - also used in Canada)

When you configure the country's tone set, the country-specific tone is heard on the phone for the following:

- dial tone
- secondary dial tone
- ring tone
- busy tone
- congestion tones
- call waiting tone
- ring cadence pattern

You configure global ring tones and tone sets using the Aastra Web UI and the IP Phone UI.

## Configuring Ring Tones and Tone Sets



### IP Phone UI

Use the following procedures to configure ring tones and tone sets on the IP phone.

### Global configuration only

1. Press  on the phone to enter the Options List.
2. Select **Preferences**.
3. Select **Tones**.
4. Select **Ring Tone**.
5. Select the type of ring tone (**Tone 1** through **Tone 5**, or **Silent**).
6. Press **Done**.
7. Select **Tone Set**.

8. Select the country for which you want to apply the tone set.  
Valid values are **Australia, Brazil, Europe, France, Germany, Italy, Italy2, Malaysia, Mexico, Brazil, Russia, Slovakia, UK, and US**. Default is **US**.
9. Press **Done**.  
The ring tone and tone set you select is immediately applied to the IP phone.



1. Click on **Basic Settings->Preferences->Ring Tones**.

Ring Tones	
Tone Set	US
Global Ring Tone	Tone 1
Line 1	Global
Line 2	Global
Line 3	Global
Line 4	Global
Line 5	Global
Line 6	Global
Line 7	Global
Line 8	Global
Line 9	Global

### *For global configuration:*

2. In the "**Ring Tones**" section, select a country from the "**Tone Set**" field.  
Valid values are **Australia, Brazil, Europe, France, Germany, Italy, Italy2, Malaysia, Mexico, Brazil, Russia, Slovakia, UK, and US**. Default is **US**.
3. Select a value from the "**Global Ring Tone**" field.  
**Note:**  
See the [Ring Tones Table](#) on page 25 for valid values.

### *For per-line configuration:*

4. In the "**Ring Tone**" section, select a line for which you want to set ring tone.
5. Select a value from the "**LineN**" field.  
**Note:**  
See the [Ring Tones Table](#) on page 25 for valid values.
6. Click Save Settings.

## Contrast Level


The "**Contrast Level**" option on the IP phone allows you to set the amount of light that illuminates the LCD display. Use this option to set the preference of contrast level.

You can set the contrast level using the IP Phone UI only.


### Setting Contrast Level



1. Press  on the phone to enter the Options List.
2. Select **Preferences**.
3. Select **Display**.
4. Select **Contrast Level**.



5. Use the ◀ and ▶ navigation buttons to increase or decrease the intensity of contrast lighting on the LCD.



6. Press **Done** to save your selection.

## Backlight

The "**Backlight**" option on the IP phone allows you to set the backlight status on the LCD display to the following:


- **Off** - Backlight is always OFF.
- **Auto** (Default)- Automatically turns ON the backlight when the phone is in use, and then automatically turns OFF the backlight when the phone is idle after a specified length of time.

Auto backlighting sets the phone to turn off the backlighting after a period of inactivity; the idle period is user definable under the Advanced softkey when you select the Auto mode. In Auto mode, the backlight turns on with a key press or state change on the phone.


### Setting the Backlight




1. Press  on the phone to enter the Options List.
2. Select **Preferences**.
3. Select **Display**.
4. Select **Backlight**.




5. Use the ▲ and ▼ navigation buttons to select the Backlight status for your phone. Default is "**Auto**". Available options are:
  - Off
  - **Auto** (Default)
6. If you selected "**Off**", press **Done** to save your setting.



7. If you selected **"Auto"**, press the **Advanced** softkey.



8. Using the keypad, enter the amount of seconds you want the phone to stay backlit when the phone is idle. Valid values are **1 to 120** seconds (2 minutes). Default is **10 seconds**. When this period of time is reached, the phone turns OFF the backlight. Use the **"Backspace"** and/or **"Clear"** softkeys to delete entries if required.



9. Press **Enter** to save your setting.

## Live Dialpad\*

The "**Live Dialpad**" option on the IP phone turns the Live Dial Pad mode ON or OFF. With live dial pad ON, the 6735i IP phone automatically dials out and turns ON Handsfree mode as soon as a dial pad key or softkey is pressed. With live dial pad OFF, if you dial a number while the phone is on-hook, lifting the receiver or pressing the  initiates a call to that number.


\*Availability of feature dependant on your phone system or service provider.

You can enable/disable the live dialpad using the IP Phone UI only.

### Enabling/Disabling Live Dialpad



1. Press  on the phone to enter the Options List.
2. Select **Preferences**.
3. Select **Live Dialpad**.



4. Use the navigation keys to turn the live dialpad ON or OFF.
5. Press **Done** to save your setting.

## Set Audio

The "**Set Audio**" option on the IP Phone allows you to set the audio mode for your IP phone. It also allows you to set the volume level of the headset microphone and enable/disable DHSG.

You can set Audio on your IP phone using the IP Phone UI only.

### Audio Mode

The 6735i allows you to use a handset, a headset, or handsfree mode to handle incoming and outgoing calls. The audio mode option provides different combinations of these three methods to provide maximum flexibility in handling calls. There are four audio mode options you can set:

Audio Mode Option	Description
Speaker	This is the default setting. Calls can be made or received using the handset or handsfree speakerphone. In handset audio mode, pressing the  button on the phone switches to handsfree speakerphone. In Speaker audio mode, lift the handset to switch to the handset.
Headset	Choose this setting if you want to make or receive all calls using a headset or headset. Calls can be switched from the handset to headset by pressing the  button on the phone. To switch from the headset to the handset, lift the handset.
Speaker/Headset	Incoming calls are sent to the handsfree speakerphone first when the  button is pressed. By pressing the button again, you can switch back and forth between the handsfree speakerphone and the headset. At anytime, lifting the handset switches back to the handset from either the handsfree speakerphone or the headset.
Headset/Speaker	Incoming calls are sent to the headset first when the  button is pressed. By pressing the button again, you can switch back and forth between the headset and the handsfree speakerphone. At anytime, lifting the handset switches back to the handset from either the headset or the handsfree speakerphone.

### Headset Mic Volume

The "**Headset Mic Volume**" option allows you to set the volume level for the headset microphone.

### DHSG

The "DHSG" option allows you to enable or disable DHSG headset support.

#### Note:

A DHSG headset and an expansion module cannot be used concurrently as they both share the same headset port.


### Setting Audio Mode, Headset Mic Volume, and DHSG



#### IP Phone UI


1. Press  on the phone to enter the Options List.
2. Select **Preferences**.
3. Select **Set Audio**.

4. Select **Audio Mode**.




5. Select the audio mode you want to use on your phone. Default is **Speaker**.  
Valid values are:

- **Speaker** (Default)
- **Headset**
- **Speaker/Headset**
- **Headset/Speaker**




6. Press **Done** to save your setting.


7. Select **Headset Mic Volume**.




8. Select the **Low**, **Medium**, or **High** volume level. Default is **Medium**.



9. Select **DHSG**.



10. Select the **DHSG is OFF** or **DHSG is ON** option. Default is **DHSG is OFF**.



11. Press **Done** to save your selection.

## Time and Date

On the IP phones, you can configure the following:

- Time and date
- Time and date format
- Time zone
- Daylight savings time
- Time Servers

**Note:**

Only the Time and Date Formats and Time Servers can be set using the Aastra Web UI

### Configuring Time and Date

Use the following procedures to configure the time and date settings on the IP phone.



#### Set Time and Time Format


**Note:**

The time and time format you configure display on the phone's idle screen.


1. Press  on the phone to enter the Options List.
2. Select **Preferences**.

3. Select **Time and Date**.

4. Select **Set Time**.




5. Using the keys on the keypad, enter a time to set on the IP phone. Use the "**Backspace**" key to move back a space and delete a character. Use the "**AM/PM**" softkey to specify either AM or PM for the time setting.



6. Press **Enter** to save the setting.

7. Select **Time Format**.

8. Using the navigation keys, set the Time Format to either a 12 hour format or a 24 hour format. Valid values are **12 Hour** and **24 Hour**. Default is **12Hour**.




9. Press **Done** to save the Time Format you selected.

## Set Date and Date Format


**Note:**

The date and date format you configure display on the phone's idle screen.

1. Select **Preferences**.
2. Select **Time and Date**.
3. Select **Set Date**.



4. Using the keys on the keypad, enter a date to set on the IP phone. Use the "**Backspace**" key to move back a space and delete a character.



5. Press **Enter** to save the setting.
6. Select **Date Format**.

7. Select a date format from the list of options. Default is **WWW MMM DD**. Valid values are:

- WWW MMM DD (default)
- DD-MMM-YY
- YYYY-MM-DD
- DD/MM/YYYY
- DD/MM/YY
- DD-MM-YY
- MM/DD/YY
- MMM DD
- DD MMM YYYY
- WWW DD MMM
- DD MMM
- DD.MM.YYYY

Date Format


- WWW MMM DD
- DD-MMM-YY
- YYYY-MM-DD
- DD/MM/YYYY
- DD/MM/YY
- DD-MM-YY
- MM/DD/YY
- MMM DD
- DD MMM YYYY
- WWW DD MMM
- DD MMM
- DD.MM.YYYY

Cancel -  
Done -

8. Press **Done** to save the Date Format.


**Set Time Zone**

1. Select **Preferences**.
2. Select **Time and Date**.
3. Select **Time Zone**.



A list of Time Zones display for different areas of the world.

4. Select a Time Zone that applies to your area.  
The default Time Zone is **US-Eastern**.




**Note:**

For a list of the Time Zones values available on the IP Phone, see ["Appendix A - Time Zone Codes."](#)

5. Press **Done** to save the Time Zone setting.

**Daylight Savings Time**


1. Select **Preferences**.
2. Select **Time and Date**.
3. Select **Daylight Savings**.



4. Select a Daylight Savings time from the list of options.

Default is **Automatic**. Valid values are:

- OFF
- 30 min summertime
- 1h summertime
- **Automatic** (Default)




5. Press **Done** to save the Daylight Savings value you selected.

### Set Time Servers


With a valid time server enabled your IP phone will synchronize the time displayed with the specified configuration server. The phone will use the time from Time Server 1 unless it is not configured or unavailable, in which case it will move on to Time Server 2, and if necessary Time Server 3.

1. Select **Preferences**.
2. Select **Time and Date**.
3. Select **Time Server 1, Time Server 2, or Time Server 3**.



4. Using the keys on the keypad, enter an IP address or domain name for the time server.

Use the "**Backspace**" key to move back a space and delete a character. Use the "**Dot**" softkey to enter dots within the IP address or domain name. Use the "**ABC**" softkey to toggle between entering numbers and entering letters.



5. Press **Enter** to save the time server setting.



1. Click on **Basic Settings->Preferences->Time and Date Setting**.

Time and Date Setting	
Time Format	12h
Date Format	WWW MMM DD
NTP Time Servers	<input checked="" type="checkbox"/> Enabled
Time Server 1	0.0.0.0
Time Server 2	0.0.0.0
Time Server 3	0.0.0.0

2. In the **"Time Format"** field, select the time format you want to use on your phone. Valid values are:
  - **12h** (12 hour format) (default)
  - **24h** (24 hour format)

**Note:**

The time and time format you configure display on the phone's idle screen.

3. In the **"Date Format"** field, select the date format you want to use on your phone. Default is **WWW MMM DD**.

Valid values are:

- WWW MMM DD (default)
- DD-MMM-YY
- YYYY-MM-DD
- DD/MM/YYYY
- DD/MM/YY
- DD-MM-YY
- MM/DD/YY
- MMM DD
- DD MMM YYYY
- WWW DD MMM
- DD MMM
- DD.MM.YYYY

**Note:**

The date and date format you configure display on the phone's idle screen.

4. In the **"NTP Time Servers"** field, enable by checking the checkbox or disable by unchecking the box (default is enabled).
5. In the **"Time Server 1"**, **"Time Server 2"**, and **"Time Server 3"** fields, enter IP addresses or qualified domain names for the primary, secondary, and tertiary time servers.

**Note:**

Time Servers can only be entered if NTP Time Servers is enabled.

6. Click **Save Settings**.

## Language

The IP phones support several different languages. You can have the IP Phone UI and the Aastra Web UI display in a specific language as required. When you set the language to use, all of the display screens (menus, services, options, configuration parameters, etc.) display in that language. The IP phones support the following languages:

- English
- Czech
- Catalan
- Valencian
- Welsh
- German
- Danish
- Spanish
- Mexican Spanish
- Finnish
- French
- Canadian French
- Italian
- Dutch
- Dutch (Netherlands)
- Norwegian
- Polish
- Portuguese
- Portuguese Brazilian
- Russian
- Slovak
- Swedish
- Turkish

You can also configure the language to use when inputting values in the Aastra Web UI and the IP Phone UI.

### *Specifying the Language to Use*

Once the language pack(s) are available on your phone from your System Administrator, you can specify which language to use on the phone and/or the Aastra Web UI.

**Note:**

All languages may not be available for selection. The available languages are dependant on the language packs currently loaded to the IP phone.



#### **IP Phone UI**

Use the following procedure to specify which language to use for the IP Phone UI.

1. Press  on the phone to enter the Options List.
2. Select **Preferences**.
3. Select **Language**.

**4. Select Screen Language.**

The current language setting displays on the IP Phone.

**5. To change the language setting, use the ▲ and ▼ keys to scroll through the languages.****Note:**

All languages may not be available for selection. The available languages are dependant on the language packs currently loaded to the IP phone. English is the default language and cannot be changed or removed. For more information about loading language packs, see your System Administrator.

**6. Press Done to set the language on the phone.**

The change is dynamic. When you exit the Options Menu, the phone displays all menu items in the language you selected.

**Aastra Web UI****Note:**

You must have the language pack(s) already loaded to your phone in order to use them. For more information about loading language packs, see your System Administrator.

**1. Click on Basic Settings->Preferences->Language Settings.****2. In the "Webpage Language" field, select a language to apply to the Aastra Web UI.****Note:**

All languages may not be available for selection. The available languages are dependant on the language packs currently loaded to the IP phone by your System Administrator. English is the default language and cannot be changed or removed.

**3. Click Save Settings. The change is dynamic. The Aastra Web UI displays all screens in the language you selected.****Language Input**

The 6735i supports text and character inputs in various languages (English, German, French, Spanish, Italian, Portuguese, Russian, and Nordic). Inputting textual or character information into the IP Phone UI can be done using the keypad on the phone. You enable the Language Input feature using the Aastra Web UI or the IP Phone UI. You can then use text and characters in a specific language when performing inputs on the phone.

The following tables identify the language characters that you can use to enter text and characters on the 6735i.

**Keypad Input Alphabet Tables**

**English**

Key	Uppercase Characters	Lowercase Characters
0	0	0
1	1;=,_'&()	1.;;=,_'&()
2	ABC2	abc2
3	DEF3	def3
4	GHI4	ghi4
5	JKL5	jkl5
6	MNO6	mno6
7	PQRS7	pqrs7
8	TUV8	tuv8
9	WXYZ9	wxyz9
*	* <SPACE>	* <SPACE>
#	#/\@	#/\@

**French**

Key	Uppercase Characters	Lowercase Characters
0	0	0
1	1.;;=,_'&()	1.;;=,_'&()
2	ABC2ÀÂÇÃÄÅÆ	abc2àâçãäåæ
3	DEF3ÉÊËËË	def3éèèèè
4	GHI4Ï	ghi4ï
5	JKL5	jkl5
6	MNO6ÑÓÔÕÖ	mno6ñóôõö
7	PQRS7	pqrs7
8	TUV8	tuv8úùüü
9	WXYZ9	wxyz9
*	* <SPACE>	* <SPACE>
#	#/\@	#/\@

**Spanish**

Key	Uppercase Characters	Lowercase Characters
0	0	0
1	1.;;=,_'&()	1.;;=,_'&()
2	ABC2ÁÂÇ	abc2áâç
3	DEF3ÉÊ	def3éè
4	GHI4Í	ghi4í
5	JKL5	jkl5
6	MNO6ÑÓÔ	mno6ñóò
7	PQRS7	pqrs7
8	TUV8ÚÛ	tuv8úü
9	WXYZ9	wxyz9
*	* <SPACE>	* <SPACE>
#	#/\@	#/\@

**German**

Key	Uppercase Characters	Lowercase Characters
0	0	0
1	1.;=_-'&()	1.;=_-'&()
2	ABC2ÄÄ	abc2ää
3	DEF3É	def3é
4	GHI4	ghi4
5	JKL5	jkl5
6	MNO6Ö	mno6ö
7	PQRS7ß	pqrs7ß
8	TUV8Ü	tuv8ü
9	WXYZ9	wxyz9
*	* <SPACE>	* <SPACE>
#	#/\@	#/\@

**Italian**

Key	Uppercase Characters	Lowercase Characters
0	0	0
1	1.;=_-'&()	1.;=_-'&()
2	ABC2ÀÇÇ	abc2àçç
3	DEF3ÉÈÈ	def3èèè
4	GHI4	ghi4
5	JKL5	jkl5
6	MNO6ÓÒ	mno6óò
7	PQRS7	pqrs7
8	TUV8Ü	tuv8ù
9	WXYZ9	wxyz9
*	* <SPACE>	* <SPACE>
#	#/\@	#/\@

**Portuguese**

Key	Uppercase Characters	Lowercase Characters
0	0	0
1	1.;=_-'&()	1.;=_-'&()
2	ABC2ÁÀÃÇ	abc2àáãç
3	DEF3ÉÈ	def3éè
4	GHI4Í	ghi4í
5	JKL5	jkl5
6	MNO6ÓÔ	mno6óô
7	PQRS7	pqrs7
8	TUV8ÚÛ	tuv8úü
9	WXYZ9	wxyz9
*	* <SPACE>	* <SPACE>
#	#/\@	#/\@

**Russian**

Key	Uppercase Characters	Lowercase Characters
0	0	0
1	1.;=_-'&()	1.;=_-'&()
2	АБВГ2ABC	абвг2abc
3	ДЕЁЖЭЗDEF	Деёжэзdef
4	ИЙКЛ4GHI	ийкл4ghi
5	МНОП5JKL	мноп5jkl
6	РСТУ6MNO	рсту6mno
7	ФХЦЧ7PQRS7	фхчч7pqrs
8	ШЩЪЫ8TUV	шщъы8tuv
9	ЪЗЮЯ9WXYZ	ъзюя9wxyz
*	* <SPACE>	* <SPACE>
#	#/\@	#/\@


**Nordic**

Key	Uppercase Characters	Lowercase Characters
0	0	0
1	1.;=_-'&()	1.;=_-'&()
2	ABC2ÅÄÆÀ	abc2åäæà
3	DEF3É	def3é
4	GHI4	ghi4
5	JKL5	jkl5
6	MNO6ÖØ	mno6öø
7	PQRS7ß	pqrs7ß
8	TUV8Ü	tuv8ü
9	WXYZ9	wxyz9
*	* <SPACE>	* <SPACE>
#	#/\@	#/\@

**Configuring Language Input Using the IP Phone UI**

You can configure the language you use for inputting on the phone by setting the **Input Language** option. The default input language setting is English. You can change this setting using the IP Phone UI or the Aastra Web UI.

For Example:





### IP Phone UI

Use the following procedure to change the input language using the IP Phone UI.

1. Press  on the phone to enter the **Options** List.
2. Select **Preferences**.
3. Select **Language**. Select **Input Language**.  
Select the language you want to use when inputting text and characters into the IP Phone UI. Valid values are:
  - **English** (default)
  - **Français** (French)
  - **Español** (Spanish)
  - **Deutsch** (German)
  - **Italiano** (Italian)
  - **Português** (Portuguese)
  - **Русский** (Russian)
  - **Nordic**

**Note:**  
Available input languages are dependent on the configuration enabled by your System Administrator.
4. Press **Done** when you have selected an input language.



### Aastra Web UI

Use the following procedure to set the input language using the Aastra Web UI.

1. Click on **Basic Settings-> Preferences->Language Settings**.



2. Select a language from the "**Input Language**" field. Setting this field allows you to specify the language to use when entering text and characters in the Aastra Web UI and IP Phone UI. Valid values are:
  - **English** (default)
  - **Français** (French)
  - **Español** (Spanish)
  - **Deutsch** (German)
  - **Italiano** (Italian)
  - **Português** (Portuguese)
  - **Русский** (Russian)
  - **Nordic**

**Note:**  
All languages may not be available for selection. The available input languages are dependant on the configuration enabled by your System Administrator.
3. Click **Save Settings**. The change is dynamic. The Aastra Web UI and IP Phone UI allow you to enter text and characters in the language you selected.

**Latin 2 Character Set**

The 6735i includes support for ISO 8859-2 (Latin2) of multi-national languages when displaying and inputting in the IP Phone UI and the Aastra Web UI.

UTF-8 is also compatible with XML encoding on the IP Phones.

The following table illustrates the Latin 2 character set used on the 6735i IP Phone.

	-0	-1	-2	-3	-4	-5	-6	-7	-8	-9	-A	-B	-C	-D	-E	-F
<b>A-</b>	<a href="#">NBSP</a> 00A0 160	À 0104 161	Á 02D8 162	Â 0141 163	Ã 00A4 164	Ä 013D 165	Å 015A 166	Æ 00A7 167	Ç 00A8 168	Š 0160 169	Ş 015E 170	Ť 0164 171	Ž 0179 172	<a href="#">SHY</a> 00AD 173	Ž 017D 174	Ž 017B 175
<b>B-</b>	° 00B0 176	ą 0105 177	ć 02DB 178	ł 0142 179	ł 00B4 180	ł 013E 181	ś 015B 182	ŷ 02C7 183	š 00B8 184	ş 0161 185	ť 015F 186	ž 0165 187	ž 017A 188	” 02DD 189	ž 017E 190	ž 017C 191
<b>C-</b>	Ř 0154 192	Á 00C1 193	Â 00C2 194	Ă 0102 195	Ä 00C4 196	Í 0139 197	Ç 0106 198	Č 00C7 199	É 010C 200	Ę 00C9 201	Ë 0118 202	Ě 00CB 203	Ě 011A 204	Í 00CD 205	Î 00CE 206	Ď 010E 207
<b>D-</b>	Đ 0110 208	Ñ 0143 209	Ñ 0147 210	Ó 00D3 211	Ô 00D4 212	Ó 0150 213	Ö 00D6 214	× 00D7 215	Ř 0158 216	Û 016E 217	Ú 00DA 218	Û 0170 219	Ü 00DC 220	Ý 00DD 221	Ţ 0162 222	ß 00DF 223
<b>E-</b>	í 0155 224	á 00E1 225	â 00E2 226	ă 0103 227	ä 00E4 228	í 013A 229	ç 0107 230	č 00E7 231	é 010D 232	ę 00E9 233	ë 0119 234	ě 00EB 235	ě 011B 236	í 00ED 237	î 00EE 238	ď 010F 239
<b>F-</b>	đ 0111 240	ñ 0144 241	ñ 0148 242	ó 00F3 243	ô 00F4 244	ó 0151 245	ö 00F6 246	÷ 00F7 247	ř 0159 248	û 016F 249	ú 00FA 250	ú 0171 251	ü 00FC 252	ý 00FD 253	ţ 0163 254	· 02D9 255

## User Password

This category allows you to change the user password for your phone. Changing your password ensures that only you can alter your phone settings, and helps keep your system secure. You can change your user password using the IP Phone UI or the Aastra Web UI.

If you change the password	Then you need to:
using the IP Phone UI,	use that new password to log into the Aastra Web UI.
using the Aastra Web UI,	use that new password when changing the user password via the IP Phone UI.

### Note:

Valid values when creating or changing a password are 0 to 4294967295 (integers only; symbols and alpha characters are not allowed). Default password is an empty string "" (field is blank).

### Setting a User Password



#### IP Phone UI

### Note:

If required, use the following keys while entering a password

- **Backspace** softkey moves cursor back a space and deletes characters
- **Cancel** softkey cancels the password changing process without saving.

1. Press  on the phone to enter the Options List.
2. Select **User Password** and press **Select**.
3. At the "Current Password:" prompt, enter the current user password and press **Enter**.
4. At the "New Password:" prompt, enter the new user password and press **Enter**.
5. At the "Re-enter Password:" prompt, re-enter the new user password and press **Enter**.  
A message, "Password Changed" displays on the screen.



#### Aastra Web UI

1. Click on **Operation->User Password**

### Reset User Password

Please enter the current and new passwords

Current Password

New Password

Password Confirm

2. In the "**Current Password**" field, enter the current user password.  
**Note:**  
By default, the user name is "user" (all lowercase) and the password field is left blank.
3. In the "**New Password**" field, enter the new user password.

4. In the "Password Confirm" field, enter the new user password again.
5. Click Save Settings.

## Resetting a User Password

If you forget your password, you can reset it and enter a new password. The reset user password feature resets the password to the factory default which is blank (no password).

You can reset a user password using the Aastra Web UI only.

**Note:**

Valid values when creating or changing a password are 0 to 4294967295 (integers only; symbols and alpha characters are not allowed). Default password is an empty string "" (field is blank).

### Reset a User Password

Use the following procedure to reset a user password.



1. Click on **Operation->Phone Lock**.



2. In the "Reset User Password" field, click **Reset**.  
The following screen displays.



3. In the "Current Password" field, leave this blank.
4. In the "New Password" field, enter a new password.
5. In the "Password Confirm" field, re-enter your new user password.
6. Click **Save Settings**.

## Restarting Your Phone

You may want to restart your phone to check for updates on the server. You may occasionally need to restart your phone to set changes or updates to your phone or network settings. You may also need to restart your phone if you have been asked to do so by your System Administrator, or should you experience any unexpected behavior.



### IP Phone UI

1. Press the  button on the phone to enter the Options List.
2. Select **Restart Phone**.
3. When the prompt, "Are you sure you wish to restart the phone?" appears, press the **Restart** softkey. If you do not wish to restart your phone, press **Cancel**.

#### Note:

Your phone is out of service temporarily during the restart and downloading process.



### Aastra Web UI

1. Click on **Operation->Reset**.



2. Click **Restart**.
3. Click **OK** at the confirmation prompt.

## Phone Lock

You can lock your phone to prevent the phone from being used or configured. You can lock the phone using any of the following:

- At the path *Options->Phone Lock* on the IP Phone UI.
- At the path *Operations->Phone Lock* on the Aastra Web UI.
- At a configured key on the phone. For more information about configuring a Lock/Unlock key on your phone, see "Phone Lock Key" on page 109.)

In the Aastra Web UI, the *Operation->Phone Lock* path also allows you to perform the following:

- Reset a user password. Clicking on the "Reset" button in the "Reset User Password" field displays a screen that allows you to enter and save a new user password.
- Set an emergency dial plan. An emergency dial plan can be 911, 999, 112, 110 or all of the above. The default emergency dial plan is 911|999|112|110.

The following procedures describe locking the phone, setting an emergency dial plan, and resetting the user password.

## Locking/Unlocking a Phone

Use the following procedures to lock an IP phone and prevent it from being used or configured.



### IP Phone UI

#### Lock the Phone

1. Press  on the phone to enter the Options List.
2. Select **Phone Lock** and press **Select**.
3. At the "Lock the phone?" prompt, press **Yes**  
The message "Phone is locked" displays.

#### Unlock the Phone

1. Press  on the phone to enter the Options List.
2. At the prompt, "To unlock the phone", enter your user password and press **Enter**.  
The phone unlocks.



### Aastra Web UI

1. Click on **Operation->Phone Lock**.



The screenshot shows a web interface titled "Phone Lock". It has a blue header with the title. Below the header, there is a list of settings:

- Lock or unlock the phone** (highlighted in blue)
- Emergency Dial Plan: 911|999|112|110
- Lock the phone?: Lock
- Reset User Password: Reset

At the bottom of the settings list is a "Save Settings" button.

#### Lock the Phone

2. In the "**Lock the Phone?**" field, click **Lock**.  
The phone locks dynamically and displays the following message:  
"Phone is locked".

#### Unlock the Phone

3. Click on **Operation->Phone Lock**.
4. In the "**Unlock the Phone?**" field, click **Unlock**.  
The phone unlocks dynamically and displays the following message:  
"Phone is unlocked".

## Defining an Emergency Dial Plan

Public telephone networks in countries around the world have a single emergency telephone number (emergency services number), that allows a caller to contact local emergency services for assistance when required. The emergency telephone number may differ from country to country. It is typically a three-digit number so that it can be easily remembered and dialed quickly. Some countries have a different emergency number for each of the different emergency services.

You can specify the digits to dial on the IP phone for contacting emergency services. Once you specify the emergency number(s) on the phone, you can dial those numbers directly on the dial pad when required and the phone automatically dials to those emergency services.

### Note:

Contact your local phone service provider for available emergency numbers in your area.

The following table describes the default emergency numbers on the IP phones.

Emergency Number	Description
911	A United States emergency number
999	A United Kingdom emergency number
112	An international emergency telephone number for <b>GSM mobile phone</b> networks. In all European Union countries it is also the emergency telephone number for both mobile and fixed-line telephones.
110	A police and/or fire emergency number in Asia, Europe, Middle East, and South America.

You can set the emergency dial plan using the Aastra Web UI.

### Define an Emergency Dial Plan

Use the following procedure to specify the numbers to use on your phone for dialing emergency services in your area.



#### Aastra Web UI

1. Click on **Operation->Phone Lock**.

**Phone Lock**

Lock or unlock the phone

Emergency Dial Plan

Lock the phone?

Reset User Password


2. In the "**Emergency Dial Plan**" field, enter the 3-digit number used in your local area to contact emergency services. For multiple numbers, enter a "|" between each emergency number. For example:  
**911|110**  
Default for this field is **911|999|112|110**.
3. Click **Save Settings** to save the emergency dial plan to your phone.

### Reference

For more advanced options you can set on your phone, see "[Additional Features](#)" on [page 168](#).

# Line Keys, Programmable Keys, and Softkeys

This section describes the Multiple Line/Call Appearance Keys (L1, L2, L3, and L4) located on the bottom-right of the phone, and the customizable programmable keys and softkeys located at the top of the phone.



## Multiple Line and Call Appearances

The 6735i has 4 hard line/call appearance buttons each with a corresponding status light.

These line/call appearance buttons and lights can represent physical lines, calls for your extension or calls from a group that your extension is part of. By pressing a line/call appearance button, you connect to the line or a call it represents. The line/call appearance light indicates the status of that line or call. When the phone is taken off-hook, the phone automatically selects a line for you.

Line/Call Appearance Light Behavior	Line/Call Appearance Status
Off	Idle line or no call activity
Light flashes quickly	Ringing
Light is solid	Connected
Light flashes slowly	Hold


When you have more than one call, you can use the left and right navigation buttons (◀ and ▶) to scroll left and right to the different call information. Icons ◀ and ▶ appear if there is call information either left, right or both sides of the current information you are viewing.

The display shows which line the call information is referring to (L1, L2, L3, L4, etc.), the Caller ID information (name and number, if available), the call status (**Connected**, **Ring**, **Hold**, etc.) and the timer specific to that call.

## Softkeys and Programmable Keys

Your 6735i has 6 multi-functional top programmable keys and 6 multi-functional bottom softkeys:

- **6 Top Keys:** programmable hard keys  
(up to 6 programmable functions; the following illustration shows the default functions)
- **6 Bottom Keys:** programmable state-based softkeys  
(up to 20 programmable functions).



### Note:

If a M670i or M675i Expansion Module(s) is attached to the phone, you can configure up to an additional 36 softkeys on each M670i Expansion Module and up to 60 softkeys on each M675i Expansion Module. (The 6735i IP Phone allows up to 3 expansion modules on each phone). For more information about expansion modules, see [“Model M670i and M675i Expansion Modules”](#) on page 195.

You can use the Aastra Web UI only, to configure key functions.

The following table lists the functions you can set on the programmable keys and softkeys and provides a description for each function,.

Key Function	Description
None	Indicates no setting for the key.
Line	Indicates the key is configured for line use.
Speed Dial	Indicates the key is configured for speed dial use. You can also configure a prefix for a speed dial number.
Do Not Disturb	Indicates the key is configured for "do not disturb" on the phone.
Busy Lamp Field (BLF)	Indicates the key is configured for Busy Lamp Field (BLF) use. User can dial out on a BLF configured key.
BLF/List	Indicates the key is configured for BLF/List use. User can dial out on a BLF/List configured key.
Auto Call Distribution (ACD)	(For Sylantrio Servers) Indicates the key is configured to allow the Sylantrio server to distribute calls from a queue to registered IP phone users (agents).
Directed Call Pickup (DCP)/ Group Call Pickup (GCP)	(Feature dependant on your call manager) Indicates the key is configured to allow you to intercept - or pickup - a call on a monitored extension(s).

Key Function	Description
<b>XML</b>	Indicates the key is configured to accept an XML application for accessing customized XML services. You can also specify an XML key URL for this option.
<b>Flash</b>	Indicates the key is set to generate a flash event when it is pressed on the 6735i. The IP phone generates flash events only when a call is connected and there is an active RTP stream (for example, when the call is not on hold).
<b>Sprecode</b>	Indicates the key is configured to automatically activate specific services offered by the server. For example, if the sprecode value of *82 is configured, then by pressing the sprecode key, *82 automatically activates a service provided by the server. Contact your System Administrator for available services.
<b>Park</b>	Indicates the key is configured to park incoming calls when pressed.
<b>Pickup</b>	Indicates the key is configured to pick up parked calls when pressed.
<b>Last Call Return (lcr)</b>	Indicates the key is configured for "last call return" when pressed.
<b>Call Forward</b>	Indicates the key is configured as a Call Forward key. When pressed, the IP Phone UI displays the Call Forward menus.
<b>BLF/Xfer</b>	Indicates the key is configured as a simplified BLF key and a transfer key. You can use this key to perform the BLF function, or you can use it as a transfer key to transfer calls.
<b>Speeddial/Xfer</b>	Indicates the key is configured as a simplified speed dial key and a transfer key. You can use this key to perform speed dial functions, or you can use it as a transfer key to transfer calls.
<b>Speeddial/Conf</b>	Indicates the key is configured as a speed dial key and a conference key. You can use this key to speed dial from within a conference call, and add the new call directly to the conference.
<b>Directory</b>	Indicates the key is configured to access the Directory List.
<b>Callers List</b>	Indicates the key is configured to access the Callers List.
<b>Intercom</b>	Indicates the key is configured to be used for intercom calls.
<b>Services</b>	Indicates the key is set to access Services, such as, Directory List, Callers List, Voicemail, or any other XML applications set up by your System Administrator.
<b>Phone Lock</b>	Indicates the key is configured as a phone lock key, allowing you to press this key to lock/unlock the phone.
<b>Paging</b>	Indicates the key is configured as a Paging key. When pressed, the phone can send Real Time Transport Protocol (RTP) streams from a preconfigured multicast address without involving SIP signaling. You can also receive RTP streams from preconfigured multicast addresses (can specify up to 5 addresses) using the "Paging Listen Addresses" at the path, <i>Basic Settings-&gt;Preferences-&gt;Group Paging</i> RTP Settings in the Aastra Web UI. For more information about setting this parameter, see " <a href="#">Group RTP Paging (receives RTP streams)</a> " on <a href="#">page 182</a> .
<b>Empty</b>	Indicates the key has no function assigned.

Keys can also be set up to quickly to access features such as Call Return (\*69) or Voicemail.


**Note:**

Quick access features like Call Return and Voicemail must first be configured on your PBX in order to work on your phone. See your System Administrator for more information.

The following paragraphs describe how to configure each function listed in the previous table.

## State-Based Softkeys (Bottom Keys only)

On the 6735i bottom softkeys, you can configure a specific state to display when a softkey is being used.



The following table describes the states available to configure for the softkeys.

State	Description
idle	The phone is not being used.
connected	The current line is in an active call (or the call is on hold).
incoming	The phone is ringing.
outgoing	The user is dialing a number, or the far-end is ringing.
busy	The current line is busy because the line is in use or the line is set as "Do Not Disturb".

The following table identifies the applicable default states for each softkey type on the IP phone.

Softkey Type	Default States
None	All states disabled.
Line	idle, connected, incoming, outgoing, busy
Speed Dial	idle, connected, incoming, outgoing, busy
DND	idle, connected, incoming, outgoing, busy
BLF	idle, connected, incoming, outgoing, busy
BLF/List	idle, connected, incoming, outgoing, busy
Auto Call Distribution (ACD)	idle
Directed Call Pickup (DCP) Group Call Pickup (GCP)	idle, connected, incoming, outgoing, busy
XML	idle, connected, incoming, outgoing, busy
Flash	All states disabled.
Sprecode	connected
Park	connected
Pickup	idle, outgoing
Last Call Return	idle, connected, incoming, outgoing, busy
Call Forward	idle, connected, incoming, outgoing, busy
BLF/Xfer	idle, connected, incoming, outgoing, busy
Speeddial/Xfer	idle, connected, incoming, outgoing, busy
Speeddial/Conf	idle, connected, incoming, outgoing, busy

Softkey Type	Default States
Directory	idle, connected, incoming, outgoing, busy
Callers List	idle, connected, incoming, outgoing, busy
Intercom	idle, connected, incoming, outgoing, busy
Services	idle, connected, incoming, outgoing, busy
Phone Lock	All states disabled.
Paging	All states disabled.
Empty	idle, connected, incoming, outgoing, busy

In the Aastra Web UI, the operational states for each softkey display enabled. To disable a state, you uncheck the box for that state.

### Key Display Behavior

On the 6735i IP Phone, you can configure up to 20 functions on the softkeys. If you have no softkeys configured on the IP Phone, and you assign softkey functions to higher number keys in the Aastra Web UI, the key functions automatically appear in the first available position on the LCD display.

For example, if softkeys 1 through 20 are set to "**None**", and you set softkey 12 as the following:

**Type:** speeddial

**Label:** LAB

**Value:** 3456

after saving the settings, the "LAB" label actually appears in position 1 of the LCD.


A softkey function of "**none**" does not display on the idle screen at all.

The following illustrations show the configuration of Key 12 and how that key displays on the phone:

### Softkeys Configuration

Key	Type	Label	Value	Line	Idle	Connected	Incoming	Outgoing	Busy
1	None			1	<input checked="" type="checkbox"/>				
2	None			1	<input checked="" type="checkbox"/>				
3	None			1	<input checked="" type="checkbox"/>				
4	None			1	<input checked="" type="checkbox"/>				
5	None			1	<input checked="" type="checkbox"/>				
6	None			1	<input checked="" type="checkbox"/>				
7	None			1	<input checked="" type="checkbox"/>				
8	None			1	<input checked="" type="checkbox"/>				
9	None			1	<input checked="" type="checkbox"/>				
10	None			1	<input checked="" type="checkbox"/>				
11	None			1	<input checked="" type="checkbox"/>				
12	Speeddial	LAB	3456	1	<input checked="" type="checkbox"/>				
13	None			1	<input checked="" type="checkbox"/>				
14	None			1	<input checked="" type="checkbox"/>				
15	None			1	<input checked="" type="checkbox"/>				
16	None			1	<input checked="" type="checkbox"/>				
17	None			1	<input checked="" type="checkbox"/>				
18	None			1	<input checked="" type="checkbox"/>				
19	None			1	<input checked="" type="checkbox"/>				
20	None			1	<input checked="" type="checkbox"/>				


Key 12 displays in softkey position 1 on the phone



## Line Key

You can set a programmable key or softkey to act as a line/call appearance key on the 6735i. The This key acts as a line that behaves the same as a hard line key (L1, L2, L3, and L4). For more information about the behavior of line keys, see [“Multiple Line and Call Appearances”](#) on page 53.

If you configure line keys for the bottom softkeys, the status of the lines/call appearance keys appear on the phone’s display as shown in the following image.



Icons next to the softkeys on the phone’s display indicate the status for that line or call. The following table provides a description for each icon.

Softkey Line/Call Appearance Lights			
Activity	Light	Icon	Definition
Idle	Solid	■	There is no call activity for the line/call appearance softkey.
Connected	Solid	●	A call is connected to your phone on this line/call appearance softkey. The equivalent on a line/call appearance hard key is a solid green light.
Ringing	Flashing	◐	A call is ringing at your phone on this line/call appearance softkey. The equivalent on a line/call appearance hard key is a fast flashing green light.
On Hold	Flashing	◑	A call is on hold on your phone on this line/call appearance softkey. The equivalent on a line/call appearance hard key is a slow flashing green light.

Depending on how the phone has been configured, the maximum number of total line/call appearances that can be configured is 9 (4 line/call appearance hard keys plus 5 softkeys or programmable keys). If all line/call appearances have been set up between two different numbers, a total of 8 lines can be configured.

This means that when all line/call appearances are in use, 1 call is connected while the rest are on hold. No further outgoing or incoming calls can be made until one of the line/call appearances becomes available.

In active states, such as ringing, conference, connected, etc., all softkeys disappear except softkeys that have been set up as line/call appearances, and any context dependent softkeys required for the active state, such as the **Drop** softkey in the connected state. Typically, context dependent softkeys appear in the top left position and all line/call appearance softkeys appear in the remaining positions.

**Note:**

In some situations, such as during a conference call, the line/call appearance softkeys may overwrite some of the context dependent softkeys. In this case, instead of the **Previous** and **Next** softkeys, up or down icons, ▲ and ▼ appear on the display. By using the ▲ and ▼ navigation keys, you can access the same functionality as the **Previous** and **Next** softkeys.

You use the Aastra Web UI to set a programmable key or softkey as a line.

### Configuring a Line Key

You can set a key as an additional line on the 6735i. The key acts as a line that behaves the same as a hard line key. For more information about the behavior of line keys, see “Multiple Line and Call Appearances” on page 53.

You use the Aastra Web UI to set a key as a line.



#### Aastra Web UI

Use the following procedure to set a key to function as a line. The procedure shows the softkey screens as an example.

1. Click on **Operation->Softkeys and XML**.  
or  
Click on **Operation->Programmable Keys**.  
or  
Click on **Operation->Expansion Module <N>**.

#### Softkeys Configuration

Key	Type	Label	Value	Line	Idle	Connected	Incoming	Outgoing	Busy
1	Line	Test		5	<input checked="" type="checkbox"/>				
2	None			1	<input checked="" type="checkbox"/>				
3	Park			1	<input checked="" type="checkbox"/>				
4	Pickup			1	<input checked="" type="checkbox"/>				
5	None			1	<input checked="" type="checkbox"/>				

#### Softkeys

2. Select from "**Key 1**" through "**Key 20**".
3. In the "**Type**" field, select **Line** to apply to the key.
4. In the "**Label**" field, enter a label to apply to this key.
5. In the "**Line**" field, select a line to apply to this key.  
Valid values are **5** through **9**.
6. In the state fields, check (enable) or uncheck (disable) the states you want to apply to this softkey.

#### Programmable Keys

7. Select from "**Key 1**" through "**Key 6**".
8. In the "**Line**" field, select a line to apply to this key.  
Valid values are **5** through **9**.

### Expansion Module Keys

9. Select from "**Key 1**" through "**Key 36**" (M670i).  
or  
Select from "**Key 1**" through "**Key 60**" (M675i).
10. In the "**Line**" field, select a line to apply to this key.  
Valid values are 5 through 9.
11. (M675i) In the "**Label**" field, enter a label to apply to this key.
12. Click **Save Settings**.

## Speeddial Key

The normal function of the speed dial option allows you to dial a number quickly by pressing a key configured for speed dialing. You can program the keys on the 6735i to speed dial outside numbers, dial directly to another person's line or extension, or set up to quickly access features such as Caller ID (\*69), Voicemail.

The speed dial function can be set using the IP Phone UI or the Aastra Web UI.

### Note:

You can use a speed dial key while on an active call by placing the active call on hold first, and then pressing the speed dial key.

You can create speed dial keys using any of the following methods:

- Using the Aastra Web UI at the paths:
  - Operation->Softkeys and XML
  - Operation->Programmable Keys
  - Operation->Expansion Module Keys
- Using the IP Phone UI at the path, *Options->Preferences->Speed Dial Edit*
- By pressing and holding a programmable key, softkey, keypad key, or expansion module key.

### Speed Dial Prefix

The speed dial feature also allows you to specify a preset string of numbers followed by a "+" that the phone dials automatically after pressing the speed dial key. You can use this feature for numbers that contain long prefixes.

For example, if you had the following speed dial configuration in the Aastra Web UI:

#### Key 1

**Type**=speeddial

**Label**=Europe Office

**Value**=1234567+

**Line**=2

then, after you press key 1 on the phone, the prefix number displays on the phone screen. The phone proceeds to dial the prefix number automatically and pauses for you to enter the remaining phone number using the keypad on the phone.

You can save up to 30 speed dial numbers on the 6735i.

Use the following procedures to set speed dial on the 6735i IP phone.

**Press-and-Hold to Create a Speed Dial (applicable to programmable keys, softkeys, keypad keys, expansion module keys)****IP Phone UI**

Pressing and holding down a programmable key, softkey, keypad key, or expansion module key on the phone initiates a speed dial feature.

**Note:**

When creating a speed dial key from the IP Phone UI, you must select a softkey, keypad key, or expansion module key that has no preassigned function (key must be set to **None**).

1. Press a unconfigured programmable key, softkey, keypad key, or expansion module.  
The following screen displays:

**Note:**

You can press the **"Cancel"** softkey at anytime during the speed dial programming to cancel and not save the speed dial information.

2. In the **"Enter Name:"** field, enter a name to apply to the speed dial key.  
Use the keypad keys to enter the name. Continue to press the keypad keys to access the next letter for that key (i.e. press **2** three times to access **C**). Press **►** to move to the next space, or wait for the cursor to automatically advance to the next position. To insert a space between letters, press **►**. To backspace and erase a mistake, press the **Backspace** softkey.

**Note:**

The phone automatically uses an uppercase letter for the first letter of each word and a lowercase letter for all subsequent letters in the word. If necessary, use the **"ABC ►"** softkey to specify uppercase letters or lowercase letters when entering the name.

You can enter up to 16 letters in the "Enter Name:" field.


Press the **▼** key to move to the next field.

3. In the **"Enter Number:"** field, enter a number for the speed dial key using the keypad keys. You can enter up to 16 numbers in the "Enter Number:" field.

**Note:**

When in the **"Enter Number:"** field, the phone automatically switches to the numbers softkey. Press the **▼** key to move to the next field.

- In the "Line:" field, select a line to apply to the speed dial key.



This is the line that the phone opens to dial the number after you press the speed dial key. By default, the phone uses Line 1 for the speed dial key. If you want to use a different line, press the "Change" key, or press the > key to select another line.

- Press the "Save" softkey to save the speed dial information to the speed dial key you selected.

**Note:**

To delete or remove a speed dial configuration from the phone, you can press the Remove key.

### Creating a Speed Dial Using the Speed Dial Edit Option

You can use the IP Phone UI at the path, **Options->Preferences->Speed Dial Edit**, to create a speed dial key.



- Press  on the phone to enter the Options List.

- Select **Preferences** and press **Select**.

- Select **Speed Dial Edit** and press **Select**.

The following prompt displays:

"Press SD button"


All current speed dial key LEDs flash RED (for softkeys, programmable keys and expansion module keys). All other function key LEDs turn off, during this process. After you press a speed dial key for editing, the phone restores all key LEDs to their previous state.

**Note:**

If you select a key that is currently set as a speed dial key, the speed dial information displays for you to edit.

- Press a unconfigured softkey, programmable key, keypad key, or expansion module key.

The following screen displays:



**Note:**

You can press the "Cancel" softkey at anytime during the speed dial programming to cancel and not save the speed dial information.

5. In the "**Enter Name:**" field, enter a name to apply to the speed dial key.

Use the keypad keys to enter the name. Continue to press the keypad keys to access the next letter for that key (i.e. press **2** three times to access **C**). Press **▶** to move to the next space, or wait for the cursor to automatically advance to the next position. To insert a space between letters, press **▶**. To backspace and erase a mistake, press the **Backspace** softkey.


**Note:**

The phone automatically uses an uppercase letter for the first letter of each word and a lowercase letter for all subsequent letters in the word. If necessary, use the "**ABC ▶**" softkey to specify uppercase letters or lowercase letters when entering the name.

You can enter up to 16 letters in the "Enter Name:" field.

6. Press the **▼** key to move to the next field.

7. In the "**Enter Number:**" field, enter a number. for the speed dial key using the keypad keys. You can enter up to 16 numbers in the "Enter Number:" field




**Note:**

When in the "**Enter Number:**" field, the phone automatically switches to the numbers softkey.

8. Press the **▼** key to move to the next field.

9. In the "**Line:**" field, select a line to apply to the speed dial key.



This is the line that the phone opens to dial the number after you press the speed dial key. By default, the phone uses Line 1 for the speed dial key. If you want to use a different line, press the "**Change**" key, or press the **▶** key to select another line.

10. Press the "Save" softkey to save the speed dial information to the speed dial key you selected.

**Note:**

To delete or remove a speed dial configuration from the phone, you can press the **Remove** key.

## Creating a Speed Dial Key Using the Softkeys, Programmable Keys, or Expansion Module Keys



Aastra Web UI

Use the following procedure to set a key to function as a speed dial. The procedure shows the softkey screens as an example.

1. Click on **Operation->Softkeys and XML**.  
or  
Click on **Operation->Programmable Keys**.  
or  
Click on **Operation->Expansion Module <N>**.

### Softkeys Configuration

Key	Type	Label	Value	Line	Idle	Connected	Incoming	Outgoing	Busy
1	Speeddial	Test	9051234567+	2	<input checked="" type="checkbox"/>				
2	Phone Lock			1	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
3	Park			1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
4	Empty			1	<input checked="" type="checkbox"/>				
5	None			1	<input type="checkbox"/>				
6	None			1	<input type="checkbox"/>				

### Softkeys

2. Select from **"Key 1"** through **"Key 20"**.
3. In the **"Type"** field, select **Speed Dial** to apply to the key.
4. In the **"Label"** field, enter a label to apply to this key.
5. In the **"Value"** field, enter the phone number, extension, or speed dial prefix to apply to this key. If you enter a speed dial prefix, you must enter the "+" character at the end of the prefix number (for example, "123456+").
6. In the **"Line"** field, select a line to apply to this key. Valid values are **1** through **9**.
7. In the state fields, check (enable) or uncheck (disable) the states you want to apply to this softkey.

### Programmable Keys

8. Select from **"Key 1"** through **"Key 6"**.
9. In the **"Type"** field, select **Speed Dial** to apply to the key.
10. In the **"Value"** field, enter the phone number, extension, or speed dial prefix to apply to this key. If you enter a speed dial prefix, you must enter the "+" character at the end of the prefix number (for example, "123456+").
11. In the **"Line"** field, select a line to apply to this key. Valid values are **1** through **9**.

### Expansion Module Keys

12. Select from **"Key 1"** through **"Key 36"** (M670i).  
or  
Select from **"Key 1"** through **"Key 60"** (M675i).
13. In the **"Type"** field, select **Speed Dial** to apply to the key.
14. (M675i) In the **"Label"** field, enter a label to apply to this key.
15. In the **"Value"** field, enter the phone number, extension, or speed dial prefix to apply to this key. If you enter a speed dial prefix, you must enter the "+" character at the end of the prefix number (for example, "123456+").
16. In the **"Line"** field, select a line to apply to this key. Valid values are **1** through **9**.
17. Click **Save Settings**.

## Creating Speed Dial Key Using "Keypad Speed Dial" in the Aastra Web UI



### Aastra Web UI

1. Click on **Operation->Keypad Speed Dial**.

**Keypad Speed Dial**

Key	Value	Line
1	<input type="text" value="9051234567"/>	1 <input type="button" value="v"/>
2	<input type="text" value="9067654321"/>	1 <input type="button" value="v"/>
3	<input type="text" value="9050000000"/>	1 <input type="button" value="v"/>
4	<input type="text"/>	1 <input type="button" value="v"/>
5	<input type="text"/>	1 <input type="button" value="v"/>
6	<input type="text"/>	1 <input type="button" value="v"/>
7	<input type="text"/>	1 <input type="button" value="v"/>
8	<input type="text"/>	1 <input type="button" value="v"/>
9	<input type="text"/>	1 <input type="button" value="v"/>


2. Select from "**Digit 1**" through "**Digit 9**".
3. In the input box, enter the phone number, extension, or speed dial prefix to apply to this Digit key. If you enter a speed dial prefix, you must enter the "+" character at the end of the prefix number (for example, "123456+").
4. In the "**Line**" field, select a line for which to apply the speed dial to. Valid values are **1** through **9**.
5. Click **Save Settings**.

## Editing Speed Dial Keys

On the 6735i, you can edit a speed dial key using any of the following methods:

- Using the Aastra Web UI at the path:
  - Operation->Softkeys and XML
  - Operation->Programmable Keys
  - Operation->Expansion Module Keys
- Using the IP Phone UI at the path:
  - Options->Preferences->Speed Dial Edit

The following illustration shows the path in the 6735i IP Phone UI for editing a speed dial key.



 **IP Phone UI**

Use the following procedure to edit a speed dial key from the IP Phone UI.

**Note:**

A speed dial key must be already configured on the phone to edit the key.

1. Press  on the phone to enter the Options List.
2. Select **Preferences**.
3. Select **Speed Dial Edit**.  
All current speed dial key LEDs flash RED (for programmable keys and expansion module keys). All other function key LEDs turn off, during this process. After you press a speed dial key for editing, the phone restores all key LEDs to their previous state.
4. Press a speed dial key you want to edit.  
The speed dial edit screen displays.  
**Notes:**
  1. If a number on the keypad is setup as a speed dial key, pressing the applicable number in the speed dial editing process also displays the speed dial edit screen. The edit screen allows you to change the Speed Dial Number and Line setting.
  2. If you press a key that is NOT setup as a speed dial key, the phone displays an "Invalid Key" message. However, if you press-and-hold an empty digit key, softkey, or expansion module key set to "NONE", it initiates the "Add a speed dial Key" process allowing you to setup a new speed dial key. For more information, see "Press-and-Hold to Create a Speed Dial (applicable to programmable keys, softkeys, keypad keys, expansion module keys)" on page 62.
5. Edit the speed dial information as applicable and press SAVE.

**Notes:**

1. You can cancel out of the speed dial editing process at any time without saving, by pressing the  key, or the Cancel key.
2. You can delete a speed dial key by pressing the **Remove** key.

## Editing a Speed Dial on a Softkey, Programmable Key, or Expansion Module Key



Aastra Web UI

1. Click on **Operation->Softkeys and XML.**  
or  
Click on **Operation->Programmable Keys.**  
or  
Click on **Operation->Expansion Module <N>.**

## Softkeys Configuration

Key	Type	Label	Value	Line	Idle	Connected	Incoming	Outgoing	Busy
1	Speeddial	Test	9051234567+	2	<input checked="" type="checkbox"/>				
2	Phone Lock			1	<input checked="" type="checkbox"/>				
3	Park			1	<input checked="" type="checkbox"/>				
4	Empty			1	<input checked="" type="checkbox"/>				
5	None			1	<input checked="" type="checkbox"/>				
6	None			1	<input checked="" type="checkbox"/>				

2. Select the key configured for speed dial.
3. In the "**Value**" field, edit the phone number, extension, or speed dial prefix to apply to this hard key. If you enter a speed dial prefix, you must enter the "+" character at the end of the prefix number (for example, "123456+").
4. In the "**Line**" field, select a line for which to apply the speed dial to. Valid values are **1** through **9**.
5. Click **Save Settings**.

**Note:**

You can delete a speed dial key by removing the information from the "**Value**" field.

**Editing a Speed Dial Key Using "Keypad Speed Dial" in the Aastra Web UI**

1. Click on **Operation->Keypad Speed Dial**.

**Keypad Speed Dial**

Key	Value	Line
1	<input type="text" value="9051234567"/>	1 <input type="button" value="v"/>
2	<input type="text" value="9067654321"/>	1 <input type="button" value="v"/>
3	<input type="text" value="9050000000"/>	1 <input type="button" value="v"/>
4	<input type="text"/>	1 <input type="button" value="v"/>
5	<input type="text"/>	1 <input type="button" value="v"/>
6	<input type="text"/>	1 <input type="button" value="v"/>
7	<input type="text"/>	1 <input type="button" value="v"/>
8	<input type="text"/>	1 <input type="button" value="v"/>
9	<input type="text"/>	1 <input type="button" value="v"/>

2. Select from "**Digit 1**" through "**Digit 9**".
3. In the input box, edit the phone number, extension, or speed dial prefix for this Digit key. If you enter a speed dial prefix, you must enter the "+" character at the end of the prefix number (for example, "123456+").
4. In the "**Line**" field, select a line for which to apply the speed dial to. Valid values are **1** through **9**.
5. Click **Save Settings**.

**"Do Not Disturb" (DND) Key**

The IP phones have a feature you can enable called "Do not Disturb (DND)". The DND function allows you to turn "do not disturb" ON and OFF.

**Note:**

You can configure DND using the Aastra Web UI only.

If DND is ON, callers calling into the phone hear a busy signal or a message, depending on how your System Administrator set up the configuration server. The second line on the screen of the IP phone shows when DND is set.

If the phone shares a line with other phones, only the phone that has DND configured is affected.

You can set DND on the keys using the Aastra Web UI only. DND is not configurable from the IP phone UI.

## Configuring a DND Key



### Aastra Web UI

Use the following procedure to set a key to function as "Do Not Disturb". The procedure shows the softkey screens as an example.

1. Click on **Operation->Softkeys and XML**.  
or  
Click on **Operation->Programmable Keys**.  
or  
Click on **Operation->Expansion Module <N>**.

#### Softkeys Configuration

Key	Type	Label	Value	Line	Idle	Connected	Incoming	Outgoing	Busy
1	Do Not Disturb			1	<input checked="" type="checkbox"/>				
2	None			1	<input type="checkbox"/>				
3	Line			5	<input checked="" type="checkbox"/>				
4	Empty			1	<input checked="" type="checkbox"/>				
5	Speeddial			1	<input checked="" type="checkbox"/>				
6	None			1	<input type="checkbox"/>				

#### Softkeys

2. Select from **"Key 1"** through **"Key 20"**.
3. In the **"Type"** field, select **Do Not Disturb** to apply to the key.
4. In the state fields, check (enable) or uncheck (disable) the states you want to apply to this softkey.

#### Programmable Keys

5. Select from **"Key 1"** through **"Key 6"**.
6. In the **"Type"** field, select **Do Not Disturb** to apply to the key.

#### Expansion Module Keys

7. Select from **"Key 1"** through **"Key 36"** (M670i).  
or  
Select from **"Key 1"** through **"Key 60"** (M675i).
8. In the **"Type"** field, select **Do Not Disturb** to apply to the key.
9. Click **Save Settings**.

## Busy Lamp Field (BLF) Key

The BLF feature on the IP phones allows a specific extension to be monitored for state changes. BLF monitors the status (busy or idle) of extensions on the IP phone.

### Note:

BLF feature availability is dependant on your call manager. Contact your System Administrator for more information

### Example

A Supervisor configures BLFs on his phone for monitoring the status of a worker's phone use (busy or idle). When the worker picks up his phone to make a call, a busy indicator on the Supervisor's phone shows that the worker's phone is in use and busy.

On the 6735i, the busy and idle indicators show on the IP phone screen display next to the key programmed for BLF functionality. When the monitored user is idle, an icon with the handset on-hook shows next to the BLF key. When the monitored user is on an active call, a small telephone icon is shown with the handset off-hook.

### Note:

You can also use a BLF configured key to dial out. Contact your System Administrator for more information

## Configuring a BLF Key



### Aastra Web UI

Use the following procedure to set a key to function as "BLF". The procedure shows the softkey screens as an example.

1. Click on **Operation->Softkeys and XML**.  
or  
Click on **Operation->Programmable Keys**.  
or  
Click on **Operation->Expansion Module <N>**.

### Softkeys Configuration

Key	Type	Label	Value	Line	Idle	Connected	Incoming	Outgoing	Busy
1	BLF	Test	9051234567	3	<input checked="" type="checkbox"/>				
2	None			1	<input type="checkbox"/>				
3	Line			5	<input checked="" type="checkbox"/>				
4	Empty			1	<input checked="" type="checkbox"/>				
5	Speeddial			1	<input checked="" type="checkbox"/>				
6	None			1	<input type="checkbox"/>				

### Softkeys

2. Select from "Key 1" through "Key 20".
3. In the "Type" field, select **BLF** to apply to the key.
4. In the "Label" field, enter a label to apply to this key.
5. In the "Value" field, enter the phone number or extension you want to monitor.
6. In the "Line" field, select a line for which to apply this key. Valid values are:
  - global
  - 1 through 9
7. In the state fields, check (enable) or uncheck (disable) the states you want to apply to this softkey.

### Programmable Keys

8. Select from "Key 1" through "Key 6".

9. In the "**Value**" field, enter the phone number or extension you want to monitor.
10. In the "**Line**" field, select a line for which to apply this key. Valid values are:
  - global
  - 1 through 9

#### **Expansion Module Keys**

11. Select from "**Key 1**" through "**Key 36**" (M670i).  
or  
Select from "**Key 1**" through "**Key 60**" (M675i).
12. In the "**Value**" field, enter the phone number or extension you want to monitor.
13. (M675i) In the "**Label**" field, enter a label to apply to this key.
14. In the "**Line**" field, select a line for which to apply this key. Valid values are:
  - global
  - 1 through 9
15. Click **Save Settings**.

## **BLF/List Key**

(For use with the BroadSoft Broadworks Rel 13 or higher platform only).

The BLF/List feature on the IP phones is specifically designed to support the BroadSoft Broadworks Rel 13 Busy Lamp Field feature.

This feature allows the IP phone to subscribe to a list of monitored users defined through the BroadWorks web portal.

#### **Note:**

Your System Administrator must have BLF/List enabled on the BroadWorks Server. Contact your System Administrator for more information.

In addition to monitoring the idle and busy state, the BLF/List feature also supports the ringing state. When the monitored user is idle, there is a small telephone icon shown with the handset on-hook. When the monitored user is on an active call, a small telephone icon is shown with the handset off-hook.

#### **Note:**

You can use a BLF/List configured key to dial out.

#### **Example**

A receptionist has a 6735i running Broadsoft firmware that subscribes to a list of extensions from the BroadWorks Application Server. On the 6735i, the key LEDs illuminate either flashing, solid, or turn off depending on the state of those extensions.

#### **Note:**

The Broadworks BLF feature is not the same as the Broadworks Shared Call Appearance (SCA) feature and does not permit call control over the monitored extension.

### Configuring a BLF/List Key

The BLF List function can be configured on the 6735i using the Aastra Web UI only.

If you set a key to use BLF/List, you must also enter a **BLF List URI** at **Operation->Softkeys and XML->Services**. The BLF List URI is the name of the BLF/List defined on the BroadSoft BroadWorks Busy Lamp field page for your particular user. For example, sip:9@192.168.104.13. The value of the BLF/List URI parameter must match the list name configured. Otherwise, no values display on the 6735i screen and the feature is disabled.



Use the following procedure to set a key to function as "BLF/List". The procedure shows the softkey screens as an example.

1. Click on **Operation->Softkeys and XML**.  
or  
Click on **Operation->Programmable Keys**.  
or  
Click on **Operation->Expansion Module <N>**.

#### Softkeys Configuration

Key	Type	Label	Value	Line	Idle	Connected	Incoming	Outgoing	Busy
1	BLF/List	Test		3	<input checked="" type="checkbox"/>				
2	Pickup			1	<input checked="" type="checkbox"/>				
3	Speeddial			1	<input checked="" type="checkbox"/>				
4	None			1	<input type="checkbox"/>				
5	None			1	<input type="checkbox"/>				
6	None			1	<input type="checkbox"/>				
7	None			1	<input type="checkbox"/>				
8	None			1	<input type="checkbox"/>				
9	None			1	<input type="checkbox"/>				
10	None			1	<input type="checkbox"/>				
11	None			1	<input type="checkbox"/>				
12	None			1	<input type="checkbox"/>				
13	None			1	<input type="checkbox"/>				
14	None			1	<input type="checkbox"/>				
15	None			1	<input type="checkbox"/>				
16	None			1	<input type="checkbox"/>				
17	None			1	<input type="checkbox"/>				
18	None			1	<input type="checkbox"/>				
19	None			1	<input type="checkbox"/>				
20	None			1	<input type="checkbox"/>				

Services	
XML Application URI:	<input type="text"/>
XML Application Title:	<input type="text"/>
BLF List URI:	sip:9@192.168.104.13

#### Softkeys

2. Select from "Key 1" through "Key 20".
3. In the "Type" field, select "BLF/List" (BroadSoft BroadWorks).

4. In the "**Line**" field, select a line number that is actively registered to the appropriate SIP proxy you are using. Valid values are:
  - global
  - 1 through 9**Note:**  
The "Label" and "Value" field are not required. The BroadWorks BLF/List name is configured in the "BLF List URI" field instead.
5. In the state fields, check (enable) or uncheck (disable) the states you want to apply to this softkey.
6. In the "**BLF List URI**" field, enter the name of the BLF list defined on the BroadSoft BroadWorks Busy Lamp field page for your particular user. For example, sip:9@192.168.104.13.  
**Note:**  
Contact your System Administrator for the BLF List URI.

#### **Programmable Keys**

7. Select from "**Key 1**" through "**Key 6**".
8. In the "**Line**" field, select a line for which to apply this key. Valid values are:
  - global
  - 1 through 9**Note:**  
The "Value" field is not required. The BroadWorks BLF/List name is configured in the "BLF List URI" field instead.
9. In the "**BLF List URI**" field, enter the name of the BLF list defined on the BroadSoft BroadWorks Busy Lamp field page for your particular user. For example, sip:9@192.168.104.13.  
**Note:**  
Contact your System Administrator for the BLF List URI.

#### **Expansion Module Keys**

10. Select from "**Key 1**" through "**Key 36**" (M670i).  
or  
Select from "**Key 1**" through "**Key 60**" (M675i).
11. In the "**Line**" field, select a line for which to apply this key. Valid values are:
  - global
  - 1 through 9**Note:**  
The "Value" field is not required. The BroadWorks BLF List name is configured in the "BLF List URI" field instead.
12. In the "**BLF List URI**" field, enter the name of the BLF list defined on the BroadSoft BroadWorks Busy Lamp field page for your particular user. For example, sip:9@192.168.104.13.  
**Note:**  
Contact your System Administrator for the BLF/List URI.
13. Click **Save Settings**.

## Automatic Call Distribution (ACD) Key (for Sylanro Servers)

The 6735i and any attached Expansion Modules support Automatic Call Distribution (ACD) for Sylanro servers. The ACD feature allows the Sylanro server to distribute calls from a queue to registered IP phone users (agents).

To use the ACD feature on an IP phone, you must first configure an ACD softkey, programmable key, or expansion module key. When you want to subscribe to a queue (in order to receive incoming calls), you press the ACD key and the IP phone UI prompts you to specify the following information:

- **User ID:** the phone number(s) used to login into the queue.
- **Password:** the password used to login to the queue.
- **Available/unavailable:** shows the current status of the IP phone. Specifies if the IP phone user is available/unavailable to receive a call from the queue.

### Note:

Your System Administrator must provide you with your User ID and Password to access the applicable phone queue.

After creating an ACD key, you are ready to receive calls from a queue on the server. You must press the ACD key and then log in by entering your User ID and Password. An "Available" softkey displays allowing you to make your phone available to accept these calls.

When you are on an active call, or you miss a call, the server automatically changes the phone's status to unavailable. The server updates its database with this new information and no longer distributes calls to the phone. The phone remains in this "unavailable" state until:

- you make yourself "available" again by pressing the "Available" softkey.
- an ACD timer expires (set by your System Administrator).

You can also choose to manually change the phone status to unavailable by pressing the "Unavailable" softkey on the phone.

### Note:

It is recommended you configure no more than a single ACD softkey or expansion module key per IP phone.

## Configuring an Automatic Call Distribution (ACD) Key



Aastra Web UI

Use the following procedure to configure ACD on the 6735i IP Phone. The procedure shows the softkey screens as an example.

1. Click on **Operation->Softkeys and XML**.  
or  
Click on **Operation->Programmable Keys**.  
or  
Click on **Operation->Expansion Module <N>**.

### Softkeys Configuration

Key	Type	Label	Value	Line	Idle	Connected	Incoming	Outgoing	Busy
1	Auto call distribution	Test		4	<input checked="" type="checkbox"/>				
2	None			1	<input checked="" type="checkbox"/>				
3	Line			5	<input checked="" type="checkbox"/>				
4	Empty			1	<input checked="" type="checkbox"/>				
5	Speeddial			1	<input checked="" type="checkbox"/>				
6	None			1	<input checked="" type="checkbox"/>				

### Softkeys

2. Select from "**Key 1**" through "**Key 20**".
3. In the "**Type**" field, select "**Auto call distribution**".
4. In the "**Label**" field, enter a label to apply to this ACD key.
5. In the "**Line**" field, select a line to apply Automatic call distribution. Valid values are **1** through **9**.
6. In the state fields, check (enable) or uncheck (disable) the "**idle**" state for this softkey.

### Programmable Keys

#### Note:

It is recommended you configure no more than a single ACD programmable key or Expansion Module key per IP phone.

7. Select from "**Key 1**" through "**Key 6**".
8. In the "**Line**" field, select a line to apply Automatic call distribution. Valid values are **1** through **9**.

### Expansion Module Keys

9. Select from "**Key 1**" through "**Key 36**" (M670i).  
or  
Select from "**Key 1**" through "**Key 60**" (M675i).
10. (M675i) In the "**Label**" field, enter a label to apply to this ACD key.
11. In the "**Line**" field, select a line to apply Automatic call distribution. Valid values are **1** through **9**.
12. Click **Save Settings**.

### Using the ACD Feature on your IP Phone

The ACD feature allows you to login to a phone queue in order to receive distributed calls on your IP phone. To login to a phone queue, you must preconfigure an ACD softkey, programmable key, or expansion module key on your IP Phone as described in the previous procedure.

Your Administrator sets up the queue that you access when you press the ACD Key. Contact your System Administrator for more information.

When you press the ACD Key, the phone prompts you to enter a User ID and Password to login into the queue. Once logged in, you can make your phone “available” or “unavailable” to take calls by pressing the Available/Unavailable Key ( ▼ ). The server monitors your IP phone status. When you set the IP phone to “available,” the server begins distributing calls to your phone. When you set the IP phone to “unavailable,” the server temporarily stops distributing calls to your phone.

The LED for the ACD Key shows the current status of your phone.

**ACD LED Table**

This LED changes when you log into the phone queue and are available to take calls. The LED changes again when you are busy with an active call. The table below shows the status of the LED as they may appear on your IP phone.


Phone Model	Status: Logged In and Available	Status: Unavailable	Logged Out
6735i	Solid Red LED √ icon	Blinking Red LED Blinking √ icon	No LED ∅ icon

**Using the ACD Key**


Use the following procedure to log into a phone queue from your IP phone.



1. Check with your Administrator to verify the queue linked to your ACD Key.
2. Press the **ACD** Key on your IP phone. The LCD displays the label of the ACD queue you are accessing.



The "User ID" and "Password" prompts displays.



3. Using the keypad, enter your User ID (phone number provided by your System Administrator).


4. Using the keypad, enter your Password (provided by your System Administrator) and press the **Log In** Key.

**Note:**


Use the **Backspace** key to move back a space and delete a character if required. Use the **Cancel** softkey to cancel the ACD login.

Your phone logs into the queue on the server.

5. You are logged into the queue and the following screen displays.



6. To allow your phone to be available in the queue, press the **Available** softkey. The following screen displays.



If your IP phone status is set to **"Available"** then the server begins to distribute phone calls from this queue to your IP phone. You must manually change the state to **"Available"** in order to start receiving calls.

7. To temporarily stop receiving calls, press the **Unavailable** softkey.

If you are on a call (or miss a call that has been distributed to your phone), your phone status automatically changes to **"Unavailable"**. Your phone remains in the **"Unavailable"** state until one of the following occurs:

- You use the IP Phone UI to manually switch the IP phone state back to "Available"
- or
- The availability "timer" for your IP phone expires. This only occurs if your Administrator has configured an auto-availability timer on your IP phone. Contact your System Administrator for more information.

8. To logout of the queue, press the **Log Out** softkey. The server no longer distributes phone calls to your IP phone.

## Directed Call Pickup/Group Call Pickup Keys

Aastra IP phones support the Directed Call Pickup (DCP) and Group Call Pickup (GCP) features.

The DCP/GCP feature allows you to intercept - or pickup - a call on a monitored extension. You can configure this feature using the Aastra Web UI to create a DCP or GCP softkey on the IP phone. When you configure a DCP softkey, you specify the extension that you want to monitor. Then, when the monitored extension receives a call, you press the DCP softkey to pick up the call. If the monitored extension receives multiple incoming calls simultaneously, the IP Phone UI displays a list of incoming calls. You select a call from this list, and are connected to the call.

When you configure a GCP softkey, you specify the ring group (for example, extensions 2200 - 2210) that you want to monitor for incoming calls. When an incoming call is received on any of these extensions, the Operator presses the GCP softkey and is connected to the call. If multiple incoming calls are received simultaneously, the Operator press the GCP softkey, selects an extension from a list, and presses the **Pickup** softkey to answer the call.

### Notes:

- Your System Administrator must configure the extension range for the Group Call Pickup feature. Contact your System Administrator for more information.
- DCP/GCP feature availability is dependant on your call manager. Contact your System Administrator for more information.

### Configuring Directed Call Pickup (DCP) Key



#### Aastra Web UI

Use the following procedure to configure Directed Call Pickup on the 6735i IP Phone. The procedure shows the softkey screens as an example.

1. Click on **Operation->Softkeys and XML**.  
or  
Click on **Operation->Programmable Keys**.  
or  
Click on **Operation->Expansion Module <N>**.

#### Softkeys Configuration

Key	Type	Label	Value	Line	Idle	Connected	Incoming	Outgoing	Busy
1	Directed Call Pickup	Test	2200	9	<input checked="" type="checkbox"/>				
2	None			1	<input checked="" type="checkbox"/>				
3	Line			5	<input checked="" type="checkbox"/>				
4	Empty			1	<input checked="" type="checkbox"/>				
5	Speeddial			1	<input checked="" type="checkbox"/>				
6	None			1	<input checked="" type="checkbox"/>				

#### Softkeys

2. Select from **"Key 1"** through **"Key 20"**.
3. In the **"Type"** field, select **Directed Call Pickup**.
4. In the **"Label"** field, enter a label to apply to this Directed Call Pickup key.
5. In the **"Value"** field, specify the extension you want to intercept when you press this softkey. For example: **2200**.
6. In the **"Line"** field, select the line for which to apply the Directed Call Pickup configuration. Valid values are **1** through **9**.
7. In the state fields, check (enable) or uncheck (disable) the states you want to apply to this softkey.

**Programmable Keys**

8. Select from "**Key 1**" through "**Key 6**".
9. In the "**Value**" field, specify the extension you want to intercept when you press this softkey. For example: **2200**.
10. In the "**Line**" field, select the line for which to apply the Directed Call Pickup configuration. Valid values are:
  - global
  - **1 through 9**

**Expansion Module Keys**

11. Select from "**Key 1**" through "**Key 36**" (M670i).  
or  
Select from "**Key 1**" through "**Key 60**" (M675i).
12. In the "**Value**" field, specify the extension you want to intercept when you press this softkey. For example: **2200**.
13. (M675i) In the "**Label**" field, enter a label to apply to this Directed Call Pickup key.
14. In the "**Line**" field, select the line for which to apply the Directed Call Pickup configuration. Valid values are:
  - global
  - **1 through 9**
15. Click **Save Settings**.

**Configuring Group Call Pickup (GCP) Key****Aastra Web UI**

Use the following procedure to configure Group Call Pickup on the 6735i IP Phone. The procedure shows the softkey screens as an example.

**Note:**

A ring group must be configured in order for a GCP key to function.

1. Click on **Operation->Softkeys and XML**.  
or  
Click on **Operation->Programmable Keys**.  
or  
Click on **Operation->Expansion Module <N>**.

**Softkeys Configuration**

Key	Type	Label	Value	Line	Idle	Connected	Incoming	Outgoing	Busy
1	Directed Call Pickup	Test	groupcallpickup	8	<input checked="" type="checkbox"/>				
2	None			1	<input checked="" type="checkbox"/>				
3	Line			5	<input checked="" type="checkbox"/>				
4	Empty			1	<input checked="" type="checkbox"/>				
5	Speedial			1	<input checked="" type="checkbox"/>				
6	None			1	<input checked="" type="checkbox"/>				

**Softkeys**

2. Select from "**Key 1**" through "**Key 20**".
3. In the "**Type**" field, select **Directed Call Pickup**.
4. In the "**Label**" field, enter a label to apply to this Group Call Pickup key.
5. In the "**Value**" field, enter **groupcallpickup**.
6. In the "**Line**" field, select the line for which to apply the Group Call Pickup configuration. Valid value are **1 through 9**.

7. In the state fields, check (enable) or uncheck (disable) the states you want to apply to this softkey.

### **Programmable Keys**

8. Select from "**Key 1**" through "**Key 6**".

9. In the "**Value**" field, specify the extension you want to intercept when you press this softkey. For example: **group-callpickup**.

10. In the "**Line**" field, select the line for which to apply the Directed Call Pickup configuration. Valid values are:

- global
- 1 through 9

### **Expansion Module Keys**

11. Select from "**Key 1**" through "**Key 36**" (M670i).

or

Select from "**Key 1**" through "**Key 60**" (M675i).

12. In the "**Value**" field, specify the extension you want to intercept when you press this softkey. For example: **group-callpickup**.

13. (M675i) In the "**Label**" field, enter a label to apply to this Group Call Pickup key.

14. In the "**Line**" field, select the line for which to apply the Directed Call Pickup configuration. Valid values are:

- global
- 1 through 9

15. Click **Save Settings**.

## Using Directed Call Pickup/Group Call Pickup

Use the following procedure for the DCP/GCP feature on your phone.



### IP Phone UI

#### Note:


Before using the DCP/GCP feature on your phone, you must first configure the DCP or GCP Key. You must identify the extension(s) or phone number(s) you want to monitor when configuring the key. See the previous procedures to configure a DCP or GCP Key

### Using Directed Call Pickup (DCP)

1. When the monitored extension receives a call, press the **DCP** Key to pick up the call.  
If the monitored extension receives multiple incoming calls simultaneously, the phone displays a list of incoming calls.
2. Use the ▲ and ▼ keys to scroll through the list to select an extension.
3. Press the **Pickup** Key for the extension you select.  
The call is answered.

### Using Group Call Pickup (GCP)

1. If any of the monitored group of extensions receives a call, press the **GCP** Key.  
The call is answered.  
If the monitored group of extensions receives multiple incoming calls simultaneously, the phone displays a list of incoming calls.
2. Use the ▲ and ▼ keys to scroll through the list to select an extension.
3. Press the **Pickup** Key for the extension you select.  
The call is answered.



## XML Key

The 6735i IP phone has a feature you can enable called "**XML**" (Extensible Markup Language). XML is a markup language much like HTML. Your System Administrator can create customized XML menu services and load them to your IP phone. These services include things like weather and traffic reports, contact information, company info, stock quotes, or custom call scripts. You can configure XML using the Aastra Web UI only.


**Note:**

The XML services must be set up by your System Administrator before you can use the key. Contact your System Administrator for more information.

On the 6735i IP phone, you can access the XML applications from the IP Phone UI in two ways:

- Via the "**Services**" menu
- Via an XML key

By default, the Services key is the first key on the top, left keys.



Using the Aastra Web UI, you can configure a key to access XML applications. Under **Operations->Softkeys and XML**, **Operations->Programmable Keys**, or **Operations->Expansion Module**, you can assign a key the type "XML".

You must also specify an XML URI and a Services label using the following XML fields:

- XML Application URI
- XML Application Title

The XML Application URI is the URI loaded by your phone. The phone performs an HTTP GET. Contact your System Administrator for the applicable XML URI to enter in the "XML Application URI" field.

The XML Application Title is the label that displays beside the XML softkey on your phone. If you use the Services key to access the XML features, the "XML Application Title" is the label that displays on the Services Menu in the IP Phone UI.

**Note:**

Contact your System Administrator for the applicable URI to enter in this field.

After the XML application is applied, you can use the IP Phone UI to press the Services key and access the XML services.

## Configuring XML Services



Aastra Web UI

1. Click on **Operation->Softkeys and XML.**  
or  
Click on **Operation->Programmable Keys.**  
or  
Click on **Operation->Expansion Module <N>.**

## Softkeys Configuration

Key	Type	Label	Value	Line	Idle	Connected	Incoming	Outgoing	Busy
1	Services	Test		1	<input checked="" type="checkbox"/>				
2	Pickup			1	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>
3	Speeddial			1	<input checked="" type="checkbox"/>				
4	None			1	<input type="checkbox"/>				
5	None			1	<input type="checkbox"/>				
6	None			1	<input type="checkbox"/>				
7	None			1	<input type="checkbox"/>				
8	None			1	<input type="checkbox"/>				
9	None			1	<input type="checkbox"/>				
10	None			1	<input type="checkbox"/>				
11	None			1	<input type="checkbox"/>				
12	None			1	<input type="checkbox"/>				
13	None			1	<input type="checkbox"/>				
14	None			1	<input type="checkbox"/>				
15	None			1	<input type="checkbox"/>				
16	None			1	<input type="checkbox"/>				
17	None			1	<input type="checkbox"/>				
18	None			1	<input type="checkbox"/>				
19	None			1	<input type="checkbox"/>				
20	None			1	<input type="checkbox"/>				

## Services

XML Application URI:	<input "="" type="text" value="http://216.94.98.90/xml/menu/mymenu.php?source="/>
XML Application Title:	<input type="text" value="XML Menu"/>
BLF List URI:	<input type="text"/>

## Softkeys

2. Select from **"Key 1"** through **"Key 20"**.
3. In the **"Type"** field, select **"Services"**.
4. In the **"Label"** field, enter a label for the Services key.
5. In the state fields, check (enable) or uncheck (disable) the states you want to apply to this softkey.
6. In the **"XML Application URI"** field, enter an application URI(s).  
**Note:**  
Contact your System Administrator for the appropriate value(s) to enter in the "XML Application URI" field.
7. In the **"XML Application Title"** field, enter the title of the service. This title appears in the Services Menu after pressing the **Services** key. If multiple XML applications are specified in the **XML Application URI** field, a list of applications displays after pressing the **Services** key.

### **Programmable Keys**

**8.** Select from "**Key 1**" through "**Key 6**".

**9.** In the "**Type**" field, select "**Services**".

**10.** In the "**XML Application URI**" field, enter an application URI(s).

**Note:**

Contact your System Administrator for the appropriate value(s) to enter in the "XML Application URI" field.

**11.** In the "**XML Application Title**" field, enter the title of the service. This title appears in the Services Menu after pressing the **Services** key. If multiple XML applications are specified in the **XML Application URI** field, a list of applications displays after pressing the **Services** key.

### **Expansion Module Keys**

**12.** Select from "**Key 1**" through "**Key 36**" (M670i).

or

Select from "**Key 1**" through "**Key 60**" (M675i).

**13.** In the "**Type**" field, select "**Services**".

**14.** (M675i) In the "**Label**" field, enter a label for the Services key.

**15.** In the "**XML Application URI**" field, enter an application URI(s).

**Note:**

Contact your System Administrator for the appropriate value(s) to enter in the "XML Application URI" field.

**16.** In the "**XML Application Title**" field, enter the title of the service. This title appears in the Services Menu after pressing the **Services** key. If multiple XML applications are specified in the **XML Application URI** field, a list of applications displays after pressing the **Services** key.

**17.** Click **Save Settings**.

## Configuring an XML Key



Aastra Web UI

Use the following procedure to configure an XML key on the 6735i IP Phone. The procedure shows the softkey screen as an example.

1. Click on **Operation->Softkeys and XML**.  
or  
Click on **Operation->Programmable Keys**.  
or  
Click on **Operation->Expansion Module <N>**.

### Softkeys Configuration

Key	Type	Label	Value	Line	Idle	Connected	Incoming	Outgoing	Busy
1	XML	Test	http://10.70.3.7/xml/m	1	<input checked="" type="checkbox"/>				
2	Pickup			1	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>
3	Speeddial			1	<input checked="" type="checkbox"/>				
4	None			1	<input type="checkbox"/>				
5	None			1	<input type="checkbox"/>				
6	None			1	<input type="checkbox"/>				
7	None			1	<input type="checkbox"/>				
8	None			1	<input type="checkbox"/>				
9	None			1	<input type="checkbox"/>				
10	None			1	<input type="checkbox"/>				
11	None			1	<input type="checkbox"/>				
12	None			1	<input type="checkbox"/>				
13	None			1	<input type="checkbox"/>				
14	None			1	<input type="checkbox"/>				
15	None			1	<input type="checkbox"/>				
16	None			1	<input type="checkbox"/>				
17	None			1	<input type="checkbox"/>				
18	None			1	<input type="checkbox"/>				
19	None			1	<input type="checkbox"/>				
20	None			1	<input type="checkbox"/>				

### Services

XML Application URI:	http://216.94.98.90/xml/menu/mymenu.php?source=
XML Application Title:	XML Menu
BLF List URI:	

### Softkeys

2. Select from **"Key 1"** through **"Key 20"**.
3. In the **"Type"** field, select **"XML"**.
4. In the **"Label"** field, enter a label to apply to this key.
5. In the **"Value"** field, enter a URI(s) to apply to this key.  
**Note:**  
Contact your System Administrator for the appropriate value(s) to enter in the "Value" field.
6. In the state fields, check (enable) or uncheck (disable) the states you want to apply to this softkey.

7. In the "**XML Application URI**" field, enter the applicable URI(s).

**Note:**

Contact your System Administrator for the appropriate value(s) to enter in the "XML Application URI" field.

8. In the "**XML Application Title**" field, enter the title of the service. This title appears on the phone's LCD after pressing the **XML** key. If multiple XML applications are specified in the **XML Application URI** field, a list of applications displays after pressing the XML key.

**Programmable Keys**

9. Select from "**Key 1**" through "**Key 6**".

10. In the "**Type**" field, select "**XML**".

11. In the "**Value**" field, enter a URI(s) to apply to this key.

**Note:**

Contact your System Administrator for the appropriate value(s) to enter in the "Value" field.

12. In the "**XML Application URI**" field, enter the applicable URI(s).

**Note:**

Contact your System Administrator for the appropriate value(s) to enter in the "XML Application URI" field.

13. In the "**XML Application Title**" field, enter the title of the service. This title appears on the phone's LCD after pressing the **XML** key. If multiple XML applications are specified in the **XML Application URI** field, a list of applications displays after pressing the XML key.

**Expansion Module Keys**

14. Select from "**Key 1**" through "**Key 36**" (M670i).

or

Select from "**Key 1**" through "**Key 60**" (M675i).

15. In the "**Type**" field, select "**XML**".

16. In the "**Value**" field, enter a URI(s) to apply to this key.

**Note:**

Contact your System Administrator for the appropriate value(s) to enter in the "Value" field.

17. (M675i) In the "**Label**" field, enter a label to apply to this key.

18. In the "**XML Application URI**" field, enter the applicable URI(s).

**Note:**

Contact your System Administrator for the appropriate value(s) to enter in the "XML Application URI" field.

19. In the "**XML Application Title**" field, enter the title of the service. This title appears on the phone's LCD after pressing the **XML** key. If multiple XML applications are specified in the **XML Application URI** field, a list of applications displays after pressing the XML key.

20. Click **Save Settings**.

### Accessing the XML Service


After an XML application(s) has been saved to your IP phone, and either the Services Menu or a key have been configured to access the XML applications, the customized service is ready for you to use.



#### IP Phone UI

#### From the Services Menu

Use the following procedure to access XML applications from the Services Menu. Use the following illustration as a reference.



1. Press the **Services** key.
2. Use the ▲ and ▼ to scroll through the items.
3. For menu and directory services, select a service to display the information for that customized service. Message services display to the screen after pressing the softkey or programmable key. For user input services, follow the prompts as appropriate.
4. To exit from the "**Services**" menu, press the Services key again.

#### From an XML Key

1. Press the XML key on the 6735i phone. A "**Custom Features**" screen displays or the title you specified.
2. Use the ▲ and ▼ to scroll through the customized features.
3. For menu and directory services, select a service to display the information for that customized service. Message services display to the screen after pressing the programmable key. For user input services, follow the prompts as appropriate.
4. To exit from the "**Customized Features**" screen, press the XML key again.

## Flash Key

You can set a key to generate a flash event when it is pressed on the 6735i. You do this by setting the key to **"flash"**. The IP phone generates flash events only when a call is connected and there is an active RTP stream (for example, when the call is not on hold).

### Configuring a Flash Key



#### Aastra Web UI

Use the following procedure to configure a Flash key on the 6735i IP Phone. The procedure shows the softkey screen as an example.

1. Click on **Operation->Softkeys and XML**.  
or  
Click on **Operation->Programmable Keys**.  
or  
Click on **Operation->Expansion Module <N>**.

#### Softkeys Configuration

Key	Type	Label	Value	Line	Idle	Connected	Incoming	Outgoing	Busy
1	Flash	Test		1	<input checked="" type="checkbox"/>				
2	Line			5	<input checked="" type="checkbox"/>				
3	Park			1	<input checked="" type="checkbox"/>				
4	Pickup			1	<input checked="" type="checkbox"/>				
5	None			1	<input checked="" type="checkbox"/>				
6	None			1	<input checked="" type="checkbox"/>				

#### Softkeys

2. Select from **"Key 1"** through **"Key 20"**.
3. In the **"Type"** field, select **"Flash"**.
4. In the **"Label"** field, enter a label to display on the phone for the key.

#### Programmable Keys

5. Select from **"Key 1"** through **"Key 6"**.
6. In the **"Type"** field, select **"Flash"**.

#### Expansion Module Keys

7. Select from **"Key 1"** through **"Key 36"** (M670i).  
or  
Select from **"Key 1"** through **"Key 60"** (M675i).
8. In the **"Type"** field, select **"Flash"**.
9. (M675i) In the **"Label"** field, enter a label to display on the phone for the key.
10. Click **Save Settings**.

## Sprecode Key

You can set a key to automatically activate specific services offered by the server by setting a key to "**Sprecode**". For example, if the sprecode value of \*82 is configured, then by pressing the key, \*82 automatically activates a service provided by the server. The value you enter for this field is dependent on the services provided by the server. Contact your System Administrator for information about available services.

### Configuring a Sprecode Key



#### Aastra Web UI

Use the following procedure to configure a Sprecode key on the 6735i IP Phone. The procedure shows the softkey screen as an example.

1. Click on **Operation->Softkeys and XML**.  
or  
Click on **Operation->Programmable Keys**.  
or  
Click on **Operation->Expansion Module <N>**.

#### Softkeys Configuration

Key	Type	Label	Value	Line	Idle	Connected	Incoming	Outgoing	Busy
1	Sprecode	Test		1	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
2	None			5	<input type="checkbox"/>				
3	Park			1	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
4	Pickup			1	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>
5	Line			5	<input checked="" type="checkbox"/>				
6	None			1	<input type="checkbox"/>				

#### Softkeys

2. Select from "**Key 1**" through "**Key 20**".
3. In the "**Type**" field, select "**Sprecode**".
4. In the "**Label**" field, enter a label to display on the IP phone for this key.
5. In the "**Value**" field, enter the appropriate value for accessing specific services from the server.  
**Note:**  
For values to enter in this field, contact your System Administrator.
6. In the state fields, check (enable) or uncheck (disable) the "**Connected**" state for this softkey.

#### Programmable Keys

7. Select from "**Key 1**" through "**Key 6**".
8. In the "**Type**" field, select **Sprecode**.
9. In the "**Value**" field, enter the appropriate value for accessing specific services from the server.  
**Note:**  
For values to enter in this field, contact your System Administrator.

#### Expansion Module Keys

10. Select from "**Key 1**" through "**Key 36**" (M670i).  
or  
Select from "**Key 1**" through "**Key 60**" (M675i).
11. In the "**Type**" field, select **Sprecode**.
12. (M675i) In the "**Label**" field, enter a label to display on the IP phone for this key.

13. In the "Value" field, enter the appropriate value for accessing specific services from the server.

**Note:**  
For values to enter in this field, contact your System Administrator.

14. Click **Save Settings**.

## Park/Pickup Keys

The 6735i phone has a park and pickup call feature that allows you to park a call and pickup a call when required. The IP phones support the Park/Pickup feature on the Asterisk, BroadWorks, Sylanro, and ININ servers.

The park/pickup feature performs as follows:

- When a call comes in and you pickup the handset, you can press the applicable "Park" key to park the call.
- After the call is parked, you can press the "Pickup" key, followed by the applicable value to pickup the call.

Administrators can configure the park and pickup keys for any line using the configuration files or the Aastra Web UI.

Users can make changes to customize the label of the park/pick up keys using the Web UI.

### Configuring Park/Pickup Keys



Use the following procedure to configure park/pickup on the 6735i phone:

1. Click on **Operation->Softkeys and XML**.  
or  
Click on **Operation->Programmable Keys**.  
or  
Click on **Operation->Expansion Module <N>**.

#### Softkeys Configuration

Key	Type	Label	Value	Line	Idle	Connected	Incoming	Outgoing	Busy
1	Park	Test		1	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
2	Pickup	Test1		1	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>
3	None			1	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
4	None			1	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
5	None			1	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
6	None			1	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>

#### Softkeys

2. Select from "Key 1" through "Key 20".
3. In the "Type" field, select **Park**.
4. In the "Label" field, enter a label for the park softkey.  
**Note:**  
The "Value" and "Line" fields are configured by the Administrator.
5. In the state fields, check (enable) or uncheck (disable) the "Connected" state for this softkey.
6. Select from "Key 1" through "Key 20".
7. In the "Type" field, select **Pickup**
8. In the "Label" field, enter a label for the pickup softkey.  
**Note:**  
The "Value" and "Line" fields are configured by the Administrator.

9. In the state fields, check (enable) or uncheck (disable) the states you want to apply to this softkey.
10. Click **Save Settings**.
11. Click on **Reset**, then click **Restart** to restart the IP phone and apply the changes.

#### *Programmable Keys*

12. Select from "**Key 1**" through "**Key 6**".
13. In the "**Type**" field, select **Park**.
14. In the "**Value**" field, enter the appropriate value for accessing specific services from the server.  
**Note:**  
The "**Value**" and "**Line**" fields are configured by the Administrator.
15. Select from "**Key 1**" through "**Key 6**".
16. In the "**Type**" field, select **Pickup**.
17. In the "**Value**" field, enter the appropriate value for accessing specific services from the server.  
**Note:**  
The "**Value**" and "**Line**" fields are configured by the Administrator.
18. Click **Save Settings**.
19. Click on **Reset**, then click **Restart** to restart the IP phone and apply the changes.

#### *Expansion Module Keys*

20. Select from "**Key 1**" through "**Key 36**" (M670i).  
or  
Select from "**Key 1**" through "**Key 60**" (M675i).
21. In the "**Type**" field, select **Park**.
22. (M675i) In the "**Label**" field, enter a label to display on the IP phone for this key.
23. In the "**Value**" field, enter the appropriate value for accessing specific services from the server.  
**Note:**  
The "**Value**" and "**Line**" fields are configured by the Administrator.
24. Select from "**Key 1**" through "**Key 36**" (M670i).  
or  
Select from "**Key 1**" through "**Key 60**" (M675i).
25. In the "**Type**" field, select **Pickup**.
26. (M675i) In the "**Label**" field, enter a label to display on the IP phone for this key.
27. In the "**Value**" field, enter the appropriate value for accessing specific services from the server.  
**Note:**  
The "**Value**" and "**Line**" fields are configured by the Administrator.
28. Click **Save Settings**.
29. Click on **Reset**, then click **Restart** to restart the IP phone and apply the changes.

#### *Using the Park Call/Pickup Parked Call Feature*

Use the following procedure on the IP phone to park a call and pick up a parked call.

##### *Park a Call*

1. While on a live call, press the "**Park**" key.
2. Perform the following for your specific server:

### For Asterisk Server

Server announces the extension number where the call has been parked. Once the call is parked, press the  key to complete parking.

### For BroadWorks Server

After you hear the greeting from the Call-Park server, enter the extension where you want to park the call.

### For Sylanro Server

Enter the extension number where you want to park the call, followed by "#" key.

### For ININ Server

Enter the extension number where you want to park the call, followed by "#" key.

If the call is parked successfully, the response is either a greeting voice confirming that the call was parked, or a hang up occurs. The parked call party hears music on hold.

**3.** If the call fails, you can pick up the call (using the next procedure) and press the **"Park"** key again to retry step 2.

### *Pickup a Parked Call*

1. Pick up the handset on the phone.
2. Enter the extension number where the call was parked.
3. Press the **"Pickup"** key.  
If the call pick up is successful, you are connected with the parked call.

## Last Call Return (lcr) Key *(Sylantro Servers only)*

Using the Aastra Web UI, you can configure the "Last call return" (lcr) function on a key. This feature is for Sylantro servers only.

### How it works

If you configure "lcr" on a key, and a call comes into your phone, after you are finished with the call and hang up, you can press the key configured for "lcr" and the phone dials the last call you received. When you configure an "lcr" key, the label "LCR" displays next to that key on the IP phone. When the Sylantro server detects an "lcr" request, it translates this request and routes the call to the last caller.

### Configuring a Last Call Return Key



#### Aastra Web UI

Use the following procedure to configure a Last Call Return key on the 6735i IP Phone. The procedure shows the softkey screen as an example.

1. Click on **Operation->Softkeys and XML.**  
or  
Click on **Operation->Programmable Keys.**  
or  
Click on **Operation->Expansion Module <N>.**

#### Softkeys Configuration

Key	Type	Label	Value	Line	Idle	Connected	Incoming	Outgoing	Busy
1	Last Call Return			4	<input checked="" type="checkbox"/>				
2	Speeddial			1	<input type="checkbox"/>				
3	Park			1	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
4	Pickup			1	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>
5	None			1	<input checked="" type="checkbox"/>				
6	None			1	<input checked="" type="checkbox"/>				

#### Softkeys

2. Select from "Key 1" through "Key 20".
3. In the "Type" field, select **Last Call Return.**
4. In the "Line" field, select the line you want to apply to this key.  
Valid values are 1 through 9.
5. In the state fields, check (enable) or uncheck (disable) the states you want to apply to this softkey.

#### Programmable Keys

6. Select from "Key 1" through "Key 6".
7. In the "Type" field, select **Last Call Return.**
8. In the "Line" field, select the line you want to apply to this key.  
Valid values are 1 through 9.

#### Expansion Module Keys

9. Select from "Key 1" through "Key 36" (M670i).  
or  
Select from "Key 1" through "Key 60" (M675i).
10. In the "Type" field, select **Last Call Return.**

11. In the "Line" field, select the line you want to apply to this key.  
Valid values are 1 through 9.

12. Click **Save Settings**.

## Call Forward Key

Using the Aastra Web UI, you can configure the **Call Forward** (CFWD) function on a softkey, programmable key, or expansion module key. Use call forwarding when you want a specific account on your phone to be forwarded to another number when your phone is in the busy state or the no answer state, or both. Pressing the Call Forward key on the phone accesses the Call Forward Menus. The menus that display are dependant on the Call Forward mode (**Account** (default), **Phone**, or **Custom**) configured for the phone.

For more information about call forwarding and call forwarding modes, see "Call Forward Account-Based Configuration" on page 152.

### Configuring a Call Forward Key



1. Click on **Operation->Softkeys and XML**.  
or  
Click on **Operation->Programmable Keys**.  
or  
Click on **Operation->Expansion Module <N>**.

#### Softkeys Configuration

Key	Type	Label	Value	Line	Idle	Connected	Incoming	Outgoing	Busy
1	Call Forward			1	<input checked="" type="checkbox"/>				
2	Speeddial			1	<input type="checkbox"/>				
3	Park			1	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
4	Pickup			1	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>
5	None			1	<input checked="" type="checkbox"/>				
6	None			1	<input checked="" type="checkbox"/>				

#### Softkeys

2. Select from "Key 1" through "Key 20".
3. In the "Type" field, select **Call Forward**.
4. In the state fields, check (enable) or uncheck (disable) the states you want to apply to this softkey.

#### Programmable Keys

5. Select from "Key 1" through "Key 6".
6. In the "Type" field, select **Call Forward**.

#### Expansion Module Keys

7. Select from "Key 1" through "Key 36" (M670i).  
or  
Select from "Key 1" through "Key 60" (M675i).
8. In the "Type" field, select **Call Forward**.
9. Click **Save Settings**.

## BLF/Xfer

The BLF key allows one or more extensions to be monitored, and once there is any state change with those extensions, the key shows the status of the monitored lines. The Xfer key allows a call to be transferred to other recipients blindly or consultatively. The BLF/Xfer key combines the BLF and Xfer key's functionality together allowing the user to transfer calls or use BLF with one key.

### Note:

It is recommended that you enable the "Switch UI Focus to Ringing Line" parameter when using the BLF/Xfer feature. For more information about this parameter, see "Switch UI Focus to Ringing Line" on page 173.

### BLF/Xfer Key Requirements and Functionality

- **BLF/Xfer and BLF**

A BLF/Xfer key can be configured for subscribing to an extension and monitor the status of the extension, similar to the BLF key functionality. Changes of the state of the monitored extension are indicated by a LED / Icon.

- **BLF/Xfer and Blind Transfer Calls**

When the focused line is in the "Connected" state, pressing the BLF/Xfer key transfers the call to the extension unconditionally, disregarding the status of the monitored extension.

If transferring a call to an extension fails, a message "Transfer Failed" displays on the phone, and you can reconnect the call (get the call back) by pressing the line key again.

- **BLF/Xfer and Call Forward**

When the focused line is in the "Ringing" state, pressing the BLF/Xfer key forwards the call to the extension unconditionally, disregarding the status of the monitored extension.

- **BLF/Xfer and Speed Dial**

When the focused line and the monitored extension are idle, pressing the BLF/Xfer key causes the phone to go offhook and dial the number of the extension.

## Configuring a BLF/Xfer Key



Aastra Web UI

1. Click on **Operation->Softkeys and XML.**  
or  
Click on **Operation->Programmable Keys.**  
or  
Click on **Operation->Expansion Module <N>.**

## Softkeys Configuration

Key	Type	Label	Value	Line	Idle	Connected	Incoming	Outgoing	Busy
1	BLF/Xfer	Test	35	3	<input checked="" type="checkbox"/>				
2	Speeddial			1	<input type="checkbox"/>				
3	Park			1	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
4	Pickup			1	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>
5	None			1	<input checked="" type="checkbox"/>				
6	None			1	<input checked="" type="checkbox"/>				

## Softkeys

2. Select from **"Key 1"** through **"Key 20"**.
3. In the **"Type"** field, select **BLF/Xfer**.
4. In the **"Value"** field, enter the monitored extension or the extension to transfer calls to (for example, **"35"**).
5. In the **"Line"** field, select the line for which you want to use the key functionality.  
Valid values are:
  - global
  - 1 through 9
6. In the state fields, check (enable) or uncheck (disable) the states you want to apply to this softkey.

## Programmable Keys

7. Select from **"Key 1"** through **"Key 6"**.
8. In the **"Type"** field, select **BLF/Xfer**.
9. In the **"Value"** field, enter the monitored extension or the extension to transfer calls to (for example, **"35"**).
10. In the **"Line"** field, select the line for which you want to use the key functionality.  
Valid values are:
  - global
  - 1 through 9

## Expansion Module Keys

11. Select from **"Key 1"** through **"Key 36"** (M670i).  
or  
Select from **"Key 1"** through **"Key 60"** (M675i).
12. In the **"Type"** field, select **BLF/Xfer**.
13. (M675i) In the **"Label"** field, enter a label for the BLF/Xfer key.
14. In the **"Value"** field, enter the monitored extension or the extension to transfer calls to (for example, **"35"**).

15. In the “**Line**” field, select the line for which you want to use the key functionality.

Valid values are:

- global
- 1 through 9

16. Click **Save Settings**.

## Speeddial/Xfer

The Speed Dial key allows a number to be dialed quickly by pressing one key configured for speed dialing. The Xfer key allows a call to be transferred to other recipients blindly or consultatively. The Speeddial/Xfer key combines the Speed Dial and Xfer key's functionality together allowing the user to transfer calls or use Speeddial with one key.

### Note:

It is recommended that you enable the “Switch UI Focus to Ringing Line” parameter when using the Speed Dial/Xfer feature. For more information about this parameter, see “Switch UI Focus to Ringing Line” on page 173.

### Speed Dial/Xfer Key Requirements and Functionality

The Speed Dial/Xfer key has the following capabilities:

- **Speeddial/Xfer and Speed Dial**

When the phone is in the “Idle” state, pressing the Speeddial/Xfer key causes the phone to go offhook and dial the predefined extension.

- **Speeddial/Xfer and Blind Transfer**

When the phone is connected to a call, pressing the Speeddial/Xfer key blind transfers the call to the predefined target. If transferring a call fails, a message “Transfer Failed” displays, and you can reconnect the call (get the call back) by pressing the line key again.

- **Speeddial/Xfer and Call Forward**

When the phone is in the “Ringing” state, pressing the Speeddial/Xfer key forwards the call to the predefined extension.

## Configuring a Speeddial/Xfer Key



Aastra Web UI

1. Click on **Operation->Softkeys and XML.**  
or  
Click on **Operation->Programmable Keys.**  
or  
Click on **Operation->Expansion Module <N>.**

### Softkeys Configuration

Key	Type	Label	Value	Line	Idle	Connected	Incoming	Outgoing	Busy
1	Speeddial/Xfer	Test	5551212	4	<input checked="" type="checkbox"/>				
2	None			1	<input type="checkbox"/>				
3	BLF			1	<input checked="" type="checkbox"/>				
4	Flash			1	<input type="checkbox"/>				
5	None			1	<input type="checkbox"/>				
6	None			1	<input type="checkbox"/>				

### Softkeys

2. Select from "Key 1" through "Key 20".
3. In the "Type" field, select **Speed dial/Xfer.**
4. In the "Label" field, enter a label for the Speeddial/Xfer key.
5. In the "Value" field, enter the speed dial extension or the extension to transfer calls to (for example, "5551212").
6. In the "Line" field, select the line for which you want to use the key functionality.  
Valid values are:
  - global
  - 1 through 9
7. In the state fields, check (enable) or uncheck (disable) the states you want to apply to this softkey.

### Programmable Keys

8. Select from "Key 1" through "Key 6".
9. In the "Type" field, select **Speeddial/Xfer.**
10. In the "Value" field, enter the speed dial extension or the extension to transfer calls to (for example, "5551212").
11. In the "Line" field, select the line for which you want to use the key functionality.  
Valid values are:
  - global
  - 1 through 9

### Expansion Module Keys

12. Select from "Key 1" through "Key 36" (M670i).  
or  
Select from "Key 1" through "Key 60" (M675i).
13. In the "Type" field, select **Speeddial/Xfer.**
14. (M675i) In the "Label" field, enter a label for the Speeddial/Xfer key.
15. In the "Value" field, enter the speed dial extension or the extension to transfer calls to (for example, "5551212").

16. In the "Line" field, select the line for which you want to use the key functionality.

Valid values are:

- global
- 1 through 9

17. Click **Save Settings**.

## Speeddial/Conf

The 6735i allows you to configure a softkey or programmable key or expansion module key to be used as a speed dial conference key (**Speeddial/Conf** key) while remaining in the current call. This key allows a user on a call to conference another party at a pre-defined number while remaining in the call.

For example, while on an active call, a user can use the Speeddial/Conf key to dial a recording service and have the resulting conference recorded.

### Note:

If currently in a conference, the Speeddial/Conf key is disabled on the active call.

If you configure a softkey or programmable key or expansion module key as a **Speeddial/Conf** key and you press this key while on an active call, the focused line changes to the dialing line. A **Cancel** softkey displays on the phone allowing you to abort the conference speed dial if required. The message "Ringing..." displays below the number when the far end is ringing. The message "Conf. Unavailable" briefly displays when a conference is already in progress. The active call is not put on hold when the speed dial number is dialed.

### Note:

This feature is not compatible with centralized conferencing.

## Configuring a Speeddial/Conf Key



Aastra Web UI

1. Click on **Operation->Softkeys and XML**.

or

Click on **Operation->Programmable Keys**.

or

Click on **Operation->Expansion Module <N>**.

### Softkeys Configuration

Key	Type	Label	Value	Line	Idle	Connected	Incoming	Outgoing	Busy
1	Speeddial/Conf	Test	5551212	5	<input checked="" type="checkbox"/>				
2	None			1	<input type="checkbox"/>				
3	BLF			1	<input checked="" type="checkbox"/>				
4	Flash			1	<input type="checkbox"/>				
5	None			1	<input type="checkbox"/>				
6	None			1	<input type="checkbox"/>				

### Softkeys

2. Select from "Key 1" through "Key 20".

3. In the "Type" field, select **Speeddial/Conf**.

4. In the "Label" field, enter a label for the Speeddial/Conf key.

5. In the "Value" field, enter the speed dial extension or the extension to add to the conference (for example, "5551212").
6. In the "Line" field, select the line for which you want to use the key functionality.  
Valid values are:
  - global
  - 1 through 9
7. In the state fields, check (enable) or uncheck (disable) the states you want to apply to this softkey.

#### **Programmable Keys**


8. Select from "Key 1" through "Key 6".
9. In the "Type" field, select **Speeddial/Conf**.
10. In the "Value" field, enter the speed dial extension or the extension to add to the conference (for example, "5551212").
11. In the "Line" field, select the line for which you want to use the key functionality.  
Valid values are:
  - global
  - 1 through 9

#### **Expansion Module Keys**

12. Select from "Key 1" through "Key 36" (M670i).  
or  
Select from "Key 1" through "Key 60" (M675i).
13. In the "Type" field, select **Speeddial/Conf**.
14. (M675i) In the "Label" field, enter a label for the Speeddial/Conf key.
15. In the "Value" field, enter the speed dial extension or the extension to add to the conference (for example, "5551212").
16. In the "Line" field, select the line for which you want to use the key functionality.  
Valid values are:
  - global
  - 1 through 9
17. Click **Save Settings**.

## Services Key

By default, the 6735i has a Services key configured on key 1 of the top set of keys. However, you can use any key to configure a "Services" key.



The Services key accesses enhanced features and services provided by third parties. Using the "Services" key, you can:

- Select customized (XML) features
- Utilize a Caller List
- Utilize a Directory
- Utilize Voicemail

### Note:

Other than the Services Menu, you can also configure the Caller List and Directory List on separate keys.

The XML customized services are created and provided by your System Administrator through the diverse web based language of XML. Availability of these services depends on your phone system or service provider.

### Reference

For more information about XML, Caller List, Directory, and Voicemail, see the following:

- "XML Key" on [page 83](#)
- "Callers List" on [page 143](#)
- "Directory List" on [page 133](#)
- "Voicemail" on [page 167](#)

### Note:

Your System Administrator can create a custom Services key for your application. For more information about custom Services, see ["Customizable Callers List Key and Services Key"](#) on [page 186](#).

## Configuring a Services Key



Aastra Web UI

Use the following procedure to configure a Services key on the 6735i IP Phone. The procedure shows the programmable key screen as an example.

### Note:

By default, the **Services** key is Key 1 on the Programmable keys.

1. Click on **Operation->Softkeys and XML**.  
or  
Click on **Operation->Programmable Keys**.  
or  
Click on **Operation->Expansion Module <N>**.

### Programmable Keys Configuration

Key	Type	Value	Line
1	Services		global
2	Directory		1
3	Callers List		1
4	Icom		global
5	None		1
6	None		1

### Softkeys

2. Select from "**Key 1**" through "**Key 20**".
3. In the "**Type**" field, select **Services**.
4. In the "**Label**" field, enter a label to apply to this key.
5. In the state fields, check (enable) or uncheck (disable) the states you want to apply to this softkey.

### Programmable Keys


6. Select from "**Key 1**" through "**Key 6**".
7. In the "**Type**" field, select **Services**.

### Expansion Module Keys

8. Select from "**Key 1**" through "**Key 36**" (M670i).  
or  
Select from "**Key 1**" through "**Key 60**" (M675i).
9. In the "**Type**" field, select **Services**.
10. (M675i) In the "**Label**" field, enter a label to apply to this key.
11. Click **Save Settings**.

## Directory Key

By default, the 6735i has a Directory key configured on key 2 of the top set of keys. However, using the Aastra Web UI, you can assign the Directory key to any key on the top or bottom keys on the phone.



The "Directory List" feature allows you to store frequently used names and numbers on the phone. You can also dial directly from a directory entry.

You can use the Directory key to access a Directory List which contains a customized list of names with phone numbers and labels.

In addition to creating a Directory key, you can also download a Directory List to your PC if required using the Aastra Web UI.

### Reference

For more information about the Directory List, see ["Directory List"](#) on [page 133](#).

## Configuring a Directory Key



Aastra Web UI

Use the following procedure to configure a Directory key on the 6735i IP Phone. The procedure shows the programmable key screen as an example.

### Note:

By default, the **Directory** key is Key 2 on the Programmable keys.

1. Click on **Operation->Softkeys and XML**.  
or  
Click on **Operation->Programmable Keys**.  
or  
Click on **Operation->Expansion Module <N>**.

### Programmable Keys Configuration

Key	Type	Value	Line
1	Services		global
2	Directory		1
3	Callers List		1
4	Icom		global
5	None		1
6	None		1

### Softkeys

2. Select from "**Key 1**" through "**Key 20**".
3. In the "**Type**" field, select **Directory**.
4. In the "**Label**" field, enter a label to apply to this key.
5. In the state fields, check (enable) or uncheck (disable) the states you want to apply to this softkey.

### Programmable Keys


6. Select from "**Key 1**" through "**Key 6**".
7. In the "**Type**" field, select **Directory**.

### Expansion Module Keys

8. Select from "**Key 1**" through "**Key 36**" (M670i).  
or  
Select from "**Key 1**" through "**Key 60**" (M675i).
9. In the "**Type**" field, select **Directory**.
10. (M675i) In the "**Label**" field, enter a label to apply to this key.
11. Click **Save Settings**.

## Callers List Key

By default, the 6735i has a Callers List key configured on key 3 of the top set of keys. However, using the Aastra Web UI, you can assign the Callers List key to any key on the top or bottom keys on the phone.



The Callers list is a stored log of your incoming calls. You can use the Callers List key to access a list of callers that called your phone.

**Note:**

Your System Administrator can create a custom Callers List XML application allowing you to access the Callers List via an XML Key instead of the Callers List Key. This allows you to configure the Callers List Key with other functions if required. Contact your System Administrator for more information.

**Reference**

For more information about the Callers List, see [“Callers List”](#) on page 143.

## Configuring a Callers List Key



### Aastra Web UI

Use the following procedure to configure a Callers List key on the 6735i IP Phone. The procedure shows the programmable key screen as an example.

#### Note:

By default, the **Callers List** key is Key 3 on the Programmable keys.

1. Click on **Operation->Softkeys and XML.**  
or  
Click on **Operation->Programmable Keys.**  
or  
Click on **Operation->Expansion Module <N>.**

### Programmable Keys Configuration

Key	Type	Value	Line
1	Services		global
2	Directory		1
3	Callers List		1
4	Icom		global
5	None		1
6	None		1

#### Softkeys

2. Select from "**Key 1**" through "**Key 20**".
3. In the "**Type**" field, select **Callers List**.
4. In the "**Label**" field, enter a label to apply to this key.
5. In the state fields, check (enable) or uncheck (disable) the states you want to apply to this softkey.

#### Programmable Keys


6. Select from "**Key 1**" through "**Key 6**".
7. In the "**Type**" field, select **Callers List**.

#### Expansion Module Keys

8. Select from "**Key 1**" through "**Key 36**" (M670i).  
or  
Select from "**Key 1**" through "**Key 60**" (M675i).
9. In the "**Type**" field, select **Callers List**.
10. (M675i) In the "**Label**" field, enter a label to apply to this key.
11. Click **Save Settings**.

## Intercom Key

By default, the 6735i has an Intercom key configured on key 4 of the top set of keys. However, using the Aastra Web UI, you can assign the Intercom key to any key on the top or bottom keys on the phone.



You can use the Intercom key to automatically connect with a remote extension for outgoing calls, and to answer an incoming intercom call.

### Reference

For more information about the Intercom key, see ["Using Intercom"](#) on page 118.

### Configuring an Intercom Key



#### Aastra Web UI

Use the following procedure to configure a Callers List key on the 6735i IP Phone. The procedure shows the programmable key screen as an example.

#### Note:

By default, the **Intercom** key is Key 4 on the Programmable keys.

1. Click on **Operation->Softkeys and XML.**  
or  
Click on **Operation->Programmable Keys.**  
or  
Click on **Operation->Expansion Module <N>.**

#### Programmable Keys Configuration

Key	Type	Value	Line
1	Services		global
2	Directory		1
3	Callers List		1
4	Icom		global
5	None		1
6	None		1

### Softkeys

2. Select from **"Key 1"** through **"Key 20"**.

3. In the "Type" field, select **Intercom**.
4. In the "Label" field, enter a label to apply to this key.
5. In the state fields, check (enable) or uncheck (disable) the states you want to apply to this softkey.

**Programmable Keys**

6. Select from "Key 1" through "Key 6".
7. In the "Type" field, select **Intercom**.

**Expansion Module Keys**

8. Select from "Key 1" through "Key 36" (M670i).  
or  
Select from "Key 1" through "Key 60" (M675i).
9. In the "Type" field, select **Intercom**.
10. (M675i) In the "Label" field, enter a label to apply to this key.
11. Click **Save Settings**.

## Phone Lock Key

You can configure a key on the IP Phone to use as a lock/unlock key. You assign the function of the key as "Phone Lock".

### Configuring a Phone Lock Key



Use the following procedure to configure a Phone Lock key on the 6735i IP Phone. The procedure shows the softkey screen as an example.

1. Click on **Operation->Softkeys and XML**.  
or  
Click on **Operation->Programmable Keys**.  
or  
Click on **Operation->Expansion Module <N>**.

**Softkeys Configuration**

Key	Type	Label	Value	Line	Idle	Connected	Incoming	Outgoing	Busy
1	Phone Lock			1	<input type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
2	Park			1	<input checked="" type="checkbox"/>				
3	Pickup			1	<input checked="" type="checkbox"/>				
4	Line			5	<input checked="" type="checkbox"/>				
5	Do Not Disturb			1	<input checked="" type="checkbox"/>				
6	None			1	<input type="checkbox"/>				

**Softkeys**

2. Select from "Key 1" through "Key 20".
3. In the "Type" field, select **Phone Lock** from the list of options.

**Programmable Keys**

4. Select from "Key 1" through "Key 6".
5. In the "Type" field, select **Phone Lock** from the list of options.

**Expansion Module Keys**

6. Select from "**Key 1**" through "**Key 36**" (M670i).  
or  
Select from "**Key 1**" through "**Key 60**" (M675i).
7. In the "**Type**" field, select **Phone Lock** from the list of options.
8. Click **Save Settings**.

**Note:**

You can lock/unlock the phone using the new key you just configured, using the Aastra Web UI at the path *Operation->PhoneLock*, or using the "**Phone Lock**" option on the IP Phone UI at the path *Options->Phone Lock*. For more information about using the lock/unlock feature, see "[Locking/Unlocking a Phone](#)" on page 51.

**Using the Lock/Unlock Key on the IP Phone**

After configuring a key as a lock/unlock key, refer to the following procedure to use the key on the IP phone.

**Lock the Phone**

1. Press the **LOCK** key.  
The phone locks.  
The LED for the key AND the Message Waiting Lamp illuminate steady ON. An "Unlock" label appears next to the key you just pressed.

**Unlock the Phone**

2. Press the **UNLOCK** key.  
A password prompt displays.
3. Enter your user password and press **ENTER**.  
The phone unlocks.  
The LED for the key AND the Message Waiting Lamp go OFF. The "Lock" label appears next to the key you just pressed.

**Paging Key (Sends the RTP Stream)**

You can configure a Paging key on the phone that allows you to send a Real Time Transport Protocol (RTP) stream to pre-configured multicast address(es) without involving SIP signaling. You enter a multicast IP address(es) and a port number for the Paging key, that when pressed, initiates an outgoing multicast RTP session. This is called Group Paging on the IP phones.

You can also specify group paging RTP addresses that the phone listens for when receiving RTP streams. You can specify up to 5 listening multicast addresses at the path, *Basic Settings->Preferences->Group Paging RTP Settings*.

For more information about Group Paging and how it works, and to specify multicast addresses, see "[Group RTP Paging \(receives RTP streams\)](#)" on page 182.

## Configuring a Paging Key



Aastra Web UI

1. Click on **Operation->Softkeys and XML.**  
or  
Click on **Operation->Programmable Keys.**  
or  
Click on **Operation->Expansion Module <N>.**

### Softkeys Configuration

Key	Type	Label	Value	Line	Idle	Connected	Incoming	Outgoing	Busy
1	Paging	Test	239.0.1.15:10000	1	<input checked="" type="checkbox"/>				
2	None			1	<input checked="" type="checkbox"/>				
3	Park			1	<input checked="" type="checkbox"/>				
4	Pickup			1	<input checked="" type="checkbox"/>				
5	Empty			1	<input checked="" type="checkbox"/>				
6	None			1	<input checked="" type="checkbox"/>				

### Softkeys

2. Select from "Key 1" through "Key 20".
3. In the "Type" field, select **Paging**.
4. In the "Label" field, enter a label to apply to this key.
5. In the "Value" field, enter a multicast IP address and a port number for the Paging key. When you press this key, the phone initiates an outgoing multicast RTP session to the specified address using the specified port. (For example, 239.0.1.15:10000).  
**Notes:**
  1. When you select Paging for the "Type" field, the "Line" field is disabled.
  2. The "Value" field allows for one multicast address entry only.
6. To receive RTP streams for Group Paging, you must also configure the "**Paging Listen Addresses**" parameter at the path, *Basic Settings->Preferences->Group Paging RTP Settings*. For more information about setting this parameter, see "[Group RTP Paging \(receives RTP streams\)](#)" on page 182.

### Programmable Keys

7. Select from "Key 1" through "Key 6".
8. In the "Type" field, select **Paging**.
9. In the "Value" field, enter a multicast IP address and a port number for the Paging key. When you press this key, the phone initiates an outgoing multicast RTP session to the specified address using the specified port. (For example, 239.0.1.15:10000).  
**Notes:**
  1. When you select Paging for the "Type" field, the "Line" field is disabled.
  2. The "Value" field allows for one multicast address entry only.
10. To receive RTP streams for Group Paging, you must also configure the "**Paging Listen Addresses**" parameter at the path, *Basic Settings->Preferences->Group Paging RTP Settings*. For more information about setting this parameter, see "[Group RTP Paging \(receives RTP streams\)](#)" on page 182.

### Expansion Module Keys

11. Select from "Key 1" through "Key 36" (M670i).  
or  
Select from "Key 1" through "Key 60" (M675i).
12. In the "Type" field, select **Paging**.

13. (M675i) In the **“Label”** field, enter a label to apply to this key.
14. In the **“Value”** field, enter a multicast IP address and a port number for the Paging key. When you press this key, the phone initiates an outgoing multicast RTP session to the specified address using the specified port. (For example, 239.0.1.15:10000).
- Notes:**
1. When you select Paging for the **“Type”** field, the **“Line”** field is disabled.
  2. The **“Value”** field allows for one multicast address entry only.
15. To receive RTP streams for Group Paging, you must also configure the **“Paging Listen Addresses”** parameter at the path, *Basic Settings->Preferences->Group Paging RTP Settings*. For more information about setting this parameter, see **“Group RTP Paging (receives RTP streams)”** on page 182.
16. Click **Save Settings** to save your changes

### Using the Paging Key


The following procedure describes the use of the Paging key on the IP Phone. The procedure assumes you have already configured the Paging key using the Aastra Web UI.




#### IP Phone UI

#### Notes:

1. Recipient of a Paging call can set a global **“Do Not Disturb”** (DND) to ignore any incoming pages.
  2. For incoming Paging, the phone uses the Intercom configuration settings. The incoming Page is dependant on the **“Allow Barge-In”** parameter setting and the **“Idling/On Call”** state.
1. On the IP Phone, press the softkey, programmable key, or expansion module key you configured for Paging (labeled as **“Group 1”** in the following illustration).



The phone opens a multicast RTP session and an outgoing OR incoming phone screen displays as follows.



2. Press the **Drop** key to end the multicast RTP session and return to the idle screen.

**Note:**

If you enable global DND on the phone, the incoming multicast RTP session is dropped.

## None Key

You can set a softkey, programmable key, or expansion module key to force a blank entry on the IP phone display for a specific key. You do this by setting the key to "none". The keys are added in order (from key1 to key20) after any hard-coded keys have been added. If a particular key is not defined, it is ignored. For more information about key behavior, see "Key Display Behavior" on page 57.

### Configuring a None Key



#### Aastra Web UI

Use the following procedure to configure a None key on the 6735i IP Phone. The procedure shows the softkey screen as an example.

1. Click on **Operation->Softkeys and XML.**  
or  
Click on **Operation->Programmable Keys.**  
or  
Click on **Operation->Expansion Module <N>.**

#### Softkeys Configuration

Key	Type	Label	Value	Line	Idle	Connected	Incoming	Outgoing	Busy
1	None			1	<input checked="" type="checkbox"/>				
2	Park			1	<input checked="" type="checkbox"/>				
3	Pickup			1	<input checked="" type="checkbox"/>				
4	Line			5	<input checked="" type="checkbox"/>				
5	Do Not Disturb			1	<input checked="" type="checkbox"/>				
6	None			1	<input checked="" type="checkbox"/>				

#### Softkeys

2. Select from "Key 1" through "Key 20".
3. In the "Type" field, select **None**.

#### Programmable Keys

4. Select from "Key 1" through "Key 6".
5. In the "Type" field, select **None**.

#### Expansion Module Keys

6. Select from "Key 1" through "Key 36" (M670i).  
or  
Select from "Key 1" through "Key 60" (M675i).
7. In the "Type" field, select **None**.
8. Click **Save Settings**.

## Empty Key

You can set a softkey to force a blank entry on the IP phone display for a specific key. You do this by setting the softkey to "empty". The keys are added in order (from key 1 to key 20) after any hard-coded keys have been added. If a particular key is not defined, it is ignored.

### Configuring an Empty Key



Aastra Web UI

Use the following procedure to configure an Empty softkey on the 6735i phone.

1. Click on **Operation->Softkeys and XML**.  
or  
Click on **Operation->Programmable Keys**.  
or  
Click on **Operation->Expansion Module <N>**.

#### Softkeys Configuration

Key	Type	Label	Value	Line	Idle	Connected	Incoming	Outgoing	Busy
1	Empty			1	<input checked="" type="checkbox"/>				
2	None			1	<input checked="" type="checkbox"/>				
3	Pickup			1	<input checked="" type="checkbox"/>				
4	Line			5	<input checked="" type="checkbox"/>				
5	Do Not Disturb			1	<input checked="" type="checkbox"/>				
6	None			1	<input checked="" type="checkbox"/>				

#### Softkeys

2. Select from "Key 1" through "Key 20".
3. In the "Type" field, select **Empty**.
4. In the state fields, check (enable) or uncheck (disable) the states you want to apply to this softkey.

#### Programmable Keys

5. Select from "Key 1" through "Key 6".
6. In the "Type" field, select **Empty**.

#### Expansion Module Keys

7. Select from "Key 1" through "Key 36" (M670i).  
or  
Select from "Key 1" through "Key 60" (M675i).
8. In the "Type" field, select **Empty**.
9. Click **Save Settings**.

## Deleting a Key



Aastra Web UI

Use the following procedure to delete a key on the 6735i IP Phone. The procedure shows the softkey screen as an example.

1. Click on **Operation->Softkeys and XML.**  
or  
Click on **Operation->Programmable Keys.**  
or  
Click on **Operation->Expansion Module <N>.**

### Softkeys Configuration

Key	Type	Label	Value	Line	Idle	Connected	Incoming	Outgoing	Busy
1	None			1	<input type="checkbox"/>				
2	Park			1	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
3	Pickup			1	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>
4	Line			5	<input checked="" type="checkbox"/>				
5	Do Not Disturb			1	<input checked="" type="checkbox"/>				
6	None			1	<input type="checkbox"/>				

### Softkeys, Programmable Keys, Expansion Module Keys

2. Choose the key you want to delete from the phone.
3. In the "**Type**" field, select **None**.
4. Click **Save Settings**.

The key function is deleted from the IP phone memory.

# Making Calls

This section describes ways to make calls on your 6735i phone, using your handset, speakerphone or headset.

## Dialing a Number

First, take the phone off-hook by:

- lifting the handset
- pressing  or
- pressing a line/call appearance button
- At the dial tone, enter the number you wish to call

### Note:


After dialing the number, the phone has a short delay before sending the call. To send the call immediately, you can press the **"Dial"** softkey (if the handset is offhook) or the **"#"** key immediately after dialing the number. The phone sends the call without delay.

If you are unable to make calls within certain area codes, check with your System Administrator for any toll restrictions placed on your extension that may restrict your access to long distance area codes or dialing prefixes.

When your party picks up, a timer appears on your display that records the length of your call.

If the Live DialPad option is on, as soon as you press the first digit on the dial pad the phone automatically selects the next available line, go off-hook and dial as digits are pressed.

## Pre-dialing a Number



You can also make a call by pre-dialing a number. Pre-dialing lets you view a number before you dial. Use the **Backspace** softkey to correct any errors.

## Using Handsfree Speakerphone

The handsfree feature allows you to speak to someone without using the handset or headset. Your phone must be in either the Speaker or Speaker/Headset audio mode. For more information about setting the audio mode on your phone, see ["Audio Mode"](#) on page 32.



### IP Phone UI

- To dial using handsfree, first press  and enter a number at the dial tone.
- To answer a call on your phone using handsfree, press  or the line/call appearance button.
- If you are in Speaker audio mode, lift the handset and press  to switch between handsfree and handset.
- If you are in Speaker/headset audio mode, press  to switch between handsfree and headset.
- When the handset is on hook, press  to disconnect the call.

When handsfree is on, the speaker light turns on.

### Using a Headset

The 6735i accepts headsets through the modular RJ22 jack on the back of the phone. Contact your telephone equipment retailer or distributor to purchase a compatible headset.

**Note:**

Customers should read and observe all safety recommendations contained in headset operating guides when using any headset.

#### Advanced Volume Controls for the Headset Mic

On the 6735i, there are 3 options for the headset microphone volume. For more information about the headset microphone, see “Headset Mic Volume” on page 32.



IP Phone UI

#### To change this volume:

1. Press  to enter the Options list.
2. Select **Preferences** and press **Select**.
3. Use ▼ to scroll down to **Set Audio** and press **Select**.
4. Press ▼ to scroll down to **Headset/Mic Volume** and press **Select**.
5. Use ▼ to scroll down the list to select your desired volume.
6. Press **Done** to save changes and exit.
7. If you do not wish to save changes, press **Cancel** to return to the previous screen.

**Note:**

By default, the volume for the headset microphone is set to medium.

#### To Make and Receive Calls Using a Headset




IP Phone UI

1. Ensure that you have selected a headset audio mode by accessing the Options list (under option **Preferences->Set Audio->Audio Mode** on the IP Phone).
2. Plug the headset into the jack.
3. Press the  key to obtain a dial tone or to answer an incoming call. Depending on the audio mode selected from the options menu, a dial tone or an incoming call is received on either the headset or the handsfree speakerphone.
4. Press the  key to end the call.

## Using Intercom

On the 6735i, you can use the **Icom** key to automatically connect with a remote extension. By default, the Icom key is configured as Key 4 on the top set of keys.



### Using the Icom Key

#### IP Phone UI

1. Press the **Icom** key.
2. Enter the extension number of the person you wish to intercom or the BLF key for that extension.
3. After a beep tone, your phone automatically connects with the remote extension and you can speak through its speaker.
4. To cancel intercom, press  or the **Cancel** key.
5. When you are finished speaking, hang up the phone by placing the handset back on-hook or by pressing  or the line/call appearance button for the active call. When you hang up, the remote phone also hangs up.

You can set specific incoming Intercom call features on the 6735i IP phone using the Aastra Web UI. The following table describes these features.

Incoming Intercom Features in Aastra Web UI	Description
Microphone Mute	Allows you to enable or disable the microphone on the IP phone for Intercom calls made by the originating caller.
Auto Answer	Allows you to enable or disable the IP phone to automatically answer an Intercom call. If auto-answer is enabled on the IP phone, the phone plays a tone (if "Play Warning Tone" is enabled) to alert the user before answering the intercom call. If auto-answer is disabled, the phone treats the incoming intercom call as a normal call.
Play Warning Tone	Allows you to enable or disable a warning tone to play when the phone receives an incoming intercom call on an active line.
Allow Barge In	Allows you to enable or disable how the phone handles incoming intercom calls while the phone is on an active call.

For more information about the incoming Intercom features and for procedures on setting these features, see ["Incoming Intercom Call Features"](#) on page 180.

## Redial



### IP Phone UI

- Press  to dial the most recent number you dialed from the phone.
- If you are off-hook and press , the last number you called is called back.
- If you are on-hook and press , a **Redial Directory** list appears on-screen.

The redial list is available during active calls. It stores up to the last 100 numbers you called, allowing you to scroll through and select the number you wish to redial.

#### Note:

Your System Administrator can set your Redial key to speed dial a specific number. Contact your System Administrator for more information.

### Accessing the Redial List



### IP Phone UI

1. If you are off-hook and press , the telephone automatically dials the last number you called.
2. If you are not on the phone, press  to display the most recently dialed number and use ▼ and ▲ to scroll through the list to view the other numbers.
3. Press ▼ to see the second most recently dialed number, or ▲ to see the oldest call on your list.
4. To dial the displayed number press , or lift the Handset or press any line keys.
5. Press  or the  key to cancel.

#### Note:

The redial list is available during active calls. It also stores up to the last 100 numbers you called, allowing you to scroll through and select the number you wish to redial.

### Deleting from the Redial List



1. Press .
2. Press the **Delete** Key, then press the **Delete** key again to erase the item.

### Delete All Items



1. Press .
2. Press the **Delete** Key, then press the **Delete All** key at the prompt to erase all items.

## Mute

You can use the Mute  key to mute the handset, headset, or speakerphone. When you use the mute key on your phone, you cannot be heard on an active call or on a conference. For muted calls, the handsfree LED flashes and the Mute key LED is ON.



You can use the Mute  key to mute the handset, headset, or speakerphone. The speaker light flashes slowly and you can hear the caller, but they cannot hear you. To switch mute on or off, press .

#### Note:

If you place a muted call on hold, the phone automatically takes the call off mute when you reconnect to the call.

# Receiving Calls

When a call is ringing at your extension, the inbound callers extension and name display to the screen. The line/call appearance light flashes quickly for the incoming call.



## Answering an Incoming Call



### To answer the call

- For handsfree operation, press  or the line/call appearance button for the incoming call.
- Press  for handsfree or headset operation.
- Lift the handset for handset operation.

#### Note:

The audio mode setting you have selected in the options list under **Headset Settings** determines if the call goes to handsfree or headset operation. For more information, see the section “Customizing Your Phone” on page 25.

If the phone is already connected to a call, pressing the line/call appearance button for the new incoming call automatically places the connected call on hold and answers the new call. To reconnect to a party, press the line/call appearance button for that call.

If you cannot answer the call, the caller goes to voicemail if voicemail has been configured for your extension.

#### Note:

The  key can be used to cancel the call pickup procedure.

## Sending an Incoming Call to Voicemail

You can send an incoming call directly to voicemail without answering the call. To do this, press  without picking up the handset. If you're already on the phone your incoming call should go directly to voicemail. Your phone screen displays a voicemail icon (  ) along with the number of waiting messages, if you have unheard messages (example:  x4).

# Handling Calls

When you are connected to a call, you can use the softkeys or hard keys on the phone to place a call on hold, transfer a call, or conference.

## Placing a Call on Hold

You can place an active call on hold by pressing the Hold  key. When you place a call on hold, only your phone can retrieve the call.



### IP Phone UI

#### To place a call on hold

1. Connect to the call (if not already connected).
2. Press the Hold  key.



The line/call appearance light begins to flash slowly and after a short time the phone beeps softly to remind you that you still have a call on hold. The screen displays "**Call Held**" with the line number the call is held at the phone.

#### Note:

If you are connected to another call, the phone does not beep to remind you that you still have a call on hold.

#### When on Hold

To let your caller know that they are still on hold, music plays softly (if this has been set up for your system). The call/line appearance light for the line you are on remains solid to indicate that you are still connected.



## Automatic Hold

When juggling between calls, you do not have to press the hold button to go from one call to the next. The phone automatically puts your current call on hold as soon as you press a new line/call appearance button. If you have more than one call on hold, you can reconnect to a held call by pressing the line/call appearance button where that call is being held. Press  to disconnect the call.

## Retrieving a Held Call

If you have more than 1 call on hold, you can scroll through the held call information by pressing ◀ and ▶ navigation keys. To reconnect to a call press the line/call appearance button where that call is being held. If you press the call/line appearance button again, you disconnect from the call.

## Transferring Calls

### Blind Transfer

A blind transfer is when you transfer a call directly to another extension without consulting with the person receiving the call. To do this, simply complete the transfer immediately after you have entered the number. The call goes directly to the extension or outside line you transferred to. If the party you are transferring the call to does not answer, the transferred call rings back to your extension.

### Consultative Transfer

You also have the option to consult with the person you are transferring the call to, before you complete the transfer. To do this, simply remain on the line until the receiving party answers the call. After consulting with the receiving party, you can either complete the transfer or cancel the transfer to go back to the original call.

### Pre-Dial & Live Dial Mode

By default, when users are initiating a conference call or transfer, they will not hear a dial tone before dialing begins (pre-dial mode). The phone does not automatically dial out the number until the user presses the "Transfer" (Xfer) key. This allows the users to make changes to the dialing number before initiating the call. Administrators can configure a live dial mode.

In live dial mode, when the user is completing a conference call or transfer, they will hear a dial tone before dialing begins. In addition, the phone will either match the number to the dial plan or wait for the set digit timeout.

In the default pre-dial mode, users are able to edit the destination number prior to dialing, whereas in live dial mode they are not able to, however the "Dial" and "Cancel" softkeys are provided while the user inputs the number.




When you lift the handset on the phone, the **Xfer** key displays on the bottom set of softkeys by default. Use this key to transfer calls.



**Screen that displays when handset is lifted**

### Transferring Calls in Pre-Dial Mode

Use the following procedure to transfer a call to another extension in pre-dial mode. Use the following illustration as a reference..



1. Connect to Party 1 (if not already connected). Party 1 is the party you want to transfer.
2. Press the **Xfer** key. You will not hear a dial tone before dialing begins.
3. Enter the extension number (or the outside number) to Party 2. This is the Party for which you want to transfer Party 1. To cancel the transfer you can either select **Cancel** on the display screen, press , or hangup the handset.
 

**Note:**  
Users are able to edit the destination number ("Backspace" softkey is provided and navigation key is functional to move the cursor to the desired location).
4. Complete either a blind or consultative transfer:
  - a) To complete a blind transfer, press the **Xfer** key again before the receiving end answers.
  - b) To complete a consultative transfer, press **Dial** and remain on the line to speak with the Party 2, before either pressing the **Xfer** key or , or hanging up the handset to transfer Party 1 to Party 2.

### Transferring Calls in Live Dial Mode

Use the following procedure to transfer a call to another extension in live dial mode.

1. Connect to Party 1 (if not already connected). Party 1 is the party you want to transfer.
2. Press the **Xfer** key. You should hear a dial tone before the dialing begins.
3. Enter the extension number (or the outside number) to Party 2. This is the Party for which you want to transfer Party 1. To cancel the transfer prior to the completion of dialing, you can either select **Cancel** on the display screen, press the , or hang-up the handset.

To cancel the transfer after dialing has been completed and the ringback tone is heard, you can select **Cancel**.

**Note:**

Users are not able to edit the destination number as the phone will either match the inputted number to a dial plan or wait for the set digit timeout.

4. Complete either a blind or consultative transfer:
  - a) To complete a blind transfer, press the **Transfer** key again, or the , or hang-up the handset before the set digit timeout.
  - b) To complete a consultative transfer, press **Dial** or wait for the number match or timeout and remain on the line to speak with the Party 2, before either pressing the **Xfer** key or , or hanging up the handset to transfer Party 1 to Party 2.

### Transferring Two Existing Calls

The 6735i allows you to perform a transfer of a call when there are currently two active calls on the phone. For example, on your phone, there are two active calls - Call A and Call B. Call B is on hold. You can perform the following to transfer Call A to Call B:


1. Press **Xfer** key. A new line opens.
2. Press or scroll to the **Line** where Call B is on hold.
3. Press **Xfer** key.  
Call A is transferred to Call B.

### Completing a Transfer to a Contact in Phone Directory

Users can complete a blind transfer to a contact in their local directory. If a user is in a call and initiates a transfer, they can navigate to the Directory screen where a new transfer key can be pressed to complete a blind transfer. There is no change to start a consultative call.

When a directory entry is shown, there is a **Xfer** softkey below the current Dial softkey to trigger a blind transfer. This **Xfer** softkey is only available if a transfer has been initiated.

If a directory entry has multiple numbers, softkey 2 is used for the **Arrange** function. If a transfer has been initiated, the Arrange function will be replaced with the **Xfer** function.



**Entry has multiple numbers**

#### To Transfer a Call to a Contact in the Phone Directory:

1. Connect to Party 1 (if not already connected). Party 1 is the party you want to transfer.
2. Press the **Xfer** key. You should hear a dial tone as a second line opens up.
3. Press the **Directory** key and select a contact.
4. To complete a blind transfer, press the **Transfer** key again before the receiving end answers.

To complete a consultative transfer, press **Dial** to call the contact. Remain on the line to speak with Party 2 before pressing the **Transfer** key again to transfer Party 1 to Party 2.

To cancel the transfer, select **Cancel** on the display screen or press .

### Indication of Transferred Calls

When you transfer an active call, the near-end phone displays a Call Transferred screen when a call is transferred and the far-end call is dropped. The following is the Call Transferred screen on the 6735i phone:



The following procedure describes how to handle the Call Transferred screen on your phone.

#### IP Phone UI

1. Press the Goodbye  key.  
The Call Transferred screen no longer displays.  
or  
Select any Line key.  
The Call Transferred screen no longer displays and is replaced by a dial screen.

## Conferencing Calls

The 6735i IP phone offers two methods of conferencing:

- Local conferencing in pre-dial and live dial mode (default method).
- Centralized conferencing (for Sylanro and Broadsoft Servers) (Administrator must enable this method).

When you lift the handset on the phone, the **Conference** key displays on the bottom set of softkeys by default. Use this key to create conference calls.



**Screen that displays when handset is lifted**

### Local Conferencing

The 6735i phone supports up to 3 parties (including yourself) in a conference call. This is called Local Conferencing and is the default method of conferencing on the 6735i.

**Note:**

Your System Administrator can set your Conference key to speed dial a specific number. Contact your System Administrator for more information.

### Pre-Dial & Live Dial Mode

By default, when users are initiating a conference call or transfer, they will not hear a dial tone before dialing begins (pre-dial mode). The phone does not automatically dial out the number until the user presses the **“Conference”** key. This allows the users to make changes to the dialing number before initiating the call. Administrators can configure a live dial mode.

In live dial mode, when the user is completing a conference call or transfer, they will hear a dial tone before dialing begins. In addition, the phone will either match the number to the dial plan or wait for the set digit timeout.


In the default pre-dial mode, users are able to edit the destination number prior to dialing, whereas in live dial mode they are not able to, however the “Dial” and “Cancel” softkeys are provided while the user inputs the number.

### Using Local Conferencing in Pre-Dial Mode




#### IP Phone UI

Use the following procedure to create a conference call using local conferencing in pre-dial mode. Use the following illustration as a reference.



1. When you begin a conference, you are the first party in the conference (Party 1). Pickup the handset or press the speakerphone key. A line opens up.
2. Call Party 2 by dialing their number (or answer an incoming call of a Party).
3. Wait for Party 2 to answer. When Party 2 answers, you can consult with them before adding them to the conference.

- Press the **Conf** key. You will not hear a dial tone before the dialing begins.



- Enter the phone number of Party 3.

**Note:**


Users are able to edit the destination number (“Backspace” softkey is provided and navigation key is functional to move the cursor to the desired location).

- Wait for Party 3 to answer. When Party 3 answers, you can consult with them before adding them to the conference.
- Press the **Conf** key again to add Party 3 to the conference. Party 1 (which is yourself), Party 2, and Party 3 are all connected to a single conference.
- To drop a party from the conference, use the navigation key to select the party and press the **Drop** key.

### Using Local Conferencing in Live Dial Mode

Use the following procedure to create a conference call using local conferencing in live dial mode.

- When you begin a conference, you are the first party in the conference (Party 1). Pickup the handset or press the speakerphone key. A line opens up.
- Call Party 2 by dialing their number (or answer an incoming call of a Party).
- Wait for Party 2 to answer. When Party 2 answers, you can consult with them before adding them to the conference.
- Press the **Conf** key. You should hear a dial tone before dialing begins.



- Enter the phone number of Party 3.

**Note:**

Users are not able to edit the destination number as the phone will either match the inputted number to a dial plan or wait for the set digit timeout.

- Wait for Party 3 to answer. When Party 3 answers, you can consult with them before adding them to the conference.
- Press the **Conf** key again to add Party 3 to the conference. Party 1 (which is yourself), Party 2, and Party 3 are all connected to a single conference.
- To drop a party from the conference, use the navigation key to select the party and press the **Drop** key.

**Note:**

You can use ▼ and ▲ to scroll through and see the numbers and names (if available) of the parties in the conference call. When a name is displayed, pressing ► drops the displayed party from the call.

### **Joining Two Active Calls in a Single Conference**

1. Begin with active calls on two different lines (for example, Line 1 and Line 2 have active calls).
2. Press the **Line** key for which you want to conference the two calls together (for example, Line 1).
3. Press the **Conf** key.
4. Press the **Line** key that has the second active call (for example, Line 2).
5. Press the **Conf** key. The two active calls link into a conference call on Line 1.

**Note:**

You can use ▼ and ▲ to scroll through and see the numbers and names (if available) of the parties in the conference call. When a name is displayed, pressing ► drops the displayed party from the call.

### **Centralized Conferencing (for Sylantrio and Broadsoft Servers)**

The 6735i allows you to create multiple conferences with unlimited participants (depending on your server limitations) when your Administrator enables Centralized Conferencing.

If your Administrator does not enable Centralized Conferencing, then the 6735i uses Local Conferencing by default.

Your Administrator can configure Centralized Conferencing globally on all lines or on specific lines. Although, for the global setting to work, you must configure the lines with the applicable phone number.

### **Reference**

For more information on Centralized Conferencing, see [“Centralized Conferencing”](#) on [page 187](#) or contact your System Administrator.

### **Using Centralized Conferencing**




#### **IP Phone UI**

**Note:**

When Centralized Conferencing is enabled on your phone, local conferencing (or three-way conferencing) works as indicated in the previous section, [“Using Local Conferencing in Pre-Dial Mode”](#) on [page 127](#). Joining two active calls in a conference also works as indicated in the previous section, [“Joining Two Active Calls in a Single Conference”](#) on [page 129](#).

Use the following procedure to create a conference call using centralized conferencing. Use the following illustration as a reference.



### Setting Up a Conference and Adding Multiple Parties (for Sylantra and Broadsoft Servers)

#### Note:

You can have an unlimited number of parties in a conference (dependent on the limitations of the server).

1. When you begin a conference, you are the first party in the conference (Party 1). Pickup the handset or press the Speakerphone Key.  
A line opens up.
2. Call Party 2 by dialing their number (or answer an incoming call of a Party).
3. Wait for Party 2 to answer. When Party 2 answers, you can consult with them before adding them to Conference 1.
4. Press the **Conf** Key. A new line opens.



5. Enter the phone number of Party 3.
6. Wait for Party 3 to answer. When Party 3 answers, you can consult with them before adding them to the Conference 1.
7. Press the **Conf** Key again to add Party 3 to Conference 1. Party 1 (which is yourself), Party 2, and Party 3 are all connected to Conference 1.
8. Press an available **Line** Key (or answer an incoming call on an available line). If calling out, call Party 4.
9. Wait for Party 4 to answer. When Party 4 answers, you can consult with them before adding them to the conference.
10. Press the **Conf** Key to add Party 4 to Conference 1.
11. Press the **Line** Key that has Conference 1.
12. Press the **Conf** Key to join all parties (Parties 1 through 4) on Conference 1.
13. To add more parties, repeat steps 8 through 12.

If any party in the conference hangs up (including the party that began the conference), all other parties in the conference are still connected.

### *Setting Up Multiple Conferences (for Sylanro Server only)*

**Note:**

The 6735i is limited to 9 conferences (a single conference each on lines 1 through 9).

1. Start Conference 1 using the procedures in the previous section, “[Setting Up a Conference and Adding Multiple Parties \(for Sylanro and Broadsoft Servers\)](#)” on [page 130](#).
2. When you are finished adding all required parties to Conference 1, press an available **Line** Key to start Conference 2. You are Party 1 on Conference 2. Call Party 2.
3. When Party 2 answers, press the **Conf** Key.
4. Press an available **Line** Key.
5. Call Party 3 for Conference 2.
6. When Party 3 answers, press the **Conf** Key to join Parties 1 (which is yourself), Party 2, and Party 3 on Conference 2. You now have two active conferences on two different lines.

**Note:**

When you are connected to multiple conference calls, and you put a conference on hold, the conference may be on hold for a limited period of time before it is disconnected. Contact your System Administrator for more information.

If any party in a conference hangs up (including the party that began the conference), all other parties in the conference are still connected.

### *Joining Additional Parties to Active Conferences*

In centralized conferencing, you can join multiple incoming or outgoing calls to active conferences. Before following this procedure, at least one active conference must exist on your phone.

1. As Party 1, pickup the handset or press the speakerphone key.  
A line opens up.
2. Call Party 2 by dialing their number (or answer an incoming call of a Party).
3. Wait for Party 2 to answer. When Party 2 answers, you can consult with them before adding them to the conference.
4. Press the **Conf** Key.
5. Press the **Line** Key that has the active conference. (For example, Line 1 and Line 2 both have active conferences. Pressing Line 1 joins Party 1 and Party 2 to the conference on Line 1. Pressing Line 2 joins Party 1 and Party 2 to the conference on Line 2.)
6. Press the **Conf** Key again to join the Parties to the active conference.

### *Ending a Conference and Transferring Remaining Parties*

The 6735i allows a Host to drop from a 3-way conference and let the other two parties remain connected by pressing a **Transfer** key.

**Note:**

The Caller ID of the dropped Host still displays on the remaining parties' phones.

If you are the Host of a conference and want to leave that conference:

- While in a 3-way conference press the **Transfer** key on the phone.  
Your phone leaves the 3-way conference but the remaining parties are still connected to the conference.

## Ending Calls



### IP Phone UI

To end a call, you first need to connect or reconnect to the call if not already connected (for example, if your caller is on hold). Press  or the line/call appearance button of the active call to end the call. If connected through the handset, you can also place the handset back on hook to end the call.



1. Press the **Directory** Key. The directory displays the number of entries in your list. If the Directory list is empty, "Directory Empty/Use Save to add" displays. The following is an example of the Directory List Header screen with 97 entries in the List.



2. You can access entries by pressing ▼ and ▲ to scroll through the list.
3. To search for an entry by name, press the dial pad number corresponding to the first letter of the name (for example, press **7** for the letter **P**). Continue to press the dial pad number to access other letters on the same key (for example, press **7** three times for 'Ron'). If there are multiple entries under the same letter, you can use ▼ and ▲ to scroll through the list, or continue to press the next letters of the name to find a better match.
4. To dial the displayed number press  or just lift the handset or press any line keys.
5. Press the **Directory** Key to cancel.

### Sorting Entries and Quick Search Feature

You can sort multiple numbers according to preference and perform a quick-search feature that allows you to enter the first letter that corresponds to a name in the Directory to find specific line items. The phone displays the first name with this letter.

#### Note:

The quick-search feature in the Directory List works only when the Directory is first accessed.

### Managing the Directory List

From the Directory List in the IP Phone UI, you can perform the following:

- ["Adding New Entries to the Directory List"](#) (page 134)
- ["Editing Entries in the Directory List"](#) (page 136)
- ["Deleting Entries from the Directory List"](#) (page 138)
- ["Saving Entries to the Directory List"](#) (page 139)


### Adding New Entries to the Directory List

You can store a maximum of 7 numbers associated with a unique name. You can apply pre-defined labels to the entry which include, Office, Home, Cell, and Pager, or create your own labels. The following table indicates the maximum characters for each line and field in the Directory List.


Directory List Limitations	
Maximum length of a line	255 characters
Maximum length of a name	16 characters
Maximum length of a label	14 characters

Directory List Limitations	
Maximum length of a URI	45 characters
Maximum number directory entries in the NVRAM	200 entries

The following examples illustrate the IP Phone UI screens you can use to add entries in the Directory List.



Screen 1



Screen 2

### Adding Names, Numbers, Labels



#### On Screen 1:

- You can add names using the **abc** softkey.
- You can add numbers (up to 7 numbers per name) using the numbers on the phone's keypad.
- Use the **Backspace** softkey when required.
- Use the **Save** softkey when you are finished adding the name and number(s).
- You can exit from Screen 1 at any time without saving by pressing the **Cancel** softkey.

#### Note:

Use the ▼ and ▲ keys to toggle between Screen 1 and Screen 2.

**On Screen 2:**

- You can add a label or URI using the **abc** softkey; Or you can populate the "Label" field with a pre-defined label (Office, Home, Cell, Pager) by pressing the **Label** softkey.
- Use the **Backspace** softkey when required.
- Use the **Save** softkey when you are finished adding the Label.
- You can exit from Screen 2 at any time without saving by pressing the **Cancel** softkey.

**Editing Entries in the Directory List****IP Phone UI**

On Screen 1, when the cursor is in the "Line" field, softkey 5 displays a **Change** softkey. The following example illustrates a Directory entry for "Steve Smith", with a phone number and an "Office" label. Since the cursor is in the "Line" field, the **Change** softkey displays.

```
001 Steve Smith
    Office
    905-760-9999
    Line: 1 |
- Dial          Delete -
-              Change -
- Add Number   List -
```


The following example shows the same Directory entry without a label.

```
001 Steve Smith
    905-760-9999
    Line: 1 |
- Dial          Delete -
-              Change -
- Add Number   List -
```

- You can use the **Dial** softkey to automatically dial the number in the Directory entry.
- You can use the **Add Number** softkey to add additional numbers to the current Directory entry (up to 7 numbers per name).
- You can use the **Delete** softkey to delete a number or to delete multiple numbers in an entry (see ["Deleting Entries from the Directory List"](#) on [page 138](#)).
- You can use the **Change** softkey to change a number or a name.
- You can use the **Quit** softkey to quit the editing of the current Directory entry.


**Scrolling Multiple Screens Per Entry****IP Phone UI**

If there are multiple numbers for an entry, the ◀ and ▶ keys display for you to scroll multiple screens. The following examples show **Screen 1** as Steve Smith's Office number, **Screen 2** as Steve Smith's Home number, and **Screen 3** as Steve Smith's Cell number. The first scroll ▶ indicates there are multiple number entries for the name. The ◀ and ▶ indicates you can scroll forward or backward between screens. The ◀ indicates this is the last number entry for the name.



**Arranging Multiple Screens**

You can use the **Arrange** softkey to move the number/label/line forward or backward between screens for the specified name. If there is a label assigned to the entry, the following screen displays after pressing the **Arrange** softkey.




Pressing the **Save** softkey in the above screen places the Cell label, the Cell number, and line associated with the Cell number, into the one position. So the first screen to display for the entry would be the Cell number screen. If no label is assigned to the entry, the numbers would be arranged in the order you specify.

The following example illustrates the new arrangement of Steve Smith's number.

**Note:**

The Office label moves to the second position and the Home label moves to the last position.



**Deleting Entries from the Directory List**

You can delete entries from the Directory List in the following ways:


- Delete a single name or number and all associated numbers and labels.
- Delete specific numbers and labels from a single entry
- Delete all entries in the Directory List

You use the Delete softkey to delete a single or multiple numbers, names, or labels for an individual entry.



**To delete a single entry from the Directory List:**


1. Scroll to a name or number in the Directory List.
2. Press **Delete**. The following screen displays.



3. Press **Yes** to delete the directory entry (name, number, label, and line) from the Directory List.
4. Press **Cancel** to cancel the delete function.

## To delete specific numbers, names or labels for an entry:


1. Scroll to a name or number in the Directory List that has multiple numbers and/or labels assigned to the entry.
2. Press **Delete**. The following screen displays.



3. Press **Number** to delete only a specific number associated with a name.
4. Press **Entries** to delete the entire directory entry (name, all numbers, labels, and lines associated with the name) from the Directory List.
5. Press **Cancel** to cancel the delete function.

## To delete all entries from the Directory List:

1. Press the **Directory** key.



2. At the "Directory List" top screen, press **DeleteList**.

## Saving Entries to the Directory List

You can save entries (names and numbers) from other sources to your Directory using the following methods:


- Save from the Caller List
- Save from the Redial List

### Saving from the Callers List



#### IP Phone UI

You can save a name, number, and/or label from the Callers List to the Directory List using the following procedure. Use the following illustration as a reference.




1. Press the **Callers List** key.
2. Scroll to the entry you want to copy to the Directory List.
3. Press **Copy**. The entry is saved in the Directory List.

### Saving from the Redial List



#### IP Phone UI

You can save a name, number, and/or label from the Redial List to the Directory List using the following procedure. Use the following illustration as a reference.




1. Press the  (**Redial List**) key.
2. Scroll to the entry you want to copy to the Directory List.
3. Press **Copy**. The entry is saved in the Directory List.

### Downloading the Directory List to Your PC

You can download the Directory List to your PC via the Aastra Web UI. The phone stores the *directorylist.csv* file to your PC in comma-separated value (CSV) format.

You can use any spreadsheet application to open the file for viewing. The following is an example of a Directory List in a spreadsheet application.



	A	B	C	D	E	F
1	John	41373	2			
2	Tim	41376	1			
3	Carol	4443245	1			
4	Tom	41356	3			
5						
6						
7						
8						
9						
10						
11						
12						

The file displays the name, phone number, and line number for each Directory entry.

**Note:**

Your System Administrator can populate your IP phone Directory List with server directory files. Contact your System Administrator for more details.

### Download the Directory List

Use the following procedure to download the Directory List to your PC using the Aastra Web UI.



#### Aastra Web UI

1. Click on **Operation->Directory**.



2. In the Directory List field, click on **Save As**.  
A File Download message displays.
3. Click **OK**.
4. Enter the location on your computer where you want to download the Directory List and click **SAVE**.  
The *directorylist.csv* file downloads to your computer.
5. Use a spreadsheet application to open and view the Directory List.

### Accessing the Directory List

Use the following procedures to access the Directory List.



#### IP Phone UI

1. Press the **Services** key on the phone to display the **Services** menu, and select "**Directory List**".  
or  
Press the **Directory** softkey (default key is key 2 on the Top Keys).
2. Use the ▼ and ▲ keys to scroll through the line items in the Directory List.
3. To dial a displayed entry from the Directory List, pick up the handset, press the  handsfree key, or press the **Dial** softkey.
4. To exit the Directory List, press the **Quit** softkey.

## Callers List

The Callers list is a stored log of your incoming calls. The 6735i telephone stores information on up to 200 incoming calls in the Callers list. Your telephone logs the number and name (if available) of the caller, when they last called, and the number of times they tried to reach you.

When the Callers list is full, the oldest call records are deleted to accommodate the information of new callers.

If the telephone number of an incoming or outgoing call matches a number that you have programmed with a name in a programmable key or the Directory, the Callers list display the name and number.

The display shows you how many callers have been added to the list since you last checked it.

### Caller's List Screen Display

Display Item	Description
450-349-0438	Indicates you have returned the call from the Callers list.
N MAR 04 3:30pm 2x	"N" indicates a new call.
XX New Callers	When you're not on the telephone and not in the Callers list, the display shows you how many callers have been added to the list since you last checked it.
	Indicates an unanswered call in the Callers list.
	Indicates an answered call in the Callers list.
	Indicates a Call Waiting call in the Callers list.
	Indicates an incoming Call Waiting call.
John Burns 9054550055 Jun 8 2:41pm 2X	"2x" indicates this caller has called twice. The display shows the date and time of the last call from that caller.


You can view, scroll, and delete line items in the Callers List from the IP phone UI. You can also directly dial from a displayed line item in the Callers List.

## Accessing the Callers List



### IP Phone UI

Use the following procedure to access the Callers List. Use the following illustration as a reference.




1. Press the **Callers List** key.  
or  
Press the **Services** key if your System Administrator has configured the Services key to access the Callers List.
2. Use the ▲ keys to scroll through the line items in the Callers List.  
**Note:**  
To the left of a line item, a 📞 icon displays with the handset ON or OFF the receiver. The ON receiver indicates the call came in as a missed call. The OFF receiver indicates the call came in and was answered.
3. To delete all entries in the Callers list, press the **Delete** softkey at the "Callers List" header.  
To delete a line item from the Callers List, select the line item you want to delete and press the **Delete** softkey.
4. To cancel a delete function, press the ▼ or the ▲ **Scroll** keys.
5. To save a line item to a softkey for speed dialing, press the **Save** softkey and enter the line number at the "Save to?" prompt that is already configured for speed dialing at a softkey.
6. To dial a displayed entry from the Callers List, pick up the handset, press the  handsfree button, or press a line key.
7. To exit the Callers List, press the **Callers List** key.

### Editing Entries in the Callers List

**Important!**


The Callers List does not save changes. Editing in the Callers List is generally used if you plan to call the number and need to add a prefix.

In the Callers List, if a dial pad key is pressed when a number and/or a name is displayed, the cursor automatically adds the digit at the left side of the number to enable the entry of the prefix.



 **IP Phone UI**

Use the following procedure to edit the Callers List. Use the following illustration as a reference.



1. Press the **Callers List** Key.
2. Press ▼ and ▲ to find the entry you want to edit. Press ▼ to view the most recent call, or ▲ to see the oldest call on your list.
3. Press any key on the dial pad to begin editing.
4. To move the cursor one digit to the right, press ►. To erase one digit to the left of the cursor, press ◀.
5. To dial the displayed number press , or just lift the handset, or press any line keys.


### Deleting Entries from the Callers List

You can delete individual items from the Callers List, or you can delete all items in the Callers List.



#### IP Phone UI

Use the following procedure to delete an individual item from the Callers List. Use the following illustration as a reference.



1. Press the **Callers List** Key.
2. Use ▼ and ▲ keys to find the item you want to delete.
3. Press the **Delete** softkey.
4. Press the **Delete** softkey again at the prompt to erase the item.



#### IP Phone UI

Use the following procedure to delete all items from the Callers List.

1. Press the **Callers List** Key.
2. Press the **Delete** softkey.
3. Press the **Delete** softkey again at the prompt to erase all items.

### Downloading the Callers List to Your PC

You can download the Callers List to your PC for viewing using the Aastra Web UI. When you download the Callers List, the phone stores the *callerlist.csv* file to your computer in comma-separated value (CSV) format.

You can use any spreadsheet application to open the file for viewing. The following is an example of a Callers List in a spreadsheet application. This file displays the name, phone number, and the line that the call came in on.


	A	B	C	D	E	F
1	John	41373	2			
2	Tim	41376	1			
3	Carol	4443245	1			
4	Tom	41356	3			
5						
6						
7						
8						
9						
10						
11						
12						

## Download the Callers List

Use the following procedure to download the Callers List to your PC using the Aastra Web UI.



1. Click on **Operation->Directory**.



2. In the Callers List field, click on **Save As**.  
A File Download message displays.
3. Click **OK**.
4. Enter the location on your computer where you want to download the Callers List and click **SAVE**.  
The *callerslist.csv* file downloads to your computer.
5. Use a spreadsheet application to open and view the Callers List.

## Account Configuration (DND and Call Forwarding)

The 6735i has a feature that allows you to configure “Do Not Disturb” (DND) and “call forwarding” (CFWD) for multiple accounts on the phone. You can set specific modes for the way you want the phone to handle DND and CFWD. The three modes you can set on the phone for these features are:

- Account
- Phone
- Custom

The following paragraphs describe account-based DND and CFWD:


- DND Account-Based Configuration
- Call Forward Account-Based Configuration

### DND Account-Based Configuration

“Do Not Disturb” (DND) is a feature on the phone that prevents the phone from ringing and receiving incoming calls. When DND is enabled with “call forwarding” (CFWD), any incoming calls can be call forwarded to voicemail or another number. See [“Call Forward Account-Based Configuration”](#) on [page 152](#) for more information about call forwarding to other numbers.

On the 6735i, you can set DND on the phone-side for a specific account or for all accounts on the phone. You can set three modes for DND using the Aastra Web UI at the path, **Basic Settings->Preferences->General->DND Key Mode: Account, Phone (default), and Custom**. DND performs according to the mode you set.

You can then configure a DND key (for the phone or for an expansion module) using the Aastra Web UI at the path, **Operation->Softkeys Keys and XML or Operation->Programmable Keys**. You can enable and disable DND by toggling the key, or by setting DND for a specific account at the path, **Basic Settings->Account Configuration**. Once you enable DND, “DND” displays on the LCD for the applicable account.



#### Note:

If there is only one account configured on the phone, then the mode setting is ignored and the phone behaves as if the mode was set to “Phone”.

The following describes the key behavior for each DND mode.

- **Account** - DND key toggles the account in focus on the IP Phone UI, to ON or OFF if DND enabled for that account.
- **Phone** - (default) DND key toggles all accounts on the phone to ON or OFF.
- **Custom** - DND key displays custom screens on the IP Phone UI. User can select whether to enable/disable DND per account, enable DND on all accounts, or disable DND on all accounts.

The following table describes the key and Message Waiting Indicator (MWI) LEDs when you enable DND on the IP Phone.

Key LED Behavior for All Modes	MWI LED Behavior for All Modes
<b>DND key LED RED</b> if current account in focus has DND ON.	<b>MWI LED ON</b> if current account in focus has DND ON.
<b>DND key LED OFF</b> when current account in focus has DND disabled.	<b>MWI LED OFF</b> if current account in focus has DND OFF.

**Note:**

If you make changes to the configuration for DND via the IP Phone UI, you must refresh the Aastra Web UI screen to see the changes.

**Configuring DND**

The following describes configuring DND on your phone. To configure a DND key, see the section, [“Do Not Disturb” \(DND\) Key](#) on page 69.

**Note:**

If there is no DND key configured or if it is removed, DND is disabled on the IP Phone.

**Configuring DND Using the Aastra Web UI**



Use the following procedure to configure DND using the Aastra Web UI.

1. Click on **Basic Settings->Preferences->General**.

**Preferences**

**General**

Park Call:

Pick Up Parked Call:

Display DTMF Digits  Enabled

Play Call Waiting Tone  Enabled

Stuttered Dial Tone  Enabled

XML Beep Support  Enabled

Switch UI Focus To Ringing Line  Enabled

Call Hold Reminder During Active Calls  Enabled

Call Hold Reminder  Enabled

Call Waiting Tone Period

Preferred line  ▼

Preferred line Timeout (seconds)

Message Waiting Indicator Line  ▼

DND Key Mode  ▼

Call Forward Key Mode  ▼

2. In the “**DND Key Mode**” field, select a “do not disturb” (DND) mode to use on the phone. Valid values are: **Account**, **Phone** (default), **Custom**. Default is **Phone**.

- **account** Sets DND for a specific account. DND key toggles the account in focus on the phone to ON or OFF.
- **phone** (default) Sets DND ON for all accounts on the phone. DND key toggles all accounts on the phone to ON or OFF.
- **custom** Sets the phone to display custom screens after pressing the DND key, that list the account(s) on the phone. The user can select a specific account for DND, turn DND ON for all accounts, or turn DND OFF for all accounts.

**Notes:**

1. If there is only one account configured on the phone, then the mode setting is ignored and the phone behaves as if the mode was set to “Phone”.
2. Using the Aastra Web UI, if you change the DND Key Mode to “phone”, all accounts synchronize to the current setting of Account 1.

3. Click **Save Settings**. The changes takes affect immediately without a reboot.

4. Click on **Basic Settings->Account Configuration**.

**Account Configuration**

Account	DND	Call Forward	State	Label	No. Rings
1. Stacy Donaldson	<input checked="" type="checkbox"/>	All	<input type="checkbox"/>	<input type="text"/>	
		Busy	<input checked="" type="checkbox"/>	<input type="text"/>	
		No Answer	<input type="checkbox"/>	<input type="text"/>	1 ▾
2. 905-1234567	<input type="checkbox"/>	All	<input type="checkbox"/>	<input type="text"/>	
		Busy	<input type="checkbox"/>	<input type="text"/>	
		No Answer	<input type="checkbox"/>	<input type="text"/>	1 ▾

5. For each account, enable DND by placing a check mark in the box. Disable DND by unchecking the box.


**Notes:**

1. If you selected “**Account**” or “**Custom**” mode in step 2, you can enable/disable each account or all accounts as applicable. If you selected “**Phone**” mode, the first account allows you to change the DND status for all accounts.
2. Number and name of accounts that display to this screen are dependant on the number and name of accounts configured on the phone. In the screen in step 4, Screenname1 is configured on Line 1, Screenname2 is configured on Line 2, and Screenname3 is configured on Line 3. Only your Administrator can create accounts for your phone. Contact your Administrator for more information.

6. Click **Save Settings**. The changes takes affect immediately without a reboot.

### Using DND Modes via the IP Phone UI

After you add a DND key to your phone, you can toggle the DND state using this key on the phone. Use the following procedure to enable/disable DND on the IP Phone.




The following procedures assume you have already configured a DND key AND assumes there are three accounts configured on the phone.

**Notes:**

1. If there is no DND key configured or if it is removed, DND is disabled on the IP Phone.
2. If there is only one account configured on the phone, then the mode setting is ignored and the phone behaves as if the mode was set to "Phone".
3. Using the Aastra Web UI, if you change the DND key mode to "phone", all accounts synchronize to the current setting of Account 1.

#### DND in Account Mode


1. With the account in focus on the IP Phone UI, press the DND key to toggle DND ON or OFF for the account. Use the RIGHT and LEFT arrow keys to scroll through each account.
2. Use the RIGHT and LEFT arrow keys to scroll through each account.



In the above example, Screenname1, Screenname2, and Screenname3, are three accounts configured on the phone. Only Screenname1 and 3 have DND ON. Screenname 2 has DND OFF.

**DND in Phone Mode (Default)**

1. Press the DND key to toggle DND ON or OFF for all accounts on the phone. Toggling to ON enables DND on all accounts on the phone. Toggling to OFF disables DND on all accounts on the phone. Use the RIGHT and LEFT arrow keys to scroll through each account. Use the RIGHT and LEFT arrow keys to scroll through each account.




In the above example, toggling Screenname1 to DND ON, enabled DND for Screenname2 and 3 also.

**Note:**

Enabling DND in "Phone" mode toggles all accounts on the phone to DND ON.

**DND in Custom Mode**

1. Press the **DND** key on the phone. The screen displays a list of the accounts on the phone and allows you to enable/disable a specific account or all accounts. Use the UP and DOWN arrow keys to scroll through the accounts.



In the above example, Screenname1 and 3 have DND ON as indicated by a check mark (✓). Screenname2 has DND off as indicated by an X. The ALL ON and ALL OFF softkeys allow you to enable or disable DND on all accounts, respectively.

2. You use the **CHANGE** key to enable or disable DND for a specific account selected.
3. Press **DONE** to save the change.

**Call Forward Account-Based Configuration**

Call Forward (CFWD) on the IP phone allows incoming calls to be forwarded to another destination.

On the 6735i, you can set Call Forward (CFWD) on the phone-side for a specific account or for all accounts on the phone. You can set a CFWD mode using the Aastra Web UI at the path, **Basic Settings->Preferences->General->Call Forward Key Mode: Account** (default), **Phone**, and **Custom**. CFWD performs according to the mode you set.

You can configure CFWD using the Aastra Web UI at the path, **Basic Settings->Account Configuration**, **OR** you can configure CFWD using the IP Phone UI at the path, **Options->Call Forward**.

Using the Aastra Web UI at the path, **Operation->Softkeys and XML** or **Operation->Programmable Keys**, you can also configure a CFWD key for the phone (or for an expansion module) to use as a shortcut for accessing the CFWD menu on the phone.

The following describes the behavior for each CFWD mode.

- **Account** - (default) The account mode allows you to configure CFWD on a per account basis. Pressing a configured CFWD key applies to the account in focus.
- **Phone** - The Phone mode allows you to set the same CFWD configuration for all accounts (**All, Busy, and/or No Answer**). When you configure the initial account, the phone applies the configuration to all other accounts. (In the Aastra Web UI, only the account you configured is enabled. All other accounts are grayed out but set to the same configuration.) Using the Aastra Web UI, if you make changes to that initial account, the changes apply to all accounts on the phone.
- **Custom** - The Custom mode allows you to configure CFWD for a specific account or all accounts. You can configure a specific mode (**All, Busy, and/or No Answer**) for each account independently or all accounts. On the 6735i, you can set all accounts to **All On, All Off**, or copy the configuration for the account in focus to all other accounts using a **CopytoAll** softkey.

**Note:**

If there is only one account configured on the phone, then the mode setting is ignored and the phone behaves as if the mode was set to **Phone**.

You can enable different CFWD rules/modes independently (for example, you can set different phone numbers for **Busy, All, and NoAnswer** modes and then turn them on/off individually).

The following table describes the key and Message Waiting Indicator (MWI) LEDs when you enable CFWD on the IP Phone.

Key LED Behavior for All Modes	MWI LED Behavior for All Modes
<p><b>CFWD key LED RED</b> if CFWD All, CFWD Busy, or CFWD No Answer is enabled for the account in focus.</p> <p><b>CFWD key LED OFF</b> if any CFWD mode is disabled.</p>	<p><b>MWI LED ON</b> if current account in focus has CFWD ALL enabled.</p> <p><b>MWI LED OFF</b> if CFWD All is disabled.</p>

**Note:**

If you make changes to the configuration for CFWD via the IP Phone UI, you must refresh the Aastra Web UI screen to see the changes.

## Configuring CFWD Using the Aastra Web UI



### Aastra Web UI

Use the following procedure to configure CFWD using the Aastra Web UI.

#### Note:

(Optional) You can configure a Call Forward key on your phone to access the Call Forward menus if desired. If you do not configure a Call Forward key, you can still access the Call Forward menu from the IP Phone UI at the path, **Options->Call Forward**.

1. (optional) Click on **Operation->Softkeys and XML**.  
or  
Click on **Operation->Programmable Keys**.  
or  
Click on **Operation->Expansion Module**.

#### Softkeys Configuration

Key	Type	Label	Value	Line	Idle	Connected	Incoming	Outgoing	Busy
1	Call Forward			1	<input checked="" type="checkbox"/>				
2	Speeddial			1	<input type="checkbox"/>				
3	Park			1	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
4	Pickup			1	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>
5	None			1	<input checked="" type="checkbox"/>				
6	None			1	<input checked="" type="checkbox"/>				

#### Softkeys

2. Select from "**Key 1**" through "**Key 20**".
3. In the "**Type**" field, select **Call Forward** from the list of options.
4. (optional) If required, enable or disable the applicable states for the Call Forward key (Idle, Connected, Incoming, Outgoing, and/or Busy).

#### Programmable Keys

5. Select from "**Key 1**" through "**Key 6**".
6. In the "**Type**" field, select **Call Forward** from the list of options.

#### Expansion Module Keys

7. Select from "**Key 1**" through "**Key 36**" (M670i).  
or  
Select from "**Key 1**" through "**Key 60**" (M675i).
8. In the "**Type**" field, select **Call Forward** from the list of options.
9. Click **Save Settings**.

#### Note:

If there is no CFWD key configured on the phone or it is removed, you can still set the CFWD modes via the IP Phone UI at the path **Options->Call Forward**.

10. Click on **Basic Settings->Preferences->General.**

Preferences	
<b>General</b>	
Park Call:	<input type="text"/>
Pick Up Parked Call:	<input type="text"/>
Display DTMF Digits	<input type="checkbox"/> Enabled
Play Call Waiting Tone	<input checked="" type="checkbox"/> Enabled
Stuttered Dial Tone	<input checked="" type="checkbox"/> Enabled
XML Beep Support	<input checked="" type="checkbox"/> Enabled
Switch UI Focus To Ringing Line	<input checked="" type="checkbox"/> Enabled
Call Hold Reminder During Active Calls	<input type="checkbox"/> Enabled
Call Hold Reminder	<input type="checkbox"/> Enabled
Call Waiting Tone Period	<input type="text" value="0"/>
Preferred line	<input type="text" value="1"/> ▼
Preferred line Timeout (seconds)	<input type="text" value="0"/>
Message Waiting Indicator Line	<input type="text" value="All"/> ▼
DND Key Mode	<input type="text" value="Phone"/> ▼
Call Forward Key Mode	<input type="text" value="Account"/> ▼

11. In the “**Call Forward Key Mode**” field, select a call forward mode to use on the phone. Valid values are: Account, Phone, Custom. Default is **Account**.

- **Account** - (default) The account mode allows you to configure CFWD on a per account basis. Pressing a configured CFWD key applies to the account in focus.
- **Phone** - The Phone mode allows you to set the same CFWD configuration for all accounts (**All**, **Busy**, and/or **No Answer**). When you configure the initial account, the phone applies the configuration to all other accounts. (In the Aastra Web UI, only the account you configured is enabled. All other accounts are grayed out but set to the same configuration.) Using the Aastra Web UI, if you make changes to that initial account, the changes apply to all accounts on the phone.
- **Custom** - The Custom mode allows you to configure CFWD for a specific account or all accounts. You can configure a specific state (**All**, **Busy**, and/or **No Answer**) for each account independently or all accounts. On the 6735i, you can set all accounts to **All On**, **All Off**, or copy the configuration for the account in focus to all other accounts using a **CopytoAll** softkey.

**Note:**

If there is only one account configured on the phone, then the mode setting is ignored and the phone behaves as if the mode was set to “Phone”.

12. Click **Save Settings**.

The changes takes affect immediately without a reboot.

13. Click on **Basic Settings->Account Configuration.**

**Account Configuration**

Account	DND	Call Forward	State	Label	No. Rings
1. Stacy Donaldson	<input checked="" type="checkbox"/>	All	<input type="checkbox"/>	<input type="text"/>	
		Busy	<input checked="" type="checkbox"/>	<input type="text"/>	
		No Answer	<input type="checkbox"/>	<input type="text"/>	1 <input type="button" value="v"/>
2. 905-1234567	<input type="checkbox"/>	All	<input type="checkbox"/>	<input type="text"/>	
		Busy	<input type="checkbox"/>	<input type="text"/>	
		No Answer	<input type="checkbox"/>	<input type="text"/>	1 <input type="button" value="v"/>

The illustration above shows 2 accounts configured on the phone. Accounts must be set up by your System Administrator.

14. For each account, enable the CFWD state by placing a check mark in one or more of the following **"State"** fields:

- All
- Busy
- No Answer

The **"All"** option forwards all incoming calls for this account to the specified phone number regardless of the state of the phone. The phone can be in the Busy or No Answer states, or can be in the idle state. The phone still forwards all calls to the specified number.

The **"Busy"** option call forwards incoming calls only if the account is in the busy state. The calls are forwarded to the specified phone number.

The **"No Answer"** option call forwards incoming calls only if the account rings but is not answered in the defined number of rings. The call gets forwarded to the specified number.

**Note:**

You can use the **"Busy"** and **"No Answer"** states together using different forwarding phone numbers. If these states are enabled for an account (the **"All"** state is disabled), and the phone is in the busy state when a call comes in, the phone can forward the call to the specified phone number (for example, voicemail). If there is no answer on the phone after the specified number of rings, the phone can forward the call to a different specified number, such as a cell phone number.

**15.** For each account, in the **"Number"** field, enter the phone number for which you want the incoming calls to forward to if the phone is in the specified state.

If using the **"Account"** mode or **"Custom"** mode, you can enter different phone numbers for each account.

**Notes:**

1. If you selected **"Account"** mode in step 5, you can enable/disable each account or all accounts as applicable. You can enter different phone number for each enabled state.

If you selected **"Custom"** mode, you can enable/disable each account or all accounts as applicable. You can enter different phone numbers for each enabled state.

If you selected **"Phone"** mode, all accounts are set to the same CFWD configuration (All, Busy, and/or No Answer) as Account 1 on the phone. (In the Aastra Web UI, only Account 1 is enabled. All other accounts are grayed out but use the same configuration as Account 1.)

Using the Aastra Web UI, if you make changes to Account 1, the changes apply to all accounts on the phone. Using the IP Phone UI, if you make changes to any other account other than Account 1, the changes also apply to all accounts on the phone. When enabling a CFWD state, you must specify a phone number for the phone to CFWD to. The number you specify applies to all accounts of the same mode.

2. Number and name of accounts that display to this screen are dependant on the number and name of accounts configured on the phone. In the screen in step 7, Screenname1 is configured on Line 1, Screenname2 is configured on Line 2, and Screenname3 is configured on Line 3. The name for the account is specified by your System Administrator. Contact your System Administrator for more information.

**16.** For the **"No Answer"** state, in the **"No. Rings"** field, enter the number of times that the account rings before forwarding the call to the specified number. Valid values are 1 through 20. Default is 1.

When using the **"Account"** mode or **"Custom"** mode, you can enter a different number of rings for each account. If you use the Aastra Web UI to change the Call Forward Key Mode to **"Phone"**, all accounts synchronize to Account 1.

**17.** Click **Save Settings**.

The changes takes affect immediately without a reboot.

### Using CFWD via the IP Phone UI

Once CFWD is enabled on your phone, you can access and change the configuration using the IP Phone UI or the Aastra Web UI. You can access the CFWD menus by pressing a pre-configured Call Forward key, or by selecting *Options->Call Forward* from the IP Phone UI.

The following procedure assumes you have already configured a CFWD key AND assumes there are three accounts configured on the phone.

**Notes:**


1. If there is no CFWD key configured on the phone or it is removed, you can still enable CFWD via the IP Phone UI at the path *Options->Call Forward*.

2. If there is only one account configured on the phone, then the mode setting is ignored and the phone behaves as if the mode was set to **"Phone"**

3. Using the Aastra Web UI, if you change the CFWD key mode to **"Phone"**, all accounts synchronize to the current setting of Account 1.


**CFWD in Account Mode**

1. Use the **RIGHT** and **LEFT** arrow keys to scroll through each account.



In the above example, Screenname1, Screenname2, and Screenname3, are three accounts configured on the phone. Screenname1 has "CFWD All" enabled, Screenname2 has "CFWD Busy" enabled, and Screenname3 has CFWD disabled as indicated by no message displayed.

2. Press the **Call Forward** key. The Call Forward Mode screen displays for the account you selected. Use the **UP** and **DOWN** arrow keys to scroll through each state type.



In the above example, **CFWD All** is enabled as indicated by a check mark (✓), **CFWD Busy** is enabled but no call forward phone number is configured as indicated by a !, and **CFWD NoAns** is disabled as indicated by an X.

**3.** Select a state for the account(s) in focus using the **UP** and **DOWN** arrow keys.

You can enable/disable any or all of the following states for an account:

- **All** - Enables **CFWD All** for an account and forwards all incoming calls for that account, to the specified number.
- **Busy** - Enables **CFWD Busy** for an account and forwards incoming calls to a specified number if DND has been enabled for that account OR if the account is currently engaged in another call.
- **No Answer** - Enables **CFWD NoAns** for an account and forwards incoming calls to a specified number if the call has not been answered for the specified number of rings.


**Note:**

If **CFWD All** AND **CFWD Busy** AND **CFWD NoAns** are all enabled (and/or if the account has DND enabled), the **CFWD All** settings take precedence over **CFWD Busy** and **CFWD NoAns**.

You can also use the following keys if required:

- **All Off** - Disables all CFWD states for the current account in focus.
- **All On** - Enables all CFWD states for the current account in focus.
- **CopytoAll Key** - Copies the call forward phone number and state of the Call Forward mode (All, Busy, No Answer) in focus to every Call Forward mode of that account. For example, if you have the cursor pointing at the “**All**” state and it is enabled and has a call forward phone number configured, pressing the **CopytoAll** Key enables the **Busy** state and the **NoAns** state and assigns the same phone number to both states.
- **Cancel Key** - Cancels any configuration you may have made without saving. To cancel a configuration, you must press this **CANCEL** key before pressing the **DONE** key.

4. For the **CFWD No Answer** state, press the **CHANGE** key for the mode you selected in step 2. This displays the Call Forward State screen. In the following example, the **CFWD All** state is ON.




**Note:**

You can press the **AllAccts** key to copy the settings in the current Call Forward Settings screen for a specific call forward mode, to every account on the phone. Every account will have the same settings for that call forward mode.

5. Press the **CHANGE** key in the CFWD State screen. With the cursor in the **"State"** field, toggle the state ON and OFF by pressing the **CHANGE** key.
6. Use the **DOWN** arrow key to scroll to the **"Number"** field. Enter a phone number to apply to the current state in focus. When the phone is in the state you specified, and a call comes into the phone, it forwards the call to the number you specify.  
Use the **BACKSPACE** key if required to delete characters.
7. Use the **DOWN** arrow key to scroll to the **"No. Rings"** field. Press the **CHANGE** key to select the number of rings to apply to the phone for call forwarding incoming calls. Valid values are 1 to 20. Default is 1.  
When the phone receives an incoming call, and call forward is configured on the phone, the phone rings the number of times you specify in the No. Rings screen, and then forwards the call.
8. Press **DONE** in the CFWD State Screen to save all changes.
9. Press **DONE** in the CFWD Mode Screen to save all changes.

## CFWD in Phone Mode

Use the **RIGHT** and **LEFT** arrow keys to scroll through each account.




In the above example, Screenname1, Screenname2, and Screenname3, are three accounts configured on the phone. Screenname1, 2 and 3 have “**CFWD All**” enabled.

### Note:

In “Phone” mode, when you change the call forward configuration for an account, the change applies to all accounts.

1. Press the **Call Forward** key. The Call Forward menu displays. Use the **UP** and **DOWN** arrow keys to scroll through each state type.



In the above example, **CFWD All** is enabled as indicated by a check mark (✓), **CFWD Busy** is enabled but no call forward phone number is configured as indicated by a !, and **CFWD No Answer** is disabled, as indicated by an X.

2. Select a state using the **UP** and **DOWN** arrow keys. You can enable/disable a specific account on the phone with any or all of the following states. However, the configuration you set will apply to all accounts on the phone.
  - **All** - Enables **CFWD All** on the phone and forwards all incoming calls to the specified number.
  - **Busy** - Enables **CFWD Busy** on the phone and forwards incoming calls to a specified number if DND has been enabled OR if the phone is currently engaged in another call.
  - **No Answer** - Enables **CFWD NoAns** on the phone and forwards incoming calls to a specified number if the call has not been answered for the specified number of rings.


### Note:

If **CFWD All** AND **CFWD Busy** AND **CFWD NoAns** are all enabled (and/or if the account has DND enabled), the **CFWD All** settings take precedence over **CFWD Busy** and **CFWD NoAns**.

You can also use the following keys if required:

- **All Off Key** - Disables all CFWD modes.
- **All On Key** - Disables all CFWD modes.
- **CopytoAll Key** - Copies the call forward phone number and state of the Call Forward mode (All, Busy, No Answer) in focus to every Call Forward mode. For example, if you have the cursor pointing at the “All” state and it is enabled and has a call forward phone number configured, pressing the **CopytoAll** Key enables the **Busy** state and the **NoAns** state and assigns the same phone number to both states.
- **Cancel Key** - Cancels any configuration you may have made without saving. To cancel a configuration, you must press this **CANCEL** key before pressing the **DONE** key.

3. In the **CFWD No Answer** state, press the **CHANGE** key for the mode you selected in step 2. This displays the Call Forward State screen. In the following example, the CFWD All state is ON.




4. Press the **CHANGE** key in the CFWD State screen. With the cursor in the **"State"** field, toggle the state ON and OFF by pressing the **CHANGE** key.
5. Use the **DOWN** arrow key to scroll to the **"Number"** field. Enter a phone number to apply to the current state in focus. When the phone is in the state you specified, and a call comes into the phone, it forwards the call to the number you specify. Use the **BACKSPACE** key if required to delete characters.
6. Use the **DOWN** arrow key to scroll to the **"No. Rings"** field. Press the **CHANGE** key to select the number of rings to apply to the phone for call forwarding incoming calls. Valid values are **1** to **20**. Default is **1**. When the phone receives an incoming call, and call forward is configured on the phone, the phone rings the number of times you specify in the No. Rings screen, and then forwards the call.
7. Press **DONE** in the CFWD State Screen to save all changes.
8. Press **DONE** in the CFWD Mode Screen to save all changes.

**Note:**

In **"Phone"** mode, the configuration applies to all the accounts on the phone.


**CFWD in Custom Mode**

1. Use the **RIGHT** and **LEFT** arrow keys to scroll through each account.



In the above example, Screenname1, Screenname2, and Screenname3, are three accounts configured on the phone. Screenname1 has “**CFWD All**” enabled, Screenname2 has “**CFWD Busy**” enabled, and Screenname3 has CFWD disabled as indicated by no message displayed.

2. With the account in focus on the IP Phone UI, press the **Call Forward** key. The Call Forward Account screen displays which lists all the accounts on the phone. Use the **UP** and **DOWN** arrow keys to scroll through each account.




In the above example, Screenname1 has one or more CFWD states enabled as indicated by a check mark (✓), Screenname 2 has one or more CFWD states enabled but a specific state has no call forward phone number configured as indicated by a !, and Screenname3 has one or more CFWD states disabled as indicated by an X.

3. Select an account using the **UP** and **DOWN** arrow keys.  
 You can also use the following keys if required:
  - **All Off Key**- Disables CFWD for all accounts on the phone.
  - **All On Key** - Enables CFWD for all accounts on the phone.
  - **CopytoAll Key** - Copies all settings for the account you select, to all other accounts on the Call Forward Account screen. For example, if you have the cursor pointing at Screenname1, and you press the **CopytoAll** key, all of the CFWD settings for Screenname1 are copied to Screenname2 and Screenname3.
  - **Cancel Key** - Cancels any configuration you may have made without saving. To cancel a configuration, you must press this **CANCEL** key before pressing the **DONE** key.

4. After selecting an account, press **CHANGE**.

The Call Forward Mode screen displays for the account you selected. Use the **UP** and **DOWN** arrow keys to scroll through each state type.



In the above example, **CFWD All** is enabled as indicated by a check mark (✓), **CFWD Busy** is enabled but no call forward phone number is configured as indicated by a !, and **CFWD No Answer** is disabled, as indicated by an X. Select a state for the selected account(s) using the **UP** and **DOWN** arrow keys

You can enable/disable any or all of the following states for a specific account or for all accounts (with individual configurations):

- **All** - Enables **CFWD All** for an account and forwards all incoming calls for that account, to the specified number. The phone number can be different between accounts.
- **Busy** - Enables **CFWD Busy** for an account and forwards incoming calls to a specified number if DND has been enabled for that account OR if that account is currently engaged in another call. The phone number can be different between accounts.
- **No Answer** - Enables **CFWD NoAns** for an account and forwards incoming calls to a specified number if the call has not been answered for a specified number of rings. The phone number can be different between accounts.


**Note:**

If **CFWD All** AND **CFWD Busy** AND **CFWD NoAns** are all enabled (and/or if the account has DND enabled), the **CFWD All** settings take precedence over **CFWD Busy** and **CFWD NoAns**.

You can also use the following keys if required:

- **All Off Key** - Disables all CFWD states for the selected account.
- **All On Key** - Enables all CFWD states for the selected account.
- **CopytoAll Key** - Copies the call forward phone number and state of the selected Call Forward mode (All, Busy, No Answer) to every Call Forward mode of that account. For example, if you have the cursor pointing at the "All" state and it is enabled and has a call forward phone number configured, pressing the **CopytoAll** Key enables the **Busy** state and the **NoAns** state and assigns the same phone number to both states.
- **Cancel Key** - Cancels any configuration you may have made without saving. To cancel a configuration, you must press this **CANCEL** key before pressing the **DONE** key.

- Press the **CHANGE** key for the mode you selected in step 4. This displays the Call Forward State screen. In the following example, the CFWD All state is ON.



**Note:**

You can press the **AllAccts** key to copy the settings in the current Call Forward Settings screen for a specific call forward mode, to every account on the phone. Every account will have the same settings for that call forward mode.

- Press the **CHANGE** key in the CFWD State screen. With the cursor in the “**State**” field, toggle the state ON and OFF by pressing the **CHANGE** key.
- Use the **DOWN** arrow key to scroll to the “**Number**” field. Enter a phone number to apply to the current state in focus. When the phone is in the state you specified, and a call comes into the phone, it forwards the call to the number you specify.  
Use the **BACKSPACE** key if required to delete characters.
- Use the **DOWN** arrow key to scroll to the “**No. Rings**” field. Press the **CHANGE** key to select the number of rings to apply to the phone for call forwarding incoming calls. Valid values are 1 to 20. Default is 1.  
When the phone receives an incoming call, and call forward is configured on the phone, the phone rings the number of times you specify in the No. Rings screen, and then forwards the call.
- Press **DONE** in the CFWD State screen to save all changes.
- Press **DONE** in the CFWD Mode screen to save all changes.
- Press **DONE** in the CFWD Account screen to save all changes.

## Missed Calls Indicator

The IP phone has a "missed calls" indicator that increments the number of missed calls to the phone. This feature is accessible from the IP phone UI only.


The number of calls that have not been answered increment on the phone's idle screen as "**<number> New Calls**". As the number of unanswered calls increment, the phone numbers associated with the calls are stored in the Callers List. The user can access the Callers List and clear the call from the list. Once the user accesses the Callers List, the "**<number> New Calls**" on the idle screen is cleared.

### Accessing and Clearing Missed Calls



#### IP Phone UI

Use the following procedure to access and clear missed calls from the Callers List. Once you display the Callers List, the "**<number> New Calls**" indicator clears. Use the following illustration as a reference.



1. Press **Callers List** key on the phone.  
or  
Press the **Services** key and select **Callers List** from the menu.
2. Use the ▼ ▲ keys to scroll through the line items in the Callers List to find the line items that have the 📞 icon with the receiver ON. These are the missed calls to the phone.
3. To clear a line item from the Callers List, select the line item you want to delete and press the **Clear** softkey.  
The line item is deleted from the Callers List.

## Voicemail

The Voicemail feature on the 6735i IP phone allows you to use a line, configured with a phone number for dialing out, to connect to a voicemail server.

For each assigned Voicemail number, there can be a minimum of 0 or a maximum of 1 Voicemail access phone number. The Voicemail list displays a list of phone numbers assigned to the 6735i that have registered voicemail accounts associated with them.

**Note:**

The Voicemail list does not display the voicemail access number.

The phone displays up to 99 voicemail messages for an account even if the number of voicemails exceeds the limit.

Registered account numbers/URIs that exceed the length of the screen, either with or without the voicemail icon and the message count, are truncated with an ellipse character at the end of the number/URI string.

The end of the Voicemail list displays the number of new voicemail messages (if any exist).

Contact your System Administrator for lines configured for Voicemail.

### Using Voicemail



#### IP Phone UI

1. Press the **Services** key on the phone.
2. Select "**Voicemail**".
3. Use the ▼ and ▲ keys to scroll through the line items in the Voicemail list.
4. When you have selected a line item, press the  handsfree key, ► **Scroll Right** key, or press a line softkey to make an outgoing call using the voicemail access phone number associated with the line for which the voicemail account is registered.

From a selected item in the Voicemail list, you can also lift the handset (go offhook) to make an outgoing call using the voicemail access phone number.

# Additional Features

This section describes additional features you can use on the 6735i phone.

## *Star Codes*

All of the main call handling and extension management features using star codes can be set on your phone by your Administrator. Contact your System Administrator for more information.

If these have not been set up, you can dial any star code commands on the 6735i phone the same way you would on a regular telephone.

## Display DTMF Digits

A feature on the 6735i phone allows users to enable or disable DTMF (dual-tone multi-frequency) digits to display to the IP phone when using the keypad to dial, or when dialing from a softkey, programmable key, or expansion module key.

DTMF is the signal sent from the phone to the network that you generate when you press the phone's touch keys. This is also known as "touchtone" dialing. Each key you press on your phone generates two tones of specific frequencies. One tone is generated from a high-frequency group of tones and the other from a low frequency group.

If you enable the Display DTMF Digits parameter, the digits you are dialing from the keypad, softkey, or programmable key, display to the IP phone's LCD display. This parameter is disabled by default (no digits display when dialing).

You can enable the "Display DTMF Digits" parameter using the Aastra Web UI.

### Configuring Display of DTMF Digits



#### Aastra Web UI

Use the following procedure to configure the display of DTMF digits on the IP phone.

#### Note:

"Display DTMF Digits" is disabled by default.

1. Click on **Basic Settings->Preferences->General**.

Preferences	
<b>General</b>	
Park Call:	<input type="text"/>
Pick Up Parked Call:	<input type="text"/>
Display DTMF Digits	<input type="checkbox"/> Enabled
Play Call Waiting Tone	<input checked="" type="checkbox"/> Enabled
Stuttered Dial Tone	<input checked="" type="checkbox"/> Enabled
XML Beep Support	<input checked="" type="checkbox"/> Enabled
Switch UI Focus To Ringing Line	<input checked="" type="checkbox"/> Enabled
Call Hold Reminder During Active Calls	<input type="checkbox"/> Enabled
Call Hold Reminder	<input type="checkbox"/> Enabled
Call Waiting Tone Period	<input type="text" value="0"/>
Preferred line	<input type="text" value="1"/> ▼
Preferred line Timeout (seconds)	<input type="text" value="0"/>
Message Waiting Indicator Line	<input type="text" value="All"/> ▼
DND Key Mode	<input type="text" value="Phone"/> ▼
Call Forward Key Mode	<input type="text" value="Account"/> ▼

2. Enable the "**Display DTMF Digits**" field by checking the check box. Disable this field by unchecking the box). Default is disabled.
3. Click **Save Settings** to save your settings.

## Play Call Waiting Tone

You can enable or disable the playing of a call waiting tone when a caller is on an active call and a new call comes into the phone.

You can configure this feature using the Aastra Web UI.

### Configuring Call Waiting Tone



#### Aastra Web UI

Use the following procedures to configure a call waiting tone on the IP phone.

#### Note:

"Play Call Waiting Tone" is enabled by default.

1. Click on **Basic Settings->Preferences->General**.

**Preferences**

**General**

Park Call:	<input type="text"/>
Pick Up Parked Call:	<input type="text"/>
Display DTMF Digits	<input type="checkbox"/> Enabled
Play Call Waiting Tone	<input checked="" type="checkbox"/> Enabled
Stuttered Dial Tone	<input checked="" type="checkbox"/> Enabled
XML Beep Support	<input checked="" type="checkbox"/> Enabled
Switch UI Focus To Ringing Line	<input checked="" type="checkbox"/> Enabled
Call Hold Reminder During Active Calls	<input type="checkbox"/> Enabled
Call Hold Reminder	<input type="checkbox"/> Enabled
Call Waiting Tone Period	<input type="text" value="0"/>
Preferred line	<input type="text" value="1"/> ▼
Preferred line Timeout (seconds)	<input type="text" value="0"/>
Message Waiting Indicator Line	<input type="text" value="All"/> ▼
DND Key Mode	<input type="text" value="Phone"/> ▼
Call Forward Key Mode	<input type="text" value="Account"/> ▼

2. The **"Play Call Waiting Tone"** field is enabled by default. To disable this field, uncheck the box.
3. Click **Save Settings** to save your settings.

## Stuttered Dial Tone

You can enable or disable the playing of a stuttered dial tone when there is a message waiting on the IP phone. You can configure this feature using the Aastra Web UI.

### Configuring Stuttered Dial Tone



Use the following procedures to configure stuttered dial tone on the IP phone.

**Note:**

"Stuttered Dial Tone" is enabled by default.

1. Click on **Basic Settings->Preferences->General.**

**Preferences**

**General**

Park Call:	<input type="text"/>
Pick Up Parked Call:	<input type="text"/>
Display DTMF Digits	<input type="checkbox"/> Enabled
Play Call Waiting Tone	<input checked="" type="checkbox"/> Enabled
Stuttered Dial Tone	<input checked="" type="checkbox"/> Enabled
XML Beep Support	<input checked="" type="checkbox"/> Enabled
Switch UI Focus To Ringing Line	<input checked="" type="checkbox"/> Enabled
Call Hold Reminder During Active Calls	<input type="checkbox"/> Enabled
Call Hold Reminder	<input type="checkbox"/> Enabled
Call Waiting Tone Period	<input type="text" value="0"/>
Preferred line	<input type="text" value="1"/> ▼
Preferred line Timeout (seconds)	<input type="text" value="0"/>
Message Waiting Indicator Line	<input type="text" value="All"/> ▼
DND Key Mode	<input type="text" value="Phone"/> ▼
Call Forward Key Mode	<input type="text" value="Account"/> ▼

2. The **"Stuttered Dial Tone"** field is enabled by default. To disable this field, uncheck the box.
3. Click **Save Settings** to save your settings.

## XML Beep Support

Using the Aastra Web UI, you can enable or disable a beep to be audible when the phone receives an XML application using the **"XML Beep Support"** field at the path *Basic Settings->Preferences->General*. If you disable this feature, then no beep is heard when the XML application arrives to the phone.

If your System Administrator has set a value for this feature in a custom XML application or in the configuration files, the value you set in the Aastra Web UI overrides the Administrator's setting. Setting and saving the value in the Aastra Web UI applies to the phone immediately.

### Configuring XML Beep Support



#### Aastra Web UI

Use the following procedures to configure an XML beep on the IP phone.

#### Note:

"XML Beep Support" is enabled by default.

1. Click on **Basic Settings->Preferences->General**.

Preferences	
<b>General</b>	
Park Call:	<input type="text"/>
Pick Up Parked Call:	<input type="text"/>
Display DTMF Digits	<input type="checkbox"/> Enabled
Play Call Waiting Tone	<input checked="" type="checkbox"/> Enabled
Stuttered Dial Tone	<input checked="" type="checkbox"/> Enabled
XML Beep Support	<input checked="" type="checkbox"/> Enabled
Switch UI Focus To Ringing Line	<input checked="" type="checkbox"/> Enabled
Call Hold Reminder During Active Calls	<input type="checkbox"/> Enabled
Call Hold Reminder	<input type="checkbox"/> Enabled
Call Waiting Tone Period	<input type="text" value="0"/>
Preferred line	<input type="text" value="1"/> ▼
Preferred line Timeout (seconds)	<input type="text" value="0"/>
Message Waiting Indicator Line	<input type="text" value="All"/> ▼
DND Key Mode	<input type="text" value="Phone"/> ▼
Call Forward Key Mode	<input type="text" value="Account"/> ▼

2. The **"XML Beep Support"** field is enabled by default. To disable this field, uncheck the box.
3. Click **Save Settings**.

## Switch UI Focus to Ringing Line

You can configure a feature on the 6735i that controls the behavior of the phone when it receives an incoming call when it is already in a connected call. When a call comes into the phone, and the phone is already on a connected call, the phone switches focus to the ringing line to enable the user to see who is calling them. You can turn off this functionality so that the phone stays focused on the connected call. You can do this using the Switch Focus to Ringing Line parameter in the Aastra Web UI.

### Configuring "Switch Focus to Ringing Line" Using the Aastra Web UI



Aastra Web UI

Use the following procedure to enable or disable the "Switch Focus to Ringing Line" using the Aastra Web UI.

#### Note:

"Switch Focus to Ringing Line" is enabled by default.

1. Click on **Basic Settings->Preferences->General**.

Preferences	
<b>General</b>	
Park Call:	<input type="text"/>
Pick Up Parked Call:	<input type="text"/>
Display DTMF Digits	<input type="checkbox"/> Enabled
Play Call Waiting Tone	<input checked="" type="checkbox"/> Enabled
Stuttered Dial Tone	<input checked="" type="checkbox"/> Enabled
XML Beep Support	<input checked="" type="checkbox"/> Enabled
Switch UI Focus To Ringing Line	<input checked="" type="checkbox"/> Enabled
Call Hold Reminder During Active Calls	<input type="checkbox"/> Enabled
Call Hold Reminder	<input type="checkbox"/> Enabled
Call Waiting Tone Period	<input type="text" value="0"/>
Preferred line	<input type="text" value="1"/> ▼
Preferred line Timeout (seconds)	<input type="text" value="0"/>
Message Waiting Indicator Line	<input type="text" value="All"/> ▼
DND Key Mode	<input type="text" value="Phone"/> ▼
Call Forward Key Mode	<input type="text" value="Account"/> ▼

2. The "**Switch Focus to Ringing Line**" field is enabled by default. To disable this field, uncheck the box.
3. Click **Save Settings** to save your settings.

## Call Hold Reminder During Active Calls

The IP phones allow you to enable or disable the ability for the phone to initiate a continuous reminder tone on the active call when another call is on hold. For example, when this feature is enabled, and the call on Line 1 is on hold, and then the you answer a call on Line 2 and stay on that line, a reminder tone is played in the active audio path on Line 2 to remind you that there is still a call on hold on Line 1.

When this feature is disabled, a ring splash is heard when the active call hangs up and there is still a call on hold. You can enable or disable this feature using the **"Call Hold Reminder During Active Calls"** in the Aastra Web UI.

### Configuring "Call Hold Reminder During Active Calls"

Use the following procedure to configure "Call Hold Reminder During Active Calls" on the IP phone.

**Note:**

"Call Hold Reminder During Active Calls" is disabled by default.



#### Aastra Web UI

1. Click on **Basic Settings->Preferences->General**.

Preferences	
<b>General</b>	
Park Call:	<input type="text"/>
Pick Up Parked Call:	<input type="text"/>
Display DTMF Digits	<input type="checkbox"/> Enabled
Play Call Waiting Tone	<input checked="" type="checkbox"/> Enabled
Stuttered Dial Tone	<input checked="" type="checkbox"/> Enabled
XML Beep Support	<input checked="" type="checkbox"/> Enabled
Switch UI Focus To Ringing Line	<input checked="" type="checkbox"/> Enabled
Call Hold Reminder During Active Calls	<input type="checkbox"/> Enabled
Call Hold Reminder	<input type="checkbox"/> Enabled
Call Waiting Tone Period	<input type="text" value="0"/>
Preferred line	<input type="text" value="1"/> ▼
Preferred line Timeout (seconds)	<input type="text" value="0"/>
Message Waiting Indicator Line	<input type="text" value="All"/> ▼
DND Key Mode	<input type="text" value="Phone"/> ▼
Call Forward Key Mode	<input type="text" value="Account"/> ▼

2. The **"Call Hold Reminder During Active Calls"** field is disabled by default. To enabled this field, check the box.  
When this feature is enabled, a reminder tone is heard on the active call when another call is on hold. When disabled, a ring splash is heard when the active call hangs up and there is still a call on hold.
3. Click **Save Settings**.

## Call Hold Reminder (on single hold)

In previous releases, the call hold reminder ring splash was triggered when you hung up a call and there was at least one other call on hold. The reminder ring splash timer started only when the active call hung up and there was still another call on hold.

On the IP phones, you can enable or disable a feature that would start the reminder ring splash timer as soon as you put a call on hold (even when no other calls are active on the phone). When enabled, the phone initiates a reminder ring splash periodically for the single call on hold. When disabled, no reminder ring splash is audible.

You can enable or disable this feature using the **"Call Hold Reminder"** parameter in the Aastra Web UI.

### Configuring "Call Hold Reminder"

Use the following procedure to configure "Call Hold Reminder" on the IP phone.

**Note:**

"Call Hold Reminder" is disabled by default.



1. Click on **Basic Settings->Preferences->General**

**Preferences**

**General**

Park Call:	<input type="text"/>
Pick Up Parked Call:	<input type="text"/>
Display DTMF Digits	<input type="checkbox"/> Enabled
Play Call Waiting Tone	<input checked="" type="checkbox"/> Enabled
Stuttered Dial Tone	<input checked="" type="checkbox"/> Enabled
XML Beep Support	<input checked="" type="checkbox"/> Enabled
Switch UI Focus To Ringing Line	<input checked="" type="checkbox"/> Enabled
Call Hold Reminder During Active Calls	<input type="checkbox"/> Enabled
Call Hold Reminder	<input type="checkbox"/> Enabled
Call Waiting Tone Period	<input type="text" value="0"/>
Preferred line	<input type="text" value="1"/> ▼
Preferred line Timeout (seconds)	<input type="text" value="0"/>
Message Waiting Indicator Line	<input type="text" value="All"/> ▼
DND Key Mode	<input type="text" value="Phone"/> ▼
Call Forward Key Mode	<input type="text" value="Account"/> ▼

2. The **"Call Hold Reminder"** field is disabled by default. To enabled this field, check the box.  
When this feature is enabled, the reminder ring splash timer starts as soon as you put a call on hold (even when no other calls are active on the phone).The phone initiates a reminder ring splash periodically for the single call on hold. When disabled, no reminder ring splash is audible.
3. Click **Save Settings**.

## Call Waiting Tone Period

You can specify a specific time period (in seconds) for the call waiting tone to play at regular intervals on an active call using the parameter **“Call Waiting Tone Period”**. A value of **“0”** is the default and plays the call waiting tone only once on the active call. When the incoming caller hangs up, the call waiting tone stops on the existing active call.

You can enable or disable this feature in the Aastra Web UI.

### Configuring “Call Waiting Tone Period”

Use the following procedure to configure “Call Waiting Tone Period”.



#### Aastra Web UI

1. Click on **Basic Settings->Preferences->General**

**Preferences**

**General**

Park Call:	<input type="text"/>
Pick Up Parked Call:	<input type="text"/>
Display DTMF Digits	<input type="checkbox"/> Enabled
Play Call Waiting Tone	<input checked="" type="checkbox"/> Enabled
Stuttered Dial Tone	<input checked="" type="checkbox"/> Enabled
XML Beep Support	<input checked="" type="checkbox"/> Enabled
Switch UI Focus To Ringing Line	<input checked="" type="checkbox"/> Enabled
Call Hold Reminder During Active Calls	<input type="checkbox"/> Enabled
Call Hold Reminder	<input type="checkbox"/> Enabled
Call Waiting Tone Period	<input type="text" value="0"/>
Preferred line	<input type="text" value="1"/> ▼
Preferred line Timeout (seconds)	<input type="text" value="0"/>
Message Waiting Indicator Line	<input type="text" value="All"/> ▼
DND Key Mode	<input type="text" value="Phone"/> ▼
Call Forward Key Mode	<input type="text" value="Account"/> ▼

2. In the **“Call Waiting Tone Period”** field, enter a time period, in seconds, that the call waiting tone will be audible on an active call when another call comes in. Default is 0 seconds.
3. When enabled, the call waiting tone plays at regular intervals for the amount of time set for this parameter. For example, if set to **“30”** the call waiting tone plays every 30 seconds. When set to **“0”**, the call waiting tone is audible only once on the active call.
4. Click **Save Settings**.

## Preferred Line and Preferred Line Timeout

The 6735i has a feature called “preferred line” and “preferred line timeout”. If you enable the preferred line parameter on your phone, after a call ends (incoming or outgoing), the display switches back to the preferred line. Next time you go off-hook to make another call, you pickup on the preferred line. You can enable the **preferred line** parameter using the Aastra Web UI at the location, **Basic Settings->Preferences->General**. You can also set a **preferred timeout** parameter that specifies the number of seconds it takes for the phone to switch back to the preferred line.

### Note:

You can configure “Preferred Line” and “Preferred Line Timeout” using the Aastra Web UI only.

The following table provides the behavior of the preferred line focus feature with other features on the phone.

Phone Feature	Preferred Line Behavior
call return	The phone switches back to the focused line immediately after the call ends.
speed dial	The line is already specified when the speed dial is created. The phone switches back immediately after the call ends.
conference	For incoming calls, the phone switches back immediately after the call ends.
transfer	For incoming or outgoing calls, the current behavior is that the same line used to transfer the call does not change. For incoming calls, the phone switches back immediately after the call transfers.
bif	The phone switches back immediately after the call ends.
park	The phone switches back immediately after the call ends.
voicemail	The phone switches back immediately after the call ends.
redial	The phone switches back immediately after the call ends.
dialing	For incomplete dialing on a non-preferred line, the focus does not change if some digits are entered. If no digits are entered or digits were cleared, the focus changes to preferred line after the time out has passed without activities.
caller id	If the "Switch UI Focus To Ringing Line" parameter is disabled, the User is able to see the Caller ID when the phone switches the focus to the ringing line.
factory default	Factory default and recovery mode clears the "preferred line" and "preferred line timeout" parameters, and the phone operates in a non-preferred line mode.

### Notes:

1. If you specify a value of “0” for the **preferred line** parameter, it disables the preferred line focus feature.
2. If you specify a value of “0” for the **preferred line timeout** parameter, the phone returns the line to the preferred line immediately.

## Configuring “Preferred Line” and “Preferred Line Timeout” Using the Aastra Web UI



### Aastra Web UI

Use the following procedure to configure the Preferred Line and Preferred Line Timeout feature using the Aastra Web UI.

1. Click on **Basic Settings->Preferences->General**.

**Preferences**

**General**

Park Call:	<input type="text"/>
Pick Up Parked Call:	<input type="text"/>
Display DTMF Digits	<input type="checkbox"/> Enabled
Play Call Waiting Tone	<input checked="" type="checkbox"/> Enabled
Stuttered Dial Tone	<input checked="" type="checkbox"/> Enabled
XML Beep Support	<input checked="" type="checkbox"/> Enabled
Switch UI Focus To Ringing Line	<input checked="" type="checkbox"/> Enabled
Call Hold Reminder During Active Calls	<input type="checkbox"/> Enabled
Call Hold Reminder	<input type="checkbox"/> Enabled
Call Waiting Tone Period	<input type="text" value="0"/>
Preferred line	<input type="text" value="1"/>
Preferred line Timeout (seconds)	<input type="text" value="0"/>
Message Waiting Indicator Line	<input type="text" value="All"/>
DND Key Mode	<input type="text" value="Phone"/>
Call Forward Key Mode	<input type="text" value="Account"/>

2. In the “**Preferred Line**” field, select a preferred line to switch focus to after incoming or outgoing calls end on the phone. Default is **1**. Valid values are:
  - **None** (disables the preferred line focus feature)
  - **1 to 9**
 For example, if you set the preferred line to “**1**”, when a call (incoming or outgoing) ends on the phone (on any line), the phone switches focus back to Line 1.
3. In the “**Preferred Line Timeout**” field, enter the amount of time, in seconds, that the phone switches back to the preferred line after a call (incoming or outgoing) ends on the phone, or after a duration of inactivity on an active line. Default is **0**. Valid values are:
  - **0 to 999**
4. Click **Save Settings**.

## Message Waiting Indicator

You can configure the Message Waiting Indicator (MWI) to illuminate for a specific line or for all lines. For example, if you configure the MWI LED on line 3 only, the LED illuminates if a voice mail is pending on line 3. If you configure the MWI LED for all lines, the LED illuminates if a voice mail is pending on any line on the phone (lines 1 through 9).

You configure the MWI indicator using the Aastra Web UI.

### Configuring Message Waiting Indicator


Aastra Web UI

Use the following procedure to configure the message waiting indicator on a specific line or on all lines on the IP phone.

**Note:**

"Message Waiting Indicator Line" parameter is set to **ALL** lines by default.

1. Click on **Basic Settings->Preferences->General**.

**Preferences**

**General**

Park Call:	<input type="text"/>
Pick Up Parked Call:	<input type="text"/>
Display DTMF Digits	<input type="checkbox"/> Enabled
Play Call Waiting Tone	<input checked="" type="checkbox"/> Enabled
Stuttered Dial Tone	<input checked="" type="checkbox"/> Enabled
XML Beep Support	<input checked="" type="checkbox"/> Enabled
Switch UI Focus To Ringing Line	<input checked="" type="checkbox"/> Enabled
Call Hold Reminder During Active Calls	<input type="checkbox"/> Enabled
Call Hold Reminder	<input type="checkbox"/> Enabled
Call Waiting Tone Period	<input type="text" value="0"/>
Preferred line	<input type="text" value="1"/> ▼
Preferred line Timeout (seconds)	<input type="text" value="0"/>
Message Waiting Indicator Line	<input type="text" value="All"/> ▼
DND Key Mode	<input type="text" value="Phone"/> ▼
Call Forward Key Mode	<input type="text" value="Account"/> ▼

2. The "**Message Waiting Indicator Line**" field is set to **ALL** lines by default. If required, change the setting to a specific line by selecting a line from the list. Valid values are **All** and lines **1** through **9**.
3. Click **Save Settings**.

## Incoming Intercom Call Features

### Incoming Intercom

By default, the IP phone allows incoming intercom calls to be automatically answered without having to set up an Icom key on your phone. The phone automatically plays a warning tone when it receives an incoming intercom call. It also mutes the microphone. If the intercom call comes into the phone while an active call is already present, the phone puts the active call on hold and answers the intercom call.

You can change the behavior of how the phone handles incoming intercom calls by enabling/disabling specific parameters using the Aastra Web UI. The following table describes these features.

Incoming Intercom Features in Aastra Web UI	Description
Auto Answer	<p>Allows you to enable or disable the IP phone to automatically answer an Intercom call. If auto-answer is enabled on the IP phone, the phone plays a tone (if <b>"Play Warning Tone"</b> is enabled) to alert the user before answering the intercom call. If auto-answer is disabled, the phone treats the incoming intercom call as a normal call.</p> <p>Your Administrator can set a time period delay before the phone automatically answers. Contact your System Administrator for more information.</p>
Microphone Mute	Allows you to enable or disable the microphone on the IP phone for Intercom calls made by the originating caller.
Play Warning Tone	Allows you to enable or disable a warning tone to play when the phone receives an incoming intercom call on an active line.
Allow Barge In	Allows you to enable or disable how the phone handles incoming intercom calls while the phone is on an active call.

### Auto-Answer/Play Warning Tone

The auto-answer feature on the IP phone allows you to enable or disable automatic answering for an Intercom call. If "Auto-Answer" is enabled, the phone automatically answers an incoming intercom call. If "Play Warning Tone" is also enabled, the phone plays a tone to alert you before answering the intercom call. If "Auto-Answer" is disabled, the phone treats the incoming intercom call as a normal call. **"Auto-Answer"** and **"Play Warning Tone"** are enabled by default.

#### Note:

Your Administrator can set a time period delay before the phone automatically answers. Contact your System Administrator for more information.

### Microphone Mute

You can mute or unmute the microphone on the IP phone for intercom calls made by the originating caller. If you want to mute the intercom call, you enable this feature. If you want to unmute (or hear the intercom call), you disable this feature. **"Microphone Mute"** is enabled by default.

### Allow Barge In

You can configure whether or not the IP phone allows an incoming intercom call to interrupt an active call. The "Allow Barge In" parameter controls this feature. When you enable this parameter, which is the default value, an incoming intercom call takes precedence over any active call, by placing the active call on hold and automatically answering the intercom call. When you disable this parameter, and there is an active call, the phone treats an incoming intercom call like a normal call and plays the call warning tone. **"Allow Barge In"** is enabled by default.

## Configuring Incoming Intercom Settings



Use the following procedure to configure incoming intercom call settings on the IP phone.

1. Click on **Basic Settings->Preferences->Incoming Intercom Settings**.

Incoming Intercom Settings	
Auto-Answer	<input checked="" type="checkbox"/> Enabled
Microphone Mute	<input checked="" type="checkbox"/> Enabled
Play Warning Tone	<input checked="" type="checkbox"/> Enabled
Allow Barge In	<input checked="" type="checkbox"/> Enabled

2. The "**Auto-Answer**" field is enabled by default. The automatic answering feature is turned on for the IP phone for answering Intercom calls. To disable this field, uncheck the box.

**Note:**

If the Auto-Answer field is not checked (disabled), the phone treats the incoming intercom call as a normal call.

3. The "**Microphone Mute**" field is enabled by default. The microphone is muted on the IP phone for Intercom calls made by the originating caller. To disable this field, uncheck the box.
  4. The "**Play Warning Tone**" field is enabled by default. If "Auto-Answer" is enabled, the phone plays a warning tone when it receives in incoming intercom call. To disable this field, uncheck the box.
  5. The "**Allow Barge In**" field is enabled by default. If "Allow Barge In" is enabled, the phone puts an active call on hold and answers the incoming Intercom call. To disable this field, uncheck the box.
6. Click **Save Settings** to save your settings.

## Using Redial Key for "Last Number Redial"

The IP phone has an enhanced redial user interface that allows a user to quickly redial the last number that was dialed out from the phone. You can:

- Press the REDIAL button twice to redial the last number dialed.
- Press the REDIAL button once, scroll the list of numbers, then press the REDIAL button again to dial the number that displays on the screen.

The "last number redial" feature for the Redial key is static and is not configurable.

## Group RTP Paging *(receives RTP streams)*

You can configure the phone to allow it to receive a Real Time Transport Protocol (RTP) stream from pre-configured multicast address(es) without involving SIP signaling. This is called Group Paging on the IP phones. You can specify up to 5 multicast addresses that the phone listens for on the network. This feature is configurable using the Aastra Web UI only.

The 6735i in the local network listens for RTP on the preconfigured multicast address. The Phone displays the “Paging” message to the phone’s LCD. It uses the G711 uLaw CODEC for multicast RTP.

The recipient can drop the incoming page if required. The recipient can also set Do Not Disturb (DND) to ignore any incoming pages.

For incoming RTP multicasts, the ringing display is dependant on the setting for the “**Allow Barge-In**” parameter. (See “[Allow Barge In](#)” on [page 180](#).) If this parameter is disabled, and there is no other call on the phone, then the paging is automatically played via the default audio device.

If there is an existing call on the phone, the call initially displays in the ringing state. The user has the option to accept/ignore the call. If the “**Allow Barge-In**” parameter is enabled, the RTP multicast call barges in, and any existing calls are put on hold.

If an RTP multicast session already exists on the phone, and the phone receives another incoming RTP multicast session, the priority is given to the first multicast session and the second multicast session is ignored. The behavior for the incoming calls in this case is also based on the setting for the “**Allow Barge-in**” parameter. The incoming call is handled as if there were an existing call already on the phone.

### Configuring Group RTP Paging



#### Aastra Web UI

Use the following procedure to configure RTP streaming on the receiving end for Paging applications using the Aastra Web UI.

1. Click on **Basic Settings->Preferences->Group Paging RTP Settings**.

The screenshot shows a web interface with a blue header bar containing the text "Group Paging RTP Settings". Below the header, there is a text input field labeled "Paging Listen Addresses" which is currently empty.

2. In the “**Paging Listen Addresses**” text box, enter the multicast IP address(es) and port number on which the phone listens for incoming multicast RTP packets.  
Enter the IP address in dotted decimal format.  
(for example, 239.0.1.15:10000,239.0.1.20:15000)  
You can enter up to 5 listening multicast addresses.  
If this field is blank, the Paging Listening capability is disabled on the phone.

#### Notes:

1. Recipient of a Paging call can set a global “Do Not Disturb” (DND) to ignore any incoming pages.
2. For incoming Paging, the phone uses the Intercom configuration settings. The incoming Page is dependant on the “Allow Barge-In” parameter setting and the “Idling/On Call” state.


3. Click **Save Settings**.

## Shared Call Appearance (SCA) Call Bridging

Shared Call Appearance (SCA) is when incoming calls are presented to multiple phones simultaneously. For example, it is the ability to assign the boss' extension to a button on the secretary's phone. Calls can be transferred between two phones with the same extension button by simply putting the call on hold at one phone and picking it up on the other. Status LEDs light and flash in unison, allowing all people sharing the extension to see the status at a glance.

The phones include an enhanced SCA for the servers that support call bridging and allows two or more SCA users to be connected in a call with a third party.

Refer to the following example.



**Note:** A user can place a call on hold while in an SCA bridged call, by pressing the SCA line key.

Using the example above, when a call comes into Phone 1, Phone 2 and Phone 3 can pickup the same call by pressing the SCA line key. Phone 2 and 3 display the call they are bridging into on the LCD of the phones. Existing SCA parties in a bridge or one-to-one call hear an audible beep when another party has joined the call.

**Note:**

Your Administrator must enable/disable the beep on the server-side.

If a phone is configured for SCA bridging and it attempts to join a call, but the account on the server does not have this functionality enabled, an error message displays to the LCD on the phone.

The SCA call bridging feature is disabled by default on all phones. Your Administrator can enable/disable this feature if required. Contact your System Administrator for more information.

### Keys States and LED Behavior

There are two call states on the phones that support SCA bridging:

- **Bridge-active** - A bridged call is in progress
- **Bridge-held** - The 3rd-party (i.e., non-SCA party) in the bridge is on hold.

The following tables provide the key states and LED behavior in an SCA bridge call for users involved in an SCA call and users not involved in the SCA call.

**Line Keys and Idle Screens**

State	Call LED	Call Caller ID	Non-Call LED	Non-Call Caller ID
Idle	N/A	N/A	Off	N/A
Seized	Solid Green	None	Solid Red	None
Progressing (outgoing call)	Green	Called Party	Solid Red	None
Alerting (incoming call)	Blinking Unselected Red	N/A		
Active	Solid Green	Far-end	Solid Red	Far-end
Held	Slow Flashing Green	Far-end	Slow Flashing Red	Far-end
Hold private	Slow Flashing Green	Far-end	Solid Red	Far-end
Bridge-active	Solid Green	Far-end	Solid Red	Far-end
Bridge-held	Slow Flashing Green	Far-end	Solid Red	Far-end

**Softkey Line Keys**

State	Call Icon	Call LED	Non-Call Icon	Non-Call LED
Idle	Small circle	None	Small Circle	None
Seized	N/A	N/A	Solid Circle	Solid Red
Progressing (outgoing call)	Empty circle	Solid Red	Solid Circle	Solid Red
Alerting (incoming call)	Empty blinking circle	Flashing Red	N/A	N/A
Active	Empty circle	Solid Red	Solid Circle	Solid Red
Held	Reverse empty blinking circle	Slow Flashing Red	Solid Reverse Circle	Slow Flashing Red
Hold private	Reverse empty blinking circle	Slow Flashing Red	Solid Circle	Solid Red
Bridge-active	Empty circle	Solid Red	Solid Circle	Solid Red
Bridge-held	Reverse empty blinking circle	Slow Flashing Red	Solid Circle	Solid Red

**Programmable Line Keys**

State	Call Icon	Call LED	Non-Call Icon	Non-Call LED
Idle	Small circle	None	Small Circle	None
Seized	N/A	N/A	Solid Circle	Solid Red
Progressing (outgoing call)	Empty circle	Solid Red	Solid Circle	Solid Red
Alerting (incoming call)	Empty blinking circle	Flashing Red	N/A	N/A
Active	Empty circle	Solid Red	Solid Circle	Solid Red
Held	Reverse empty blinking circle	Slow Flashing Red	Solid Reverse Circle	Slow Flashing Red
Hold private	Reverse empty blinking circle	Slow Flashing Red	Solid Circle	Solid Red
Bridge-active	Empty circle	Solid Red	Solid Circle	Solid Red
Bridge-held	Reverse empty blinking circle	Slow Flashing Red	Solid Circle	Solid Red

### *Line key Phone Behavior*

<b>State</b>	<b>Call Line Key Pressed</b>	<b>Non-Call Line Key Pressed</b>
Idle	N/A	Attempt to seize the line
Seized	Hang up	Ignore
Progressing	Hang up	Ignore
Alerting	Answer	N/A
Active	Hold	Bridge
Held	Retrieve	Bridge
Hold private	Retrieve	Ignore
Bridge-active	Hold	Bridge
Bridge-held	Retrieve	Bridge

# Available Features Enabled by Administrators

There are features on your IP Phone that you can use ONLY if an Administrator has enabled them on your phone. Those features are described in this section. Contact your System Administrator for more information.


## Outgoing Intercom Calls

If your System Administrator configures the outgoing intercom feature on your phone, pressing the Icom button allows your phone to find an available line and place an intercom call to a recipient. To use this feature, you must configure an intercom key on your phone. For more information about configuring and using an Icom key, see [“Intercom Key”](#) on page 108.

## Missed Call Summary Subscription

A feature on the IP phones allows missed calls that have been redirected by the server, to be incremented in the missed calls indicator on the phone it was initially directed to. This feature is called the **Missed Call Summary Subscription** and can be configured by your System Administrator. For this feature to work, you must configure voicemail on the phone that the call was initially directed to.

For example, phones A, B, and C are connected to the server. Your Administrator configures the server to direct calls coming into phone B (which has voicemail configured) to be forwarded to phone C. When phone A calls phone B, the server forwards the call to phone C. With the **Missed Call Summary Subscription** enabled, phone B receives notification from the server that the call was forwarded and the missed calls indicator is incremented on phone B. See the illustration below.



Missed calls indicator increments on phone B.  
**Note:** Voicemail must be configured on phone B.

### Note:

Your System Administrator can configure the **Missed Call Summary Subscription** feature on a global or per-line basis.

## Customizable Callers List Key and Services Key

The 6735i IP Phone currently has a Callers List key and a Services key. Your System Administrator can specify an XML URI that creates a custom Callers List and Services application for your phone. When you press the Callers List key or the Services key, the phone accesses a custom XML URI Callers List, or a custom XML URI Service. These services replace the standard functions of the Callers List key and Services key. Contact your System Administrator for more information.

## Autodial (Hotline and Warmline)

Your System Administrator can configure an autodial feature on your phone. If autodial is enabled, the phone automatically dials a preconfigured number whenever it is off-hook. Depending on the configuration specified by your Administrator, the Autodial functions as either a “hotline”, or as a “warmline,” as follows:

- **Hotline:** The IP phone immediately dials a preconfigured number when you lift the handset.
- **Warmline:** The IP phone waits for a specified amount of time after you lift the handset before dialing a preconfigured number. If you do not dial a number within the time allotted, then the IP phone begins to dial the number.

The Autodial feature is available on a global or per-line basis. Contact your System Administrator for more information.

### Notes:

1. Any speed dial numbers that you configure on your IP phone are not affected by autodial settings.
2. If Autodial is configured on your phone, any lines that function as hotlines do not accept conference calls, transferred calls, and/or intercom calls.

## Centralized Conferencing

The 6735i supports centralized conferencing for Sylantrio and Broadsoft servers. This feature provides centralized conferencing on the SIP server (versus localized, on the phone). Your System Administrator must enable this feature on your phone before you can use centralized conferencing.

Centralized Conferencing allows you to perform the following:


- Conference two active calls together into a conference call.
- When on an active conference call, invite another party into the call.
- Create simultaneous conference calls on the same IP phone (Sylantrio servers only). For example, a user at extension 2005 could create two conferences, and put one conference on hold while conversing with the other party:
  - Line 1: conference together extensions 2005, 2010, and 2020.
  - Line 2: conference together extensions 2005, 2011 and 2021.
- Disconnect from an active conference call while allowing the other callers to remain connected.
- Add unlimited number of users to a conference (dependent on the limitations of the server).
- Join two active calls together into a conference.
- Join incoming or outgoing active calls to any existing conference.

### Reference

For more information about using Centralized Conferencing, see [“Centralized Conferencing \(for Sylantrio and Broadsoft Servers\)”](#) on [page 129](#).

## Answer and Ignore Softkeys for XML Applications

If you are accessing XML applications on your phone and a call comes in, your System Administrator can create "**Answer**" and "**Ignore**" keys that you can use to either answer the incoming call, or ignore it.



When the ◀ Ignore Answer ▶ line displays, you can press the **Right Arrow** key (Answer) to answer the incoming call without disturbing the current XML application. When you answer the call, the ◀ Ignore Answer ▶ line disappears from the LCD. Pressing the **Left Arrow** key (Ignore) ignores the incoming call without disturbing the current XML application. Contact your System Administrator for more information.

## XML Softkey for Special Characters in XML Applications

When using XML applications that require you to enter information such as Email addresses, that require special symbols (for example, the "@" symbol), your System Administrator can create an XML softkey to access these symbols. Pressing the symbol key in an XML application can display a single symbol or a list of symbols from which you can choose the symbol you need. Contact your System Administrator for more information.

## Playing a WAV File On Your Phone

If enabled by your Administrator, the 6735i IP Phone can play a WAV file. A WAV file is an audio file format standard for storing an audio bit stream on a system in raw, uncompressed format or compressed format to reduce the file size.


A WAV file is streamed to the phone using the HTTP protocol.

The WAV feature supports the following:

- Streaming of the WAV file to allow it to be locally played
- Allows you to abort the audio streaming by pressing the **Goodbye** key on the phone
- Supports the HTTP file download protocol
- Supports the aLaw and uLaw codecs
- Plays the WAV file only if the phone is idle
- WAV audio file starts only when 4 seconds of the audio data (or the complete file) has been accumulated
- Follows the standard phone behavior of speaker/head set/hand set

### IP Phone UI Screen During WAV Streaming

The 6735i screen displays the following during WAV streaming.



To abort the WAV streaming, press any of the following:

- **Goodbye** key
- **Drop** softkey

You can also place the handset (if in use) on hook.

### Using the Keypad During Active XML Applications

If enabled by your Administrator, the 6735i IP Phone can allow you to continue using your keypad keys during active XML applications on your phone. This feature is applicable only when your phone is in the connected state. By default, the phone suppresses dialpad events when an XML object is in focus, so your Administrators must enable the keypad to be used during active XML applications. Contact your System Administrator for more information.

### Key Redirection

#### Conference, Transfer, Redial, Intercom Keys and Voicemail Option

If enabled by your Administrator, the Conference, Transfer, Redial, and Intercom keys, as well as the Voicemail option, can be redirected to XML scripts. This allows the server to provide the phone with Redial, Transfer (Xfer), Conference (Conf), and Intercom (Icom) key features, and the Voicemail option feature, rather than accessing them from the phone-side. By default, the server-side keys function the same as the phone-side key features.

#### Notes:

1. Key remapping takes precedence over redirecting.
2. Disabling the redial, conference, or transfer features on the phone also disables the redirection of these keys.

Contact your System Administrator for more information about this feature.

#### Options Key

If enabled by your Administrator, the Services Menu on the 6735i IP Phone can be redirected to an XML script. This allows the server to provide the phone with available options, rather than accessing them from the phone-side. You access the XML script by selecting the Services Menu. You can still access the Services Menu from the phone-side by pressing and holding the Options key to display the phone-side Services Menu.

#### IMPORTANT NOTES

- If no Options URI script is configured, the local Options Menu on the phone displays as normal.
- If you configure password access to the Options Menu, this password is required when accessing the local Option Menu, but is not required for the Options Key redirection feature.
- Pressing the Options Menu for redirection from the server does not interfere with normal operations of the phone (for

example, pressing the options menu when on a call does not affect the call).

- If the phone is locked, you must unlock the phone before accessing the Options Menu redirect feature. After pressing the Options Key, the phone displays a screen that allows you to unlock the phone before continuing.
- On the 6735i, the redirection feature works after selecting the Services Menu. To display the original Options Menu, press and hold the Options key.

Contact your System Administrator for more information about this feature.

## XML Applications and Off-Hook Interaction

If enabled by your Administrator, the 6735i can be prevented from going into the off-hook/dialing state when the handset is off-hook and the call ends. This feature is disabled by default and must be enabled by your Administrator. The disabled behavior is as follows:

You are in a call using the handset and the phone displays an XML application. The far-end terminates the call, and a new XML application gets pushed/pulled onto the display. Since the handset is off-hook and in idle mode, the "offhook idle timer" starts. When this timer expires, the phone applies dial tone and moves to the off-hook/dialing state, which then destroys the XML application that was being displayed.

Contact your System Administrator for more information about this feature.

## XML Override for a Locked Phone

The 6735i has a feature that allows a locked phone to be overridden when an XML application is sent to the phone. This feature also allows you to still use programmable keys/softkeys/expansion module keys applicable to the XML application even though the phone is locked. However, any keys NOT associated with the XML application cannot be used when the phone is locked.

Also, XML Get Requests override the locked feature on the phone so that any softkey or programmable key pressed by the user that initiates a Get Request, continues to get sent.

Only a System Administrator can configure the feature of "XML override for a locked phone":

## RTP Recording and Simultaneous Playing

The IP Phones now allow for Real-Time Transport Protocol (RTP) recording and simultaneous playing of an audio file via XML commands created by your Administrator. The RTP and multicast RTP commands allow the phone to send/receive an RTP stream to/from given multicast/unicast addresses (without involving SIP signaling).

### Notes:

1. When an RTP stream is being sent with RTP recording and simultaneous playing (mix), the IP Phone LCD displays an icon with an 'm' on top to indicate that a mixed RTP stream is being sent.
2. When RTP stream is being received with RTP recording and simultaneous playing (mix), you can use the volume controls on the IP phone to adjust the volume (increase or decrease) to your specifications.

Contact your System Administrator for more information about this feature.

## "Hold" Feature Enhancement (for Broadsoft Servers)

The Hold feature allows you to put an active call on "hold," then retrieve the call later. This enhancement is intended for IP phones operating with servers that support RFC3264 (for example, Broadsoft). If a server does not support RFC3264, then the IP phones do not use RFC3264 functionality.


## Authentication Support for HTTP/HTTPS Download Methods Used with Broadsoft Client Management System (CMS)

If enabled by an Administrator, the 6735i has authentication support when using HTTP or HTTPS as download protocols (as per RFC 2617). When a phone is connected to a Broadsoft Server using the CMS tool, a LOGIN key displays. Pressing the LOGIN key displays a login screen with Username and Password. Username can be up to 40 characters and Password can be up to 20 characters. A System Administrator can optionally configure a Domain Name to be used as the Username (e.g. username@domain.com). A user can navigate the screen using the navigation keys (arrow keys) on the phone. The screen provides a SUBMIT key for submission of the field information, and a CANCEL key for exiting the login screen. Appropriate messages display if the phone reaches a timeout while trying to connect to the server, or if a Username or Password are incorrect.

Once the login information for a specific user is entered and accepted by the server, the phone reboots and downloads the user profile.

### IP Phone UI when Broadsoft CMS is Enabled

When the Broadsoft CMS feature is enabled on the IP Phone, the following screens display:



## Diverting Calls from Your Phone

Your Administrator can enable/disable a feature on your phone that allows incoming calls to be diverted to another phone if required.

When an outgoing call from your phone is being diverted to another destination (i.e., via call forward), the phone displays the Caller ID (phone number and/or caller name) of the new destination and the reason for the call diversion. Similarly, at the new destination, the Caller ID of the original call destination displays.

### Call Diversion Example

Tim calls Mark at x400.

Mark's phone is busy.


Mark's phone diverts the incoming call to another destination (Roger @ x 464).

Tim's phone displays name and extension of where the call is being diverted to and reason for diverting the call. The screen scrolls between Screen 1 and Screen 2.

Roger's phone accepts the call and displays the name and number of the phone the incoming call (Tim) and the name (or number) of the original destination (Mark). The screens scroll between Screen 1 and Screen 2.

See examples of the phones' LCD below.


The diversion LCD screens scroll every 3 seconds.




To enable this call diverting feature, contact your System Administrator.

### Display of Call Destination Information

By default, your phone displays call destination information if your phone is configured to forward calls to other destinations. The call destination information displays on multiple screens that scroll every 3 seconds. The following example shows call destination information on the 6735i IP Phone.



Since Call Diversion is enabled on the phone by default, the following example shows the behavior when call destination is also enabled.



**Notes:**

When both call diversion and call destination are enabled, the information displays to the phone's screens in the following order:

**Screen 1** Caller info


**Screen 2** Call destination

**Screen 3** Call diversion

If your phone does not display call destination information, your System Administrator may have disabled this feature. Contact your System Administrator for more information.

### Indication of Terminated Calls

An Administrator can configure your phone to display a disconnected screen ("Call Terminated") when the far-end hangs up. An audible busy signal is also heard on the phone. The configuration of this feature can also include the maximum time interval that the busy signal is audible. Contact your System Administrator for more information.



The following is the call terminated screen that displays on the 6735i if this feature is enabled on your phone:

IF	THEN
1 line active and far-end disconnects,	the line in focus: displays disconnected screen. plays busy tone. displays "Call Terminated" message on the screen.  the line not in focus: plays busy tone.
2 or more lines active, and far-end disconnects,	the line in focus: displays disconnected screen. plays busy tone. displays "Call Terminated" message on the screen for 5 seconds.  When 5 second times out: the busy tone stops the disconnected screen disappears.
2 or more lines active, and a line NOT in focus is disconnected by the far-end,	no busy tone plays no disconnected screen displays no "Call Terminated" message displays

IF	THEN
An incoming call comes in on the line in focus that has a disconnected screen displaying,	the line in focus with no calls on hold: displays a ringing screen  the line in focus WITH calls on hold: flashes its' Line LED
An incoming call comes in on another line (NOT in focus), and the disconnected screen is displaying on the line in focus,	the disconnected screen no longer displays on the line in focus.
A phone application is NOT in focus,	busy tone plays no disconnected screen displays  When the phone application in focus on screen stops: busy tone plays disconnected screen displays

**Note:**

This "indication of terminated calls" feature does not affect parked calls on the phone or the conference call feature.

The following procedure describes how to handle the disconnected screens on your phone.

**IP Phone UI**


1. Press the Goodbye  key.  
The busy tone stops and the disconnected screen no longer displays.  
or  
Select any Line key.  
The busy tone stops and the disconnected screen no longer displays.  
A dial screen displays.

# Model M670i and M675i Expansion Modules

The 6735i IP Phone offers optional M670i and M675i Expansion Modules that attach to the right side of the phone to provide additional softkeys.


The 6735i phone supports up to 3 expansion modules (either M675i or M670i) when powered via an optional power adapter. When using a PoE power source, 1 expansion module is supported.

## Model M670i



The M670i provides 18 softkeys in each column (totalling 36 keys) on the keypad. Each key provides an LED for indicating call status. The M670i provides a paper label for convenient key labelling.

## Model M675i



The M675i provides 10 softkeys in each column (totalling 20 keys) on the keypad. The M675i also provides 3 keys at the bottom left of the unit. These keys represent "Page 1", "Page 2", and "Page 3" of the LCD display. The M675i has 20 keys available on each page (totalling 60 softkeys). Each key provides an LED for indicating call status. The M675i provides an LCD for displaying key labels.

## Reference

For more information about using the M675i with your phone, see ["Using the Expansion Modules"](#) on [page 197](#).

The Expansion Module keys support the following functions:

None	Last Call Return (lcr)
Line	Call Forward
Speed Dial	BLF/Xfer
Do Not Disturb (DND)	Speeddial/Xfer
Busy Lamp Field (BLF)	Speeddial/Conf
BLF List	Directory
Auto Call Distribution (ACD)	Callers List
Directed Call Pickup	Icom (Intercom)
Extensible Markup Language (XML)	Services
Flash	Phone Lock
Sprecode	Paging
Park	Empty
Pickup	

You can configure the keys using the Aastra Web UI at the path, **Operation->Expansion Module <N>** when an Expansion Module is attached to the 6735i IP Phone.


#### **Reference**

For more information about configuring the expansion module keys with these functions, see the [“Softkeys and Programmable Keys”](#) on page 54.

## Using the Expansion Modules

### M670i Expansion Module

After configuring the softkeys on the M670i Expansion Module, you can record the name of the softkey on the paper labels provided with the Expansion Module. Press the softkey you want to use when applicable.




### M675i Expansion Module

The M675i Expansion Module screen displays softkeys in column format. The function keys on the bottom left of the Module allow you to display 3 full screens of softkeys. Each screen consists of 2 columns with the following default headings on each page:


Page 1 "**List 1**" and "**List 2**"

Page 2 "**List 3**" and "**List 4**"


Page 3 "**List 5**" and "**List 6**"



**Page 1 Screen**



**Page 2 Screen**



**Page 3 Screen**

To use the M675i, press the function key for the page you want to display to the LCD (page 1, page2, or page 3), and press the applicable softkey.

**Note:**

Your System Administrator can customize the headings on each M675i Expansion Module screen. Contact your System Administrator for more information.

**References**

For more information about configuring softkeys, see [Softkeys and Programmable Keys](#) on page 54.

For more information about installing M670i and M675i modules on your phone, see the

***Aastra 6735i SIP IP Phone Installation Guide.***

***Press-and-Hold to Create a Speed Dial Key***

You can press and hold an expansion module key to create a speed dial key and configure it the same way you configure a speed dial key on the phone.

For a procedure on creating a speed dial key, see [“Press-and-Hold to Create a Speed Dial \(applicable to programmable keys, softkeys, keypad keys, expansion module keys\)”](#) on page 62.

# Troubleshooting Solutions

## *Why is my display blank?*

Ensure that power is being provided to your phone. If your network does not provide inline power over Ethernet, you can obtain an additional accessory, the Aastra PoE (Power over Ethernet) inline power supply, to provide power over Ethernet locally to your phone. See the section “**Connecting to the Network and to Power**” in the *Aastra 6735i Installation Guide* for details.

## *Why is my speakerphone not working?*

If you press the  button and the speaker light flashes and you do not hear dial tone through the speaker phone, the Set Audio option in the phone's Options list has been set up for headset use. Press  a second time and if the light goes out, the phone has been set up to be used only with a headset or handset. If the light stays on steady and you hear dial tone, the phone has been set up so that you can alternate between the speakerphone and the headset by pressing . See the section “Set Audio” on page 32 for instructions on how to change the Set Audio option.

## *Why can't I get a dial tone?*

Check for any loose connections and that the phone has been installed properly. For installation instructions, please refer to the “**Installation and Setup**” section in the *Aastra 6735i Installation Guide* provided with your phone.

## *Why doesn't my phone ring?*

Check the ring volume on your phone. It may be turned down or turned off. To adjust the ringer volume setting, press the volume button when the phone is on-hook and idle. For more information, refer to the “**Adjusting Volume section**” in the *Aastra 6735i Installation Guide* provided with your phone.

## *Why is the light not coming on with a new Voice Mail Message?*

Your phone system or service provider must provide “Visual” Message Waiting service for this function to work. Check with your System Administrator for more information.

## *Why is my handset not working?*

Check to ensure that the handset cord is fully connected to both the phone and handset. See the section “**Connecting a Handset or Headset**” in the *Aastra 6735i Installation Guide* for information.

## *What are services, and how do I use them?*

Services on the IP phone include:

- XML Applications
- Callers List
- Directory List
- Voicemail

See the section, “[Services Key](#)” on [page 102](#) more information about the options available under “Services”.

## *How do I find the IP address of my phone?*

Instructions on where to find the IP address of your phone can be found in this guide in the section, “[Finding Your Phone's IP Address](#)” on [page 22](#).

## *Why does my phone display the “No Service” message?*

The phone displays the “**No Service**” message if the SIP settings have not been set up correctly.

Contact your System Administrator for more information.

### How do I change my user password?

You can change the user password from the IP phone UI or the Aastra Web UI.

 **IP Phone UI**

1. Press  on the phone to enter the Options List.
2. Select **User Password** and press **Select**.
3. Enter the current user password and press **Enter**.
4. Enter the new user password and press **Enter**.
5. Re-enter the new user password and press **Enter**.  
A message, "Password Changed" displays on the screen.

 **Aastra Web UI**

1. Click on **Operation->User Password**.

**Reset User Password**

Please enter the current and new passwords

Current Password	<input type="password" value="....."/>
New Password	<input type="password" value="....."/>
Password Confirm	<input type="password" value="....."/>

2. In the "**Current Password**" field, enter the current user password.  
**Note:**  
By default, the user name is "user" (not case sensitive) and the password field is left blank. If you have forgotten your password, contact your System Administrator for assistance.
3. In the "**New Password**" field, enter the new user password.
4. In the "**Password Confirm**" field, enter the new user password again.
5. Click **Save Settings**.

For information about changing your password, see "[User Password](#)" on [page 48](#).

### Why does my phone display "Bad Encrypted Config"?

The IP phone displays "Bad Encrypted Config" because encrypted configuration files are enabled but the decryption process has failed.

Report this error to your System Administrator.

### How do I restart the IP phone?

#### IP Phone UI

1. Press the  button on the phone to enter the Option List.
2. Select **Restart Phone**.
3. When the prompt, "Are you sure you wish to restart the phone?" appears, press the **Restart** softkey. If you do not wish to restart your phone, press Cancel.

#### Note:

Your phone is out of service temporarily during the restart and downloading process.

#### Aastra Web UI

1. Click on **Operation->Reset**.



2. Click **Restart**
3. Click **OK** at the confirmation prompt.

### How do I lock my phone?

You can lock your phone to prevent the phone from being used or configured. You can lock the phone using any of the following:

- At the path *Options->Phone Lock* on the IP Phone UI.
- At the path *Operations->Phone Lock* on the Aastra Web UI.
- At a configured key on the phone. For more information about configuring a Lock/Unlock key on your phone, see "[Paging Key \(Sends the RTP Stream\)](#)" on [page 110](#).

Use the following procedures to lock an IP phone and prevent it from being used or configured.

#### IP Phone UI

### Lock the Phone

1. Press  on the phone to enter the Options List.
2. Select **Phone Lock** and press **Select**.
3. Press **Yes** to set the phone to lock.  
The following message displays:  
"Phone is locked".

### Unlock the Phone

1. Press  on the phone to enter the Options List.
2. Enter your user password and press **Enter**.  
The phone unlocks



### Lock the Phone

1. Click on **Operation->Phone Lock**.



2. In the "**Lock the Phone?**" field, click **Lock**.  
The phone locks dynamically and displays the following message:  
"Phone is locked".

### Unlock the Phone

1. Click on **Operation->Phone Lock**.
2. In the "**Unlock the Phone?**" field, click **Unlock**.  
The phone unlocks dynamically and displays the following message:  
"Phone is unlocked".

# Limited Warranty

## (Not applicable in Australia – see below for Limited Warranty in Australia)

Aastra warrants this product against defects and malfunctions in accordance with Aastra's authorized, written functional specification relating to such products during a one (1) year period from the date of original purchase ("Warranty Period"). If there is a defect or malfunction, Aastra shall, at its option, and as the exclusive remedy, either repair or replace the product at no charge, if returned within the Warranty Period. If replacement parts are used in making repairs, these parts may be refurbished, or may contain refurbished materials. If it is necessary to replace the product, it may be replaced with a refurbished product of the same design and color. If it should become necessary to repair or replace a defective or malfunctioning product under this warranty, the provisions of this warranty shall apply to the repaired or replaced product until the expiration of ninety (90) days from the date of pick up, or the date of shipment to you, of the repaired or replacement product, or until the end of the original Warranty Period, whichever is later. Proof of the original purchase date is to be provided with all products returned for warranty repairs.

## Exclusions

Aastra does not warrant its products to be compatible with the equipment of any particular telephone company. This warranty does not extend to damage to products resulting from improper installation or operation, alteration, accident, neglect, abuse, misuse, fire or natural causes such as storms or floods, after the product is in your possession. Aastra will not accept liability for any damages and/or long distance charges, which result from unauthorized and/or unlawful use.

Aastra shall not be liable for any incidental or consequential damages, including, but not limited to, loss, damage or expense directly or indirectly arising from the customer's use of or inability to use this product, either separately or in combination with other equipment. This paragraph, however, shall not apply to consequential damages for injury to the person in the case of products used or bought for use primarily for personal, family or household purposes.

This warranty sets forth the entire liability and obligations of Aastra with respect to breach of warranty, and the warranties set forth or limited herein are the sole warranties and are in lieu of all other warranties, expressed or implied, including warranties or fitness for particular purpose and merchantability.

## Warranty Repair Services

Should the product fail during the Warranty Period;

- **In North America**, please call 1-800-574-1611 for further information.
- **Outside North America**, contact your sales representative for return instructions.

You will be responsible for shipping charges, if any. When you return this product for warranty service, you must present proof of purchase.

## After Warranty Service

Aastra offers ongoing repair and support for this product. This service provides repair or replacement of your Aastra product, at Aastra's option, for a fixed charge. You are responsible for all shipping charges. For further information and shipping instructions:

- **In North America**, contact our service information number: 1-800-574-1611.
- **Outside North America**, contact your sales representative.

### Note:

Repairs to this product may be made only by the manufacturer and its authorized agents, or by others who are legally authorized. This restriction applies during and after the Warranty Period. Unauthorized repair will void the warranty.

# Limited Warranty (Australia Only)

The benefits under the Aastra Limited Warranty below are in addition to other rights and remedies to which you may be entitled under a law in relation to the products.

In addition to all rights and remedies to which you may be entitled under the *Competition and Consumer Act 2010* (Commonwealth) and any other relevant legislation, Aastra warrants this product against defects and malfunctions in accordance with Aastra's authorized, written functional specification relating to such products during a one (1) year period from the date of original purchase ("Warranty Period"). If there is a defect or malfunction, Aastra shall, at its option, and as the exclusive remedy under this limited warranty, either repair or replace the product at no charge, if returned within the Warranty Period.

## Repair Notice

To the extent that the product contains user-generated data, you should be aware that repair of the goods may result in loss of the data. Goods presented for repair may be replaced by refurbished goods of the same type rather than being repaired. Refurbished parts may be used to repair the goods. If it is necessary to replace the product under this limited warranty, it may be replaced with a refurbished product of the same design and color.

If it should become necessary to repair or replace a defective or malfunctioning product under this warranty, the provisions of this warranty shall apply to the repaired or replaced product until the expiration of ninety (90) days from the date of pick up, or the date of shipment to you, of the repaired or replacement product, or until the end of the original Warranty Period, whichever is later. Proof of the original purchase date is to be provided with all products returned for warranty repairs.

## Exclusions

Aastra does not warrant its products to be compatible with the equipment of any particular telephone company. This warranty does not extend to damage to products resulting from improper installation or operation, alteration, accident, neglect, abuse, misuse, fire or natural causes such as storms or floods, after the product is in your possession. Aastra will not accept liability for any damages and/or long distance charges, which result from unauthorized and/or unlawful use.

To the extent permitted by law, Aastra shall not be liable for any incidental damages, including, but not limited to, loss, damage or expense directly or indirectly arising from your use of or inability to use this product, either separately or in combination with other equipment. This paragraph, however, is not intended to have the effect of excluding, restricting or modifying the application of all or any of the provisions of Part 5-4 of Schedule 2 to the Competition and Consumer Act 2010 (**the ACL**), the exercise of a right conferred by such a provision or any liability of Aastra in relation to a failure to comply with a guarantee that applies under Division 1 of Part 3-2 of the ACL to a supply of goods or services.

This express warranty sets forth the entire liability and obligations of Aastra with respect to breach of this express warranty and is in lieu of all other express or implied warranties other than those conferred by a law whose application cannot be excluded, restricted or modified. Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and for compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.

## Warranty Repair Services

**Procedure: Should the product fail during the Warranty Period and you wish to make a claim under this express warranty, please contact the Aastra authorized reseller who sold you this product (details as per the invoice) and present proof of purchase. You will be responsible for shipping charges, if any.**

Manufacturer: Aastra Telecom Australia Pty Ltd  
745 Springvale Road  
Mulgrave VIC 3170  
ABN 16 140 787 195  
Phone: +61 3 8562 2700

### **Limitation of Liability for Products not of a kind ordinarily acquired for personal, domestic or household use or consumption (e.g. goods/services ordinarily supplied for business-use)**

- 1.1** To the extent permitted by law and subject to clause 1.2 below, the liability of Aastra to you for any non-compliance with a statutory guarantee or loss or damage arising out of or in connection with the supply of goods or services (whether for tort (including negligence), statute, custom, law or on any other basis) is limited to:
- a)** in the case of services:
    - i)** the resupply of the services; or
    - ii)** the payment of the cost of resupply; and
  - b)** in the case of goods:
    - i)** the replacement of the goods or the supply of equivalent goods; or
    - ii)** the repair of the goods; or
    - iii)** the payment of the cost of replacing the goods or of acquiring equivalent goods; or
    - iv)** the payment of the cost of having the goods repaired.
- 1.2** Clause 1.1 is not intended to have the effect of excluding, restricting or modifying:
- a)** the application of all or any of the provisions of Part 5-4 of Schedule 2 to the Competition and Consumer Act 2010 (**the ACL**); or
  - b)** the exercise of a right conferred by such a provision; or
  - c)** any liability of Aastra in relation to a failure to comply with a guarantee that applies under Division 1 of Part 3-2 of the ACL to a supply of goods or services.

## After Warranty Service

Aastra offers ongoing repair and support for this product. If you are not otherwise entitled to a remedy for a failure to comply with a guarantee that cannot be excluded under the Australian Consumer Law, this service provides repair or replacement of your Aastra product, at Aastra's option, for a fixed charge. You are responsible for all shipping charges. For further information and shipping instructions contact:

Aastra Telecom Australia Pty Ltd  
745 Springvale Road  
Mulgrave VIC 3170  
ABN 16 140 787 195  
Phone: +61 3 8562 2700

### **Note:**

Repairs to this product may be made only by the manufacturer and its authorized agents, or by others who are legally authorized. Unauthorized repair will void this express warranty.

# Appendix A - Time Zone Codes

The following table identifies the time zone name and time zone code to use on the IP phone.

**Time Zone Name/Time Zone Code Table**

Time Zone Name	Time Zone Code
AD-Andorra	CET
AE - Dubai	GST
AG-Antigua	AST
AI-Anguilla	AST
AL-Tirane	CET
AN-Curacao	AST
AR-Buenos Aires	ART
AS-Pago Pago	BST
AT-Vienna	CET
AU-Lord Howe	LHS
AU-Tasmania	EST
AU-Melbourne	EST
AU-Sydney	EST
AU-Broken Hill	CST
AU-Brisbane	EST
AU-Lindeman	EST
AU-Adelaide	CST
AU-Darwin	CST
AU-Perth	WST
AW-Aruba	AST
AZ - Baku	AZT
BA-Sarajevo	EET
BB-Barbados	AST
BE-Brussels	CET
BG-Sofia	EET
BM-Bermuda	AST
BO-La Paz	BOT
BR-Noronha	FNT
BR-Belem	BRT
BR-Fortaleza	BRT
BR-Recife	BRT
BR-Araguaina	BRS
BR-Maceio	BRT
BR-Sao Paulo	BRS
BR-Cuiaba	AMS
BR-Porto Velho	AMT
BR-Boa Vista	AMT
BR-Manaus	AMT
BR-Eirunepe	ACT
BR-Rio Branco	ACT
BS-Nassau	EST
BY-Minsk	EET
BZ-Belize	CST

Time Zone Name	Time Zone Code
CA-Newfoundland	NST
CA-Atlantic	AST
CA-Eastern	EST
CA-Saskatchewan	EST
CA-Central	CST
CA-Mountain	MST
CA-Pacific	PST
CA-Yukon	PST
CH-Zurich	CET
CK-Rarotonga	CKS
CL-Santiago	CLS
CL-Easter	EAS
CN-Beijing	CST
CO-Bogota	COS
CR-Costa Rica	CST
CU-Havana	CST
CY-Nicosia	EES
CZ-Prague	CET
DE-Berlin	CET
DK-Copenhagen	CET
DM-Dominica	AST
DO-Santo Domingo	AST
EE-Tallinn	EET
ES-Madrid	CET
ES-Canary	WET
FI-Helsinki	EET
FJ-Fiji	NZT
FK-Stanley	FKS
FO-Faeroe	WET
FR-Paris	CET
GB-London	GMT
GB-Belfast	GMT
GD-Grenada	AST
GE - Tbilisi	GET
GF-Cayenne	GFT
GI-Gibraltar	CET
GP-Guadeloupe	AST
GR-Athens	EET
GS-South Georgia	GST
GT-Guatemala	CST
GU-Guam	CST
GY-Guyana	GYT
HK-Hong Kong	HKS
HN-Tegucigalpa	CST
HR-Zagreb	CET
HT-Port-au-Prince	EST
HU-Budapest	CET
IE-Dublin	GMT
IS-Reykjavik	GMT
IT-Rome	CET
JM-Jamaica	EST
JP-Tokyo	JST
KY-Cayman	EST

Time Zone Name	Time Zone Code
LC-St Lucia	AST
LI-Vaduz	CET
LT-Vilnius	EET
LU-Luxembourg	CET
LV-Riga	EET
MC-Monaco	CET
MD-Chisinau	EET
MK-Skopje	CET
MQ-Martinique	AST
MS-Montserrat	AST
MT-Malta	CET
MU - Mauritius	MUT
MX-Mexico City	CST
MX-Cancun	CST
MX-Merida	CST
MX-Monterrey	CST
MX-Mazatlan	MST
MX-Chihuahua	MST
MX-Hermosillo	MST
MX-Tijuana	PST
NI-Managua	CST
NL-Amsterdam	CET
NO-Oslo	CET
NR-Nauru	NRT
NU-Niue	NUT
NZ-Auckland	NZS
NZ-Chatham	CHA
OM - Muscat	GST
PA-Panama	EST
PE-Lima	PES
PL-Warsaw	CET
PR-Puerto Rico	AST
PT-Lisbon	WET
PT-Madeira	WET
PT-Azores	AZO
PY-Asuncion	PYS
RO-Bucharest	EET
RU-Kaliningrad	EET
RU-Moscow	MSK
RU-Samara	SAM
RU-Yekaterinburg	YEK
RU-Omsk	OMS
RU-Novosibirsk	NOV
RU-Krasnoyarsk	KRA
RU-Irkutsk	IRK
RU-Yakutsk	YAK
RU-Vladivostok	VLA
RU-Sakhalin	SAK
RU-Magadan	MAG
RU-Kamchatka	PET
RU-Anadyr	ANA
SE-Stockholm	CET
SG-Singapore	SGT
SI-Ljubljana	CET
SK-Bratislava	CET
SM-San Marino	CET
SR-Paramaribo	SRT
SV-El Salvador	CST

<b>Time Zone Name</b>	<b>Time Zone Code</b>
TR-Istanbul	EET
TT-Port of Spain	AST
TW-Taipei	CST
UA-Kiev	EET
US-Eastern	EST
US-Central	CST
US-Mountain	MST
US-Pacific	PST
US-Alaska	AKS
US-Aleutian	HAS
US-Hawaii	HST
UY-Montevideo	UYS
VA-Vatican	CET
YU-Belgrade	CET

# Index

## Numerics

6735i	
additional features of	168
features of	1
line settings	53
making calls	116
requirements of	2

## A

Aastra Web UI	
Basic Settings parameters	20
Operaton parameters	19
phone status	19
about this guide	1
account configuration	148
ACD key	75
Additional	168
allow barge-in, for intercom	180
answering incoming calls	121
auto-answer, for intercom	180
autodial (hotline and warmline)	187

## B

backlight, setting	29
bad encrypted config	200
BLF key	71
BLF List key	72
BLF List, setting softkey for	73
BLF, setting softkey for	71
BLF/Xfer	96
BLF/Xfer key	96
BLF/Xfer, softkeys for	97, 99, 100

## C

call destination, displaying	192
Call Forward key	95
call forwarding, softkeys for	95
call hold reminder	175
call hold reminder during active calls	174
call waiting tone	170
call waiting tone period	176
callers list	143
deleting entries in	146
downloading to phone	142, 147
editing	145
using	144
using on phone	144
Callers List key	106
callers list key, customizable	186
callers list, softkey for	107
calls	
receiving	121
calls, ending	132
calls, transferring	123
conferencing	
ending	131
joining two active calls	129
local	127
pre-dial and live dial mode	127

transfer remaining parties	131
conferencing calls	126
conferencing, centralized	187
contrast level, setting	28

## D

DCP key	79
deleting a key	115
dial plan, emergency	52
dial tones, stuttered	171
dialing	
pre-dialling a number	116
dialing a number	116
dialpad, live	31
Directory key	104
directory key, softkey for	105
directory list	133
adding and editing entries	134
arranging entries	137
deleting numbers and labels for an entry	138
downloading to PC	141
limitations for	134
scrolling multiple screens	136
sorting	134
using	142
diverting calls	191
DND key	69
DND, enabling/disabling	148, 152
do not disturb, setting softkey for	70
documentation	1
DTMF digits, displaying	169

## E

emergency dial plan, defining	52
Empty key	114
empty key, softkey for	113, 114
expansion module, M670i and M675i	195
expansion module, M675i	195

## F

Flash key	89
-----------	----

## G

GCP key	79
getting started	3
group RTP paging	182

## H

handling calls	122
headset mic	117
headset mode	32
headset, using	117
headset/speaker mode	32
held calls, retrieving	123
hold, automatic	123
hold, feature enhancement for	190

## I

idle screen	6
Indication of transferred calls	126

installation and setup .....	2
intercom calls	
incoming call features .....	180
Intercom key .....	108
Intercom key, softkey for .....	108
intercom, outgoing calls using .....	186
Intercom, using .....	118
Introduction .....	1
IP address, finding .....	22, 23, 199
<b>K</b>	
key descriptions .....	11
key redirection .....	189
Keypad Keys .....	13
keys	
ACD key .....	75
BLF key .....	71
BLF List key .....	72
BLF/Xfer key .....	96
Call Forward key .....	95
Callers List key .....	106
DCP and GCP .....	79
deleting .....	115
Directory key .....	104
DND key .....	69
Empty key .....	114
Flash key .....	89
Intercom key .....	108
Last Call Return (lcr) .....	94
Line key .....	59
None key .....	113
Paging key .....	110
Park and Pickup keys .....	91
Phone Lock key .....	109
Services key .....	102
Speeddial/Conf key .....	100
Speeddial/Xfer key .....	98
Sprecode key .....	90
XML key .....	83
<b>L</b>	
language	
latin 2 character set .....	47
overview .....	41
specifying on IP phone .....	41
last call return, softkeys for .....	94
LCR key .....	94
Line key .....	59
line, setting a softkey for .....	60
lock/unlock the phone .....	50, 201
<b>M</b>	
M670i .....	195
M675i .....	195
making calls .....	116
managing calls .....	133
message waiting indicator, configuring .....	179
microphone mute, for intercom .....	180
microphone volume, headset .....	32
missed call summary subscription .....	186
missed calls indicator	
accessing and clearing .....	166
overview .....	166
multiple line call appearances .....	53
<b>N</b>	
network disconnected .....	5
no service .....	199
None key .....	113
<b>O</b>	
on-hold calls .....	122
options	
setting via the phone UI .....	14
setting via the Web UI .....	17
<b>P</b>	
Paging key .....	110
paging, softkeys for .....	111
Park key .....	91
park/pickup	
using on the IP phone .....	92
password, resetting user's .....	49
phone lock .....	50
Phone Lock key .....	109
playing a WAV file .....	188
plugging in the phone .....	3
preferred line .....	177
preferred line timeout .....	177
programmable keys .....	54
<b>R</b>	
redial .....	119
restarting the phone .....	50
ring tone sets .....	26
ring tones .....	25
RTP paging, group .....	182
<b>S</b>	
Services key .....	102
services key, customizable .....	186
softkeys .....	54
answer softkey for XML .....	188
ignore softkey for XML .....	188
special character softkey for XML .....	188
state-based .....	56
speaker mode .....	32
speaker/headset mode .....	32
Speeddial	
creating using function keys .....	65
creating using Keypad Speeddial .....	66
creating using Speed Dial Edit .....	63
editing .....	68
speeddial	
assigning as softkey or programmable key .....	61
creating from Keypad Speeddial in Web UI .....	66
prefix .....	61
Speeddial key .....	61
press-and-hold .....	62
speeddial keys, editing .....	66
speeddial/Xfer .....	98
Speeddial/Xfer key .....	98
Sprecode key .....	90
sprecode, setting key for .....	90
star codes .....	168
starting up the phone .....	3
switch UI focus to ringing line .....	173
<b>T</b>	
terminated calls indication .....	193

time and date .....	34	VM message light not working .....	199
time and date format .....	34	<b>U</b>	
transferring calls, blind .....	123	user password .....	48
transferring calls, consultative .....	123	<b>V</b>	
transferring calls		voicemail .....	121, 167
indication of .....	126	<b>W</b>	
transferring calls		warning tone, for Intercom .....	180
pre-dial and live dial mode .....	123	warranty exclusions .....	1
troubleshooting solutions .....	199	Web UI, using .....	17
changing user password .....	200	<b>X</b>	
display blank .....	199	XML application title .....	83
finding IP address .....	199	XML application URI .....	83
handset not working .....	199	XML beep support .....	172
locking/unlocking phone .....	201	XML features .....	189, 190
no dial tone .....	199	XML key .....	83
no ring .....	199	XML services	
no speakerphone .....	199	accessing .....	88
phone displays "Bad Encrypted Config" .....	200		
phone displays "No Service" .....	199		
restarting the phone .....	201		
using services .....	199		



### **Disclaimer**

Aastra Telecom Inc. will not accept liability for any damages and/or long distance charges, which result from unauthorized and/or unlawful use. While every effort has been made to ensure accuracy, Aastra Telecom Inc. will not be liable for technical or editorial errors or omissions contained within this documentation. The information contained in this documentation is subject to change without notice.

Copyright © 2013 Aastra Technologies Limited, [www.aastra.com](http://www.aastra.com).

